

SPEAKERPHONE SYSTEM—3-TYPE 702B TELEPHONE SET CONNECTIONS AND MAINTENANCE

1. GENERAL

1.01 This section covers information necessary to modify and connect the 702B telephone set to provide speakerphone service.

1.02 This section is reissued to:

- Change section reference in 3.01.
- Include 55A* modified control unit, Fig. 2.

2. CONNECTION INDEX

Table A—Modification for 3-Type Speakerphone

Fig. 1—702B Telephone Set—Wired for 3-Type Speakerphone

Fig. 2—702B Telephone Set—Speakerphone Connections

3. MAINTENANCE

3.01 ♦ Refer to Division 502 for maintenance of 702B telephone set and to Division 512 for maintenance of speakerphone components. ♦

TABLE A
MODIFICATION FOR 3-TYPE SPEAKERPHONE

| WIRE OR LEAD | COLOR | REMOVE FROM | CONNECT TO | | INSULATE AND STORE |
|-----------------------|----------------|-------------|------------|-------------|--------------------|
| | | NETWORK | NET. | TERM. BLOCK | |
| Line Switch | (S) | A | L2 | | |
| | (Y) [S-Y] | L2 | | 3 | |
| | (BR) [S-BR] | C | G | | |
| Ringer | (BK) | G | L1 | | |
| Network | (BK) [S-BK] | A | | | • |
| Strap* | | | A ↔ C | | |
| D6AF Mounting Cord | (R) | | C | | |
| | (BL) | | G | | |
| | (Y) | | L2 | | |
| | (G) | | L1 | | |
| | (W) | | | 3 | |
| | (BK) | | | 4 | |

* Use M1W cord or equivalent.

() Indicates current color code.

[] Indicates MD color code.




Fig. 2—702B Telephone Set—Speakerphone Connections