

## ATTENDANT DIRECT STATION SELECTION CIRCUIT SD-66865-01

### WHEN USED WITH 1- AND 2-TYPE TELEPHONE CONSOLE

#### OPERATION TEST

#### 701A OR 701B PBX

#### 1. GENERAL

**1.01** This test checks the ability of the attendant direct station selection circuit to directly select one of a maximum of 200 PBX stations when the attendant depresses a single key. Also checked is busy lamp operation, attendant release of called station, and overlap operation.

**1.02** This test should be repeated for each station connected to the selector console.

**1.03** A busy lamp is provided under the key of each station appearing on the selector console.

**1.04** The RDY lamp is located on the telephone console.

**1.05** When a step requires a key to be depressed, the key is nonlocking and should be momentarily depressed, then released.

**1.06** This test requires action and verification at the telephone console, selector console, and two PBX stations.

---

#### 2. METHOD

STEP	ACTION	VERIFICATION
<b>Call Extended To Idle PBX Station</b>		
1	At telephone console — Depress OUT LINE key.	PBX dial tone heard. OUT LINE lamp lights.
2	At selector console — Depress key associated with PBX station to be called.	At telephone console — PBX dial tone removed. Audible ringing tone heard.
3	At called station — Station answers.	At selector console — Key lamp associated with called station lights.
4	At telephone console — Request called station to disconnect.	At selector console — Key lamp extinguishes.
5	At telephone console — Depress PA RLS key.	PA RLS lamp lights. OUT LINE lamp extinguishes. Console idle.

**SECTION 542-011-501**

<b>STEP</b>	<b>ACTION</b>	<b>VERIFICATION</b>
<b>Attendant Releases Called Station</b>		
6	At telephone console — Depress OUT LINE key.	PBX dial tone heard. OUT LINE lamp lights.
7	At selector console — Depress key of nearby idle PBX station.	PBX dial tone removed. Audible ringing tone heard. At nearby PBX station — Bell rings.
8	Station does not answer.	Bell continues to ring.
9	At telephone console — Depress RLS DEST key.	Audible ringing removed. OUT LINE lamp extinguishes. At nearby PBX station — Bell tripped.
<b>Overlap Test</b>		
10	At telephone console — Depress OUT LINE key.	PBX dial tone heard. OUT LINE lamp lights.
11	At selector console — Simultaneously depress two or more keys associated with two nearby PBX stations.	At one PBX station — Bell rings.
12	Station answers.	Bell tripped.
13	At telephone console — Request station to disconnect.	
14	Depress PA RLS key.	PA RLS lamp lights. Console idle. OUT LINE lamp extinguishes.