Avaya™ M4648ML-T Installation Guide

The Avaya M4648ML-T is a 48 10/100BASE-T port multilayer I/O module for the Avaya™ C460 switch.

Figure 1   M4648ML-T Front Panel

Safety Information

Caution: The Avaya C460 switch and modules contain components sensitive to electrostatic discharge. Do not touch the circuit boards unless instructed to do so.

Caution: Do not leave any slots open. Use the the blanking plates supplied to cover empty slots.

Caution: Do not insert any objects into the C460 chassis other than specifically designed Avaya products.

Warning: Keep your fingers and other objects clear of the fan module. The fans are on whenever the power is on in the chassis.

# IInstalling the Module in the Avaya C460

ⓘ You can install I/O modules in slots 3 to 6 only.

Figure 2   Installing C460 I/O Modules

Key

a   Open locking handle
b   Closed locking handle

1   Remove the existing module or blanking plate (see "Removing the Module from the Avaya C460")
2   Open the locking handles at the edge of the front panel.
3   Position the module in the slot with the module name towards the top left-hand side of the module.
4   Gently slide the module in.
ⓘ Ensure the hooks on the locking handle are aligned with the matching holes on the chassis.
5   Close the locking handles.
▶   The module slides back and connects to the backplane.
6   Gently tighten the screws.

Removing the Module from the Avaya C460

1   Loosen the screws.
2   Open the locking handles.
▶   The module is disconnected from the backplane and slides forward.
3   Grasp the handles and pull gently but firmly towards yourself.
4   Insert another module or a blanking plate.

Specifications

Power requirement

48 W

Interface

48 10/100BASE-T ports (RJ-45)

Ordering information

Product	Material Code
Avaya M4648ML-T	700255029

avaya.com