

MANUAL MESSAGE ADDRESS SEGREGATOR
CIRCUIT DESCRIPTION, SCHEMATIC AND
ACTUAL WIRING DIAGRAMS

1. GENERAL

1.01 This section provides the circuit description, schematic and actual wiring diagrams for the Manual Message Address Segregator. For description and operation, refer to Section 573-114-100TC. Installation and checkout procedures can be found in Section 573-114-200TC.

1.02 The attached material consists of Teletype Corporation diagrams. Part 2 WIRING DIAGRAM INDEX lists the title in the first column, the number of control and diagram sheets in the second column, the identification number in the third column, and the last column lists either the current issue number of the control sheet covering all sheets of the diagram or the issue number of any diagram that does not have an issue control sheet.

2. WIRING DIAGRAM INDEX

TITLE	TOTAL CONTROL AND DIAGRAM SHEETS	DIAGRAM NUMBER	CONTROL SHEET OR DIAGRAM ISSUE
SCHEMATIC WIRING DIAGRAMS			
Manual Message Address Segregator Wiring Diagram Package	2	WDP0116	2
Manual Message Address Segregator	37	8617WD	2
28 Transmitter Distributor LXD44	3	8615WD	1
Transmitter Distributor Base LXDB21 and Motor Unit LMU19	3	8616WD	1