

28 ANSWER-BACK UNIT

For information on the 28 answer-back unit, refer to the following sections:

574-235-100	28 and 35 Answer-Back Unit General Description and Principles of Operation
574-235-200	28 and 35 Answer-Back Unit Installation
574-235-400	28 and 35 Answer-Back Unit Actual and Schematic Wiring Diagram
574-235-700	28 and 35 Answer-Back Unit Adjustments
574-235-701	28 and 35 Answer-Back Unit Lubrication
574-235-702	28 and 35 Answer-Back Unit Disassembly and Reassembly
574-235-800	Self-Contained Answer-Back Unit (LABD) Parts