


33 KEYBOARD (UK)

PARTS

FIGURE	CONTENTS	PAGE
1	Keyboard Basket and Contact Block	2
2	186752 Modification Kit to Provide Locking for Keyboard (Early Design)	3
3	186752 Modification Kit to Provide Locking for Keyboard (Later Design)	3
4	Keyboard Covers	4
5	Keytops	5
6	Keylevers	6
7	Codebar Mechanism	7
8	Codebar Mechanism for Units Equipped with Even Parity	8
9	Codebar Mechanism for Numeric Keyboard	9
10	Reset Mechanism for Self-Contained and Solenoid Reset Keyboards	10
11	Reset Mechanism for Even Parity Keyboard	11
12	Cover for Self-Contained and Solenoid Reset Keyboards	12
13	Cable Components	13
14	185801 Modification Kit to Provide Locking for Keyboard	14
	Numerical Index	15

** Denotes a Painted Part
HF - Light Olive Gray Smooth Vinyl

NOTE: Refer to Section 574-020-800
for Additional 33 Keypop Descriptions.



- ① The insulators and terminals are permanently secured on the Late Design Contact Blocks and should not be ordered for replacement purposes; however, insulators and terminals are available for replacement on the Early Design Contact Blocks. The Late Design Contact Assembly is interchangeable with the complete set of parts which makes up the Early Design Contact Block Assembly.
- ② When adding the signal line break feature on keyboard(serial numbers 48,000 through 58,000)check to see if slot has been provided in the frame. (See Figure 6 for keylevers.)
- ③ Tolerances may vary the amount of flat washers used.
- ④ 180115 Modification Kit for the alternate routing of the reader cable
- ⑤ 184107 Right Contact Block Assembly
- ⑥ Used with laminated base
- ⑦ Used with cast base
- ⑧ See Note 1 on page 7.

Fig. 1 - Keyboard Basket and Contact Block




Fig. 2 - 186752 Modification Kit To Provide Locking For Keyboard
(Early Design)




Fig. 3 - 186752 Modification Kit To Provide Locking For Keyboard
(Later Design)







Fig. 4 - Keyboard Covers




Keytop Description			Keytop Description			Keytop Description		
UNSHIFT	SHIFT	Part Number	UNSHIFT	SHIFT	Part Number	UNSHIFT	SHIFT	Part Number
A		180181	P	@	180180	8		①③ 184341
A	SOM	*183891	Q		180171	9)	180168
A		①③ 184343	Q	X ON	*183888	9		①③ 184342
B		180194	Q	X-ON	184869	0		180169
B		①③ 184344	Q	RLF	185160	∅		180374
C		180192	R	TAPE	180174	-	=	180170
C		①③ 184345	R		180260	,	<	180197
C	ETX	185165	R	FS	185161	.	>	180198
D	EOT	180193	S		180282	;	+	180199
D		180278	S	X OFF	180182	/	?	180200
D		①③ 184346	S	X OFF	*183892	:	*	180205
E	WRU	180173	S		③ 185374	(No Symbol)		① 180297
E		180259	T	TAPE	180175	-		180336
E	WRU	*183889	T		180261		*	180335
F	RU	180184	T	PR	185162	/	.	180418
F		180273	T		③ 185395	/	.	180419
G	BELL	180185	U		180177	/	■	184895
G		180274	V		180193	RUB OUT		①③ 180201
G	BELL	*183890	W		180172	RETURN		①③ 180202
H		180186	X		180191	LINE FEED		①③ 180203
H	BS	185163	X		③ 185376	HERE IS		180206
I	TAB	180178	Y		180176	BREAK		180207
I		180262	Z		180190	REPT		①③ 180208
J		180187	1	!	180160	ALT MODE		180257
K	VT	180188	1		①③ 184334	ESC		180382
K		180280	1		180264	EOT		①③ 180440
K		180383	2	"	180161	DIV		① 180441
K	I	185090	2		①③ 184335	STORE		① 180442
L	FORM	180189	2	#	180162	TYPE ORD		① 180443
L		180281	3		180166	SECT		① 180444
L		180385	3		①③ 184336	SHIFT		180061
L	FORM	185164	3		180161	CTRL		181253
M		180196	4	\$	180163	CTRL		② 181971
M		180384	4		①③ 184337	FS		① 184815
M	I	185093	4	%	180164	GS		① 184816
N	↑	180195	5		180166	RS		① 184817
N	BLK	185092	5		①③ 184338	US		① 184818
N	↖	185150	6	&	180165	CLR KYBD		184734
N	↗	180179	6		①③ 184339	CTRL		185159
O	↙	185089	7	'	180166	TAB		180373
O	↘	185089	7		①③ 184340			
			8	(180167			

NOTE: All Keytops are gray with white characters except as noted.

*Gray Keytops with yellow characters.
 ① Used on Numeric Keyboard.
 ② Used with parity control.
 ③ Used on Numeric Self-Contained Keyboard

Fig. 5 - Keytops



- ① Used in Bottom Row.
- ② Used in Second Row.
- ③ Used in Third Row.
- ④ Used in Top Row.
- ⑤ Used in Numeric Keyboard (Bottom Row).
- ⑥ Used in Numeric Keyboard (Second Row).
- ⑦ Used in Numeric Keyboard (Third Row).
- ⑧ Used in Numeric Keyboard (Top Row).
- ⑨ Early Design Parts

Fig. 6 - Keylevers




Fig. 7 - Codebar Mechanism




Fig. 8 - Codebar Mechanism For Units Equipped With Even Parity





Fig. 9 - Codebar Mechanism For Numeric Keyboard




**Refer to page 1 for finish suffix

Fig. 12 - Cover For Self-Contained and Solenoid Reset Keyboards

Components	CABLE ASSEMBLIES											
	180870	180908	181978	①181969	184034	184051	184198	184199	185845	186156	①187009	195482
320418									X			
155750			X						X			
155752										X		X
161238									X	X		X
171956							X					
171959								X				
171965							X					
171970								X				
180044	X	X	X	X	X	X	X	X	X	X	X	X
180045		X										
180586												X
181892								X				
181973			X				X					
181974			X				X					
182540	X		X	X	X	X		X			X	
182643	X		X	X	X	X	X	X			X	
182644	X		X	X	X	X		X			X	
182674				X							X	
182675				X							X	
182693					X	X						
182726	X	X	X	X	X	X	X	X	X	X	X	X
195614	X		X	X	X	X		X				
320410		X								X		X

① Includes 184135, 184109 Contact Blocks on Figure 8.



CONNECTORS						
Inner (Length .31)				Outer (Length .25)		
Part No.	I.D.	O.D.	Color	Part No.	I.D.	Color
171956	.180	.204	Green	171965	.261	Yellow
171959	.261	.297	Blue	171970	.375	Blue

Fig. 13 - Cable Components




Fig. 14 - 185801 Modification Kit To Provide Locking For Keyboard

NUMERICAL INDEX

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
1263	Screw, 6-32 x 1/4 Fil 3	145321	Tie, Cable 10	180022	Codebar, No. 6 Rear 7
1297	Screw, 6-40 x 2-7/16 Fil 10	150241	Spring 10	180023	Codebar, No. 5 Front 7
2034	Washer, Flat 10	151152	Screw, 4-40 x 3/16 Hex 10	180024	Codebar, No. 5 Rear 7,8
2191	Lockwasher 3,10,12,14	151629	Nut, 6-40 Lug 10,14	180025	Codebar, No. 5 Front 7,8
3438	Washer, Flat 10	151686	Screw, 6-40 x 3/8 Fil 14	180027	Cover, Keyboard 4
3598	Nut, 6-40 Hex 12	151692	Screw, 6-40 x 3/16 Fil 12	180028	Lever 7,8,9
3599	Nut, 4-40 Hex 3	151721	Screw, 6-40 x 3/4 Hex 14	180029	Lever 7,8,9
3624	Washer, Flat 2,3,10	151880	Nut, 4-40 Hex 3,14	180030	Lever, Latch 7
3640	Lockwasher 12,14	152893	Screw, 4-40 x 1/4 Hex 11	180031	Spring, Compression 2,8,9,10
3646	Lockwasher 10	153020	Guide, Line 12	180032	Lever, Non-Repeat 7,8,9
5740	Screw, 2-56 x 1/4 Fil 3	153021	Spring, Torsion 12	180033	Shaft 7,8,9
6345	Nut, 6-32 Hex 3	153022	Bushing 12	180034	Spring, Flat 7,8,9
7002	Washer, Flat 3,8,10,12,14	153103	Screw, 4-40 Self-Tapping 11	180036	Codebar, Universal 7,9
8330	Washer, Flat 10	153267	Washer, Felt 14	180040	Block, Contact 2,8,9,10,11
35503	Foot, Rubber 12	153538	Screw, 6-40 x 7/16 Hex 12	180041	Spring 2,8,9,10
41663	Washer, Flat 4	153539	Screw, 6-40 x 11/16 Hex 10	180043	Wire, Contact 2,8,9,10
61085	Lockwasher 10	153799	Screw, 4-40 x 21/64 Hex 10	180044	Terminal, Tab Type 7,9,10,13
71073	Washer, Flat 3	155750	Sleeve, 3/32 ID x 1/2" Lg Insulating 13	180045	Terminal, Tab Type 13
74614	Resistor, 2,6000 Ohm 10	155752	Sleeve, 5/64 ID x 1/2" Lg 13	180046	Bail, Contact Reset 2,8,9,10,11
75750	Washer, Insulating 10	155753	Sleeve, 1/8 ID x 1/2" Lg 10	180048	Keylever 6
80581	Spring 7	155755	Sleeve, 11/64 ID x 5/8" Lg Insulating 3,10,11,14	180049	Keylever 6
84575	Spring 7,8,9	156448	Bushing 12	180050	Keylever 6
86079	Washer, Felt 3	156633	Washer, Felt 2	180051	Keylever 6
90749	Shim, .010" Thk 10	161238	Connector, 36 Pt Receptacle 10,13	180052	Keylever, Shift 6
90790	Washer, Flat 3	161239	Connector, 36 Pt Plug 10	180054	Keylever, Spacebar 6,7
91228	Strap, 2-1/2" Braided 10	161346	Washer, Felt 14	180055	Keylever, Spacebar 7,8
91229	Strap, 2" Braided 2	162590	Shaft 12	180056	Link, Space 7,8
92260	Lockwasher 12	163327	Ring, Retaining 7,8,9	180057	Spacebar 5,7
93117	Lockwasher 3,10,11	171956	Connector, Green Shielding 13	180061	Keypop 5
93984	Lockwasher 3	171959	Connector, Blue Shielding 13	180064	Keylever, Repeat 6
98726	Screw, 3-48 x 1/4 Fil 10	171965	Connector, Yellow Shielding 13	180065	Lever, Link Break 7
100337	Spring 2	171970	Connector, Blue Shielding 13	180066	Keylever 6
101796	Washer, Felt 10	172632	Screw, 4-40 x 3/16 Hex 11	180067	Codebar, No. 7 Rear 7
104807	Washer, Flat 3	178707	Bumper, Rubber 10	180068	Codebar, No. 7 Front 7
110434	Screw, 4-40 x 3/16 Fil 12	180000	Frame, Keyboard 2,3,7,8,9	180071	Terminal 2,8,10,11
110743	Lockwasher 10,11	180012	Codebar, No. 1 Rear 7,8	180072	Keylever, Line Break 6
112627	Nut, 2-56 Hex 3,11	180013	Codebar, No. 1 Front 7,8	180075	Terminal, Line Break 2,8,10,11
116783	Holder, Fuse 10	180014	Codebar, No. 2 Rear 7	180076	Lever, No. 5 Pulse 7,8
117608	Nut, Speed 4	180015	Codebar, No. 2 Front 7	180077	Link 7,8,9
118510	Fuse, 1/4 Amp 10	180016	Codebar, No. 3 Rear 7,8	180078	Spring, Compression 6,7,8
119648	Ring, Retaining 3,10,14	180017	Codebar, No. 3 Front 7	180081	Bracket, Right Keyboard 2,10,14
119649	Ring, Retaining 10	180018	Codebar, No. 4 Rear 7,8	180082	Bracket, Left Keyboard 2
119651	Ring, Retaining 14	180019	Codebar, No. 4 Front 7,8	180083	Spring 7
119652	Ring, Retaining 4	180020	Codebar, No. 5 Rear 7,8	180084	Cover, Keyboard 4
119653	Ring, Retaining 7,8,9,10	180021	Codebar, No. 5 Front 7,8	180090	Terminal, Common 2
121245	Clamp, 5/16 ID Cable 10			180093	Terminal 2,8,10,11
124877	Screw, 2-56 x 1/2 Rd 11			180094	Insulator 2,9
125011	Washer, Flat 3,11			180096	Link 7,8,9
125015	Washer, Flat 12				
125179	Screw, 6-32 x 3/16 Rd 14				
125181	Screw, 2-56 x 3/8 Fil 10				
126815	Screw, 2-56 x 15/64 Hex 3				
130664	Lockwasher 3				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
180099	Fastener 2,8,9,10,11	180206	Keytop 5	181964	Insulator 8,11
180100	Guide 7,8,9	180207	Keytop 5	181965	Block, Contact 8
180101	Wire, Contact 2,10	180208	Keytop 5	181966	Terminal 8
180106	Keylever 6	180257	Keytop 5	181967	Terminal 8
180107	Detent 2	180259	Keytop 5	181968	Insulator 8
180114	Bracket, Left Keyboard 2	180260	Keytop 5	181969	Cable Assembly 13
180115	Modification Kit 2	180261	Keytop 5	181970	Link w/Extension 8
180116	Keylever 6	180262	Keytop 5	181971	Keytop 5
180160	Keytop 5	180264	Keytop 5	181973	Jumper, 3-1/2" Red 13
180161	Keytop 5	180273	Keytop 5	181974	Jumper, 3" Red 13
180162	Keytop 5	180274	Keytop 5	181975	Keylever 6
180163	Keytop 5	180278	Keytop 5	181976	Keylever 6
180164	Keytop 5	180280	Keytop 5	181978	Cable Assembly 13
180165	Keytop 5	180281	Keytop 5	181979	Bracket, Left Keyboard 2,8
180166	Keytop 5	180282	Keytop 5	182239	Latchlever 3,7,8,9
180167	Keytop 5	180299	Keytop 5	182540	Connector, 15 Pt Plug Type 7,9,13
180168	Keytop 5	180335	Keytop 5	182643	Terminal, Plug Type 3,7,9,13,14
180169	Keytop 5	180336	Keytop 5	182644	Terminal, Receptacle Type 3,7,9,13,14
180170	Keytop 5	180373	Keytop 5	182674	Jumper, 2-1/4" Green 10,13
180171	Keytop 5	180374	Keytop 5	182675	Jumper, 2-1/4" Purple 10,13
180172	Keytop 5	180382	Keytop 5	182676	Jumper, 2-1/4" Red 10
180173	Keytop 5	180383	Keytop 5	182693	Jumper, 2-1/4" Orange 13
180174	Keytop 5	180384	Keytop 5	182726	Terminal, Receptacle Type 7,9,13
180175	Keytop 5	180385	Keytop 5	183236	Keylever, Repeat 6
180176	Keytop 5	180418	Keytop 5	183237	Cover, Keyboard 4
180177	Keytop 5	180419	Keytop 5	183238	Keylever 6
180178	Keytop 5	180440	Keytop 5	183600	Codebar 8
180179	Keytop 5	180441	Keytop 5	183601	Codebar 8
180180	Keytop 5	180442	Keytop 5	183604	Codebar 8
180181	Keytop 5	180443	Keytop 5	183605	Codebar 8
180182	Keytop 5	180444	Keytop 5	183608	Codebar 8
180183	Keytop 5	180444	Keytop 5	183609	Codebar 8
180184	Keytop 5	180586	Sleeve, 5-32 ID x 21/32" Lg Insulating 10,13	183610	Codebar 8
180185	Keytop 5	180870	Cable Assembly 13	183611	Codebar 8
180186	Keytop 5	180902	Jumper, 3-1/2" Braided 10	183612	Codebar 8
180187	Keytop 5	180908	Cable Assembly 13	183613	Codebar 8
180188	Keytop 5	180977	Plate w/Stud 2,10	183614	Codebar 9
180189	Keytop 5	181240	Screw w/Lockwasher, 6-40 x 3/16 Hex 10	183615	Codebar 9
180190	Keytop 5	181241	Screw w/Lockwasher, 6-40 x 1/4 Hex 8,10,11,12	183616	Codebar 9
180191	Keytop 5	181242	Screw w/Lockwasher, 6-40 x 5/16 Hex 10 12	183617	Codebar 9
180192	Keytop 5	181253	Keytop 5	183618	Codebar 9
180193	Keytop 5	181254	Keylever 6	183619	Codebar 9
180194	Keytop 5	181255	Keylever 6	183620	Codebar 9
180195	Keytop 5	181310	Lever 7,8	183621	Codebar 9
180196	Keytop 5	181892	Sleeve, 9/64 ID x 1" Lg Insulating 13	183622	Codebar 9
180197	Keytop 5	181960	Spacer, .144" Thk 8	183623	Codebar 9
180198	Keytop 5	181961	Terminal 8	183624	Codebar 9
180199	Keytop 5	181962	Terminal 8,11	183625	Codebar 9
180200	Keytop 5	181963	Terminal, Parity 8,11		
180201	Keytop 5				
180202	Keytop 5				
180203	Keytop 5				
180205	Keytop 5				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
183626	Codebar 9	184135	Block Assembly, Left	185619	Frame, Left Keyboard 2
183627	Codebar 9		Contact 8,13	185780	Spring, Compression 6
183628	Codebar 9	184165	Lever, Reset 11	185798	Spring 7,8,9
183629	Codebar 9	184174	Switch, SP-DT 11	185801	Modification Kit 1,14
183631	Codebar 9	184177	Solenoid, Rotary 11	185802	Solenoid 3,14
183632	Codebar 9	184179	Bracket 11	185803	Clip 14
183633	Codebar 9	184181	Actuator 11	185804	Bracket 14
183634	Codebar 9	184182	Plate 11	185805	Lever 14
183635	Codebar 9	184186	Switch, Reed 11	185806	Shaft 15
183636	Codebar 9	184192	Plate w/Hub 11	185845	Cable Assembly 13
183637	Codebar 9	184196	Terminal 11	185871	Screw w/Lockwasher, 8-32 x 3/8 Hex 2
183638	Codebar 9	184197	Plate w/Stud 11	186049	Lever 8
183639	Codebar 9	184198	Cable Assembly 13	186051	Link 8
183640	Codebar 9	184199	Cable Assembly 13	186071	Cover 4
183641	Codebar 9	184212	Guide 11	186154	Terminal 9
183642	Codebar 9	184214	Bracket, Right 11	186155	Terminal 9
183643	Codebar 9	184334	Keytop 5	186156	Cable Assembly 13
183644	Codebar 9	184335	Keytop 5	186253	Lever w/Hub 2,14
183645	Codebar 9	184336	Keytop 5	186314	Spring 2,8,,9,10,11
183646	Codebar 9	184337	Keytop 5	186339	Spring 8
183647	Codebar 7	184338	Keytop 5	186343	Codebar 7,8,9
183648	Codebar 7	184339	Keytop 5	186346	Shield, Magnetic 11
183649	Codebar 7	184340	Keytop 5	186349	Bracket 11
183876	Setscrew, 6-32 11	184341	Keytop 5	186406	Lever, Reset 11
183888	Keytop 5	184342	Keytop 5	186408	Modification Kit 11
183889	Keytop 5	184343	Keytop 5	186417	Wire, Contact 8
183890	Keytop 5	184344	Keytop 5	186419	Lever 8
183891	Keytop 5	184345	Keytop 5	186435	Spring 2
183892	Keytop 5	184346	Keytop 5	186436	Spring 10
183951	Wire, Contact 8,2	184351	Keytop 5	186437	Spring 7,8,9
184021	Cover, Keyboard 4	184734	Keytop 5	186558	Shaft w/Link 10
184022	Keylever 6	184815	Keytop 5	186561	Link w/Hub 10
184023	Keylever 6	184816	Keytop 5	186564	Lever 10
184024	Keylever 6	184817	Keytop 5	186565	Lever, Reset 10
184025	Keytop 5	184818	Keytop 5	186566	Screw, 4-40 Adjusting 10
184026	Keytop 5	184869	Keytop 5	196568	Pin 10
184027	Keytop 5	184895	Keytop 5	186569	Bracket 10
184031	Terminal 9	185089	Keytop 5	186579	Solenoid 10
184032	Insulator .031" Thk 9	185090	Keytop 5	186700	Shaft 3
184033	Spacer, 0.35" Thk 9	185092	Keytop 5	186701	Plate 3
184034	Cable Assembly 13	185093	Keytop 5	186702	Screw, 6-32 Spl 3
184051	Cable Assembly 13	185150	Keytop 5	186703	Plate, Top Mounting 3
184106	Block Assembly, Right	185159	Keytop 5	186704	Stud 3
	Contact 9	185160	Keytop 5	186705	Shaft 3
184107	Block Asstembly, Right	185161	Keytop 5	186706	Cam, Trip 3
	Contact 2,10	185162	Keytop 5	186707	Lever 3
184108	Block Assembly, Right	185163	Keytop 5	186709	Bushing, Eccentric 3
	Contact 10	185164	Keytop 5	186746	Lever 6
184109	Block Assembly, Right	185165	Keytop 5	186752	Modification Kit 1,3,14
	Contact 8,11,13	185394	Keytop 5	186754	Bushing 3
184111	Block Assembly, Right	185395	Keytop 5	186773	Lever, Reset 10
	Contact 9	185396	Keytop 5		

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
186830	Bracket 3	195317	Pin 10	195614	Pin, Key 13
186832	Bushing, Eccentric 3	195321	Bracket, Switch 10	195965	Tray, Copyholder 12
186833	Shaft 3	195322	Switch 10	198670	Screw w/Lockwasher, 6-40 x 5/16 Hex 12
186834	Lever 3	105332	Bracket, Power Switch 12	303037	Spring, Compression 3
186874	Cam, Trip 3	195333	Switch, Pushbutton 12	305537	Plug, Button 4
187008	Wire, Contact 8	195465	Plate, Mounting 10	305706	Shaft w/Link 10
187009	Cable Assembly 13	195470	Insulator, .031" Thk 10	305707	Arm, Reset 10
187270	Cover, Contact 2,7	195471	Wire, Contact 10	305708	Bracket, Solenoid 10
187271	Cover, Contact 2,7	195473	Terminal, Common 10	311516	Post 12
192191	Knob 12	195474**	Panel, Top 12	312918	Strap 2,10
192538	Plug, Button 4	195475	Cover, Keyboard 4,12	320410	Terminal, Spade Type 7,13
195307	Keylever, Repeat 6	195481**	Cover 12	320418	Terminal, Ring Type 13
195309	Lever, Non-Repeat 7	195482	Cable Assembly 12	321895	Post 3,14
195312	Lever, Reset 10	195483	Plate 10,12	333588	Lamp, 28 V Miniature 12
195315	Solenoid w/Plunger 10	195563	Lens, Red Pushbutton 12		
		195568	Lamp, 6 V 12		

**Refer to Page 1 for finish suffix