

14 12013

35 WALL MOUNTED CABINET (LPC)

KSR/RO

PARTS

FIGURE	CONTENTS	PAGE
1	Cover	2
2	Copyholder and Hood	3
3	176950 Back Plate Assembly	4
	Numerical Index	5


BELL SYSTEM and TELETYPE CODE CROSS-REFERENCE		
Unit Description	Teletype Code	Bell System Code
Cabinet	LPC300HF	35E

NOTE:

When ordering parts from this section, prefix each number with the letters TP.

PAINT FINISH COLOR CODE CHART														
(for parts and assemblies requiring a paint finish)														
Color	Finish Suffixes				Color	Finish Suffixes								
	Wrinkle Finish	Smooth Finish	Textured Vinyl	Smooth Vinyl		Wrinkle Finish	Smooth Finish	Textured Vinyl	Smooth Vinyl					
Beige	AA (37)	ET		HC	Gray, Federal	AB (40)	BV	GG	HB (68)					
Beige, Light		EL			Gray, Green		BK	GA (45)		HE				
Beige, Rose		ER			Gray, Light		EJ	HF (46)						
Black		BA (34)			Gray, Covert		EW				GE			
Black, High Gloss					BB							Gray, Olive		
Black, Semi Gloss		EK			Deck		AJ					BJ	HD	
Blue, Aqua		EC			Gray, Oxford							EP		
Blue, Brussels Light		ES			Green, Gray		AB (40)					BK		GA (45)
Blue, Medium		AD (38)			Green, Moss							EN		
Brown, Dark					AC (39)		Ivory					EM		
Brown, Light	AL	BZ	GC	EU										
Fawn			GF	Pink, Rose	EV									
Gray, Beige			GB	Turquoise	EH									
Gray, Charcoal			HA	White	EG									
Gray, Dark				Yellow, Pastel										

The double asterisk (**) denotes a painted part. Suffix to be applied following the part number. Number in parenthesis indicates Bell System code



**Refer to Page 1 for Finish Suffix

FIGURE 2. COPYHOLDER AND HOOD

NUMERICAL INDEX

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
1205	Screw (3-48 x 19/64 Flat) 2	151692	Screw (6-40 x 3/16 Fil) 2, 3	176977	Frame 4
2191	Washer, Lock 2, 3, 4	151722	Screw (6-40 x 3/16 Hex) 2, 4	176978	Nut (3/8 - 21 Hex) 4
2449	Washer, Lock 4	151723	Screw (10-32 x 3/8 Hex) 4	176979	Mount, Vibration 4
2658	Nut (6-32 Hex) 2, 3	152890	Washer, Flat 3	176981	Pad, Dome 2
2669	Washer, Lock 4	153020	Guide, Line 3	176982	Pad, Dome 2
3438	Washer, Flat 4	153021	Spring, Torsion 3	176983	Pad, Hood 3
3598	Nut (6-40 Hex) 3	153022	Bushing 3	176984	Pad, Hood 3
3599	Nut (4-40 Hex) 2	153023	Handle 3	176986**	Tray, Copyholder 3
3640	Washer, Lock 3	154433	Clamp 2	176987**	Plate, Bottom 2
7002	Washer, Flat 2, 3, 4	155083	Lens, Red Indicator Light 2	176988**	Door 2
61085	Washer, Lock 2	156740	Screw (6-40 x 7/32 Hex) 4	176990**	Cover, Wall Mount 2
70073	Nut (3-48 Hex) 2	158649	Screw, Thumb (4-40) 2	176991	Pad, Dome 2
70891	Washer, Lock 4	161708	Latch, Magnetic 4	176992	Pad, Dome 2
72565	Washer, Lock 4	162591	Shaft 3	176993	Pad, Door 2
74479	Bushing 3	162730	Screw (1/4-20 x 7/16 Hex) 4	176994	Pad, Door 2
74805	Screw (10-32 x 3/4 Hex) 4	176922	Plate, Back 4	176995	Pad, Front 2
76081	Washer, Flat 4	176950	Plate Assembly, Back 4	176996	Pad, Front 2
92138	Washer, Flat 4	176951	Bar, Vertical Mounting 4	176997	Retainer 2
92146	Nut (1/4-20 Hex) 4	176953	Bar 4	176998	Window, Glass 2
107116	Washer, Lock 4	176954	Eccentric 4	176999	Gasket, Window 2
111345	Bolt 2	176956	Chute, Paper 4	178501	Pad, Side 2
111346	Spring, Compression 2	176959	Isolator 4	178502	Pad, Side 2
116201	Screw (1/4-20 x 1-1/2 Fil) 4	176960	Bar, Cover Mounting 4	178545**	Door 2
117535	Washer, Flat 4	176963	Plate, Left Side 4	178546**	Dome, Front 2
125014	Washer, Flat 4	176964	Plate, Right Side 4	180904	Tab, Terminal 4
151442	Screw (6-40 x 1/2 Hex) 3	176965	Screw (1/2 - 13 x 1 Hex) 4	183261	Screw, Self-Tapping (#8) 3
151558	Nut, Speed 2	176966	Screw (3/8-24 x 3/4 Hex) 4	195600	Window 2
151572	Washer, Lock 4	176967	Deflector, Paper 4	195782**	Hood w/Studs 3
151610	Washer, Flat 2	176968	Bracket 4	199497	Block, Left 4
151630	Screw (6-40 x 1/4 Hex) 3, 4	176969	Screw, Fastener 2	199498	Block, Right 4
151631	Screw (6-40 x 5/16 Hex) 4			305059	Guide, Form (9-1/2") 2
151686	Screw (4-40 x 3/8 Fil) 3			310345	Latch, Flush 2