

35 RECEIVING ONLY REPERFORATOR TABLE


ACTUAL WIRING DIAGRAM

CONTENTS	PAGE	
1. GENERAL	1	2. ACTUAL WIRING DIAGRAM
2. ACTUAL WIRING DIAGRAM	1	2.01 Wiring diagram 5866WD covers the LT 300 (Bell 35A) 35 receive only reperforator table.
1. GENERAL		2.02 The actual wiring diagram presents a physical picture of each electrical component. The individual leads to each component are marked with their distant terminating points and wire color codes. The TF wiring field is part of the electrical service unit which is covered in another section.
1.01 This section is reissued to provide the most current wiring diagram for the electrical components installed on the 35 receive only reperforator table.		2.03 Notes are included on the diagram to explain the symbols used or to point out certain special conditions that should be observed.

5866 WD

ISSUE	DATE	AUTH. NO.
2	4-28-65	83155-1
3	6-2-65	87258

NO.	NOTES
1	<p>WIRING LEGEND</p> <p>— DISTANT TERMINATING AREA</p> <p>— DISTANT TERMINAL DESIGNATION</p> <p>A-1-W-BL</p> <p>— WIRE COLOR CODE</p>
2	<p>COLOR CODE</p> <p>BK-BLACK</p> <p>W-BK WHITE BLACK</p>



APPROVALS	
D AND R	E OF M
<i>[Signature]</i>	<i>[Signature]</i>
E. NUMBER	
PROD. NO. 5866 WD	

ACTUAL WIRING DIAGRAM FOR LT-300

DATE: 5-31-62
P.D. FILE NO.
DRAWN. GLZ. CHKD. <i>[Signature]</i>
ENG. J.A.C. APPD. <i>[Signature]</i>

TELETYPE CORPORATION
5866 WD