

37 TYPING UNIT (YP)

PARTS

FIGURE	CONTENTS	PAGE	FIGURE	CONTENTS	PAGE
1	Right Side Frame	2	26	Pressure Roller Mechanism	27
2	Left Side Frame	3	27	Line Feed and Platen Mechanism	28
3	Front Plate Mechanism	4	28	Paper Spindle and Reset Bail Mechanism	29
4	Front Plate Mechanism (Continued)	5	29	Stunt Box Components	30
5	Print Hammer Carriage Mechanism	6	30	Shift Fork Mechanism	31
6	Print Hammer Mechanism	7	31	Function Bars	31
7	Aggregate Motion Linkage	8	32	Function Levers, Latches and Pawl	32
8	Aggregate Motion Linkage (Continued)	9	33	Left Ribbon Feed Mechanism	33
9	Aggregate Motion Linkage (Continued)	10	34	Right Ribbon Feed Mechanism	34
10	Aggregate Motion Linkage (Continued)	11	35	Sprocket Feed Platen Mechanism	35
11	Vertical Positioning and Retraction Mechanisms	12	36	Vertical Tabulation with Form Feed-Out	36
12	Vertical Positioning and Retraction Mechanisms (Continued)	13	37	326010 Modification Kit (10 spaces per inch) to Add Horizontal Tabulator and	
13	Codebar Mechanism	14		326401 Modification Kit (12 spaces per inch) to Add Horizontal Tabulator	37
14	Typebox Carriage Mechanism	15	38	326013 Modification Kit to Provide Paper-Out Alarm (Sprocket Feed)	38
15	319775 and 319885 Typebox Arrangements	16	39	306402 Modification Kit to Provide Horizontal Tabulator Transmitter Control for Printer	38
16	Main Shaft	17	40	306316 Modification Kit to Provide On Line Backspace	39
17	Main Shaft Clutches	18	41	306406 Modification Kit to Add Vertical Tabulator Transmitter Control	39
18	Main Shaft Clutches (Continued)	19	42	319650 Modification Kit to Provide Low Paper Alarm	40
19	Trip Shaft Mechanism	20	43	328300 Modification Kit to Provide Character Received (Open Contact)	40
20	Clutch Trip Bracket Mechanism	21	44	330700 Modification Kit to Provide a Pointer and Mounting Facilities for a Print Position Scale for the Printer	41
21	Carriage Return and Spacing Drum Mechanism	22		Numerical Index	42
22	Selector Mechanism	23			
23	Selector Magnet Mechanism	24			
24	Codebar Selector Mechanism	25			
25	Space Suppression Mechanism	26			

TELETYPE CODE	BELL CODE	RIBBON
306408	91215	BLACK
306489	92415	RED-BLACK

NOTE: When ordering parts from this section, prefix each number with the letters TP.




FIGURE 1. RIGHT SIDE FRAME




FIGURE 2. LEFT SIDE FRAME




FIGURE 4. FRONT PLATE MECHANISM (Continued)




FIGURE 5. PRINT HAMMER CARRIAGE MECHANISM




FIGURE 6. PRINT HAMMER MECHANISM.




FIGURE 9. AGGREGATE MOTION LINKAGE (Continued)




FIGURE 11. VERTICAL POSITIONING AND RETRACTION MECHANISMS




FIGURE 12. VERTICAL POSITIONING AND RETRACTION MECHANISM (Continued)




FIGURE 13. CODEBAR MECHANISM





FIGURE 14. TYPEBOX CARRIAGE MECHANISM



319775 "AYE" TYPE PALLET CHART							
Number	Pallet	Number	Pallet	Number	Pallet	Number	Pallet
319701	A	319725	Y	319745	s	319762	9
319702	B	319726	Z	319746	t	319594	:
319703	C	319609	{	319747	u	319595	
319704	D	319630	/	319748	v	157791	<
319705	E	319610	}	319749	w	319636	=
319706	F	319638	:	319750	x	157790	>
319707	G	319727	a	319751	y	319596	?
319708	H	319728	b	319752	z	319597	!
319709	I	319729	c	319632	[319599	"
319710	J	319730	d	319607	~	319602	#
319711	K	319731	e	319633]	319604	\$
319712	L	319732	f	319637	^	319603	%
319713	M	319733	g	319621	-	319606	&
319714	N	319734	h	157726	@	319598	'
319715	O	319735	i	319623	\	319600	(
319716	P	319736	j	319573	0	319601)
319717	Q	319737	k	319738	1	319605	*
319718	R	319738	l	319755	2	319635	+
319719	S	319739	m	319756	3	319593	,
319720	T	319740	n	319757	4	319634	-
319721	U	319741	o	319758	5	319592	.
319722	V	319742	p	319759	6	319631	\
319723	W	319743	q	319760	7		
319724	X	319744	r	319761	8		

319885 "AYD" TYPE PALLET CHART							
Number	Pallet	Number	Pallet	Number	Pallet	Number	Pallet
319530	A	319554	Y	319574	s	319591	9
319531	B	319555	Z	319575	t	319594	:
319532	C	319609	{	319576	u	319595	;
319533	D	319630	/	319577	v	194884	<
319534	E	319610	}	319578	w	319636	=
319535	F	319638	:	319579	x	194885	>
319536	G	319556	a	319629	y	319596	?
319537	H	319557	b	319581	z	157647	!
319538	I	319558	c	319632	[319599	"
319539	J	319559	d	319607	~	157659	#
319540	K	319560	e	319633]	319604	\$
319541	L	319561	f	319637	^	194017	%
319542	M	319625	g	319621	-	319606	&
319543	N	319563	h	155480	@	319598	'
157614	O	319564	i	319623	\	319600	(
319545	P	319626	j	155446	0	319601)
319546	Q	319566	k	319583	1	319605	*
319547	R	319567	l	319584	2	319635	+
319548	S	319568	m	319585	3	319593	,
319549	T	319569	n	319586	4	319634	-
319550	U	319570	o	319587	5	319592	.
319551	V	319627	p	319588	6	319631	\
319552	W	319628	q	319589	7		
319553	X	319573	r	319590	8		

FIGURE 15. 319775 AND 319885 TYPEBOX ARRANGEMENTS




FIGURE 16. MAIN SHAFT




FIGURE 19. TRIP SHAFT MECHANISM




FIGURE 20. CLUTCH TRIP BRACKET MECHANISM




FIGURE 23. SELECTOR MAGNET MECHANISM




FIGURE 24. CODEBAR SELECTOR MECHANISM




FIGURE 26. PRESSURE ROLLER MECHANISM




FIGURE 27. LINE FEED AND PLATEN MECHANISM






FIGURE 28. PAPER SPINDLE AND RESET BAIL MECHANISM



SWITCH ASSEMBLY NUMBER	CONTACT PLATE NUMBER	CONTACT ARM POSITION			
		1	2	3	4
172566	172595		157899		
172575	172595	157899	157899		
172576	172595	157899	157899	157899	157899
172586	172595			157899	157899



① 327817 Cable Assembly

FIGURE 29. STUNT BOX COMPONENTS





FIGURE 30. SHIFT FORK MECHANISM



Function Bar	Function	Function Bar	Function
306201	CR	319790	DC -1
306202	LF	319791	DC-2
306204	EOT	319792	DC-3
306205	BELL	319793	DC-4
306206	BS	319796	ESC TERMINATE
306207	ACK	319798	H. DUPLEX
306208	NACK	319799	F. DUPLEX
306209	WRU	319800	RED
306214	ESC	319801	BLACK
306221	SUPPRESSION	319802	ESC HOLD

FIGURE 31. FUNCTION BARS




FIGURE 32. FUNCTION LEVERS, LATCHES AND PAWL




FIGURE 33. LEFT RIBBON FEED MECHANISM




FIGURE 34. RIGHT RIBBON FEED MECHANISM





FIGURE 35. SPROCKET FEED PLATEN MECHANISM



⓪ 154765 Modification Kit to equip vertical tabulator for 5-1/2 and 11 inch length forms.

FIGURE 36. VERTICAL TABULATION WITH FORM FEED-OUT






FIGURE 37. 326010 MODIFICATION KIT (10 SPACES PER INCH) TO ADD HORIZONTAL TABULATOR AND 326401 MODIFICATION KIT (12 SPACES PER INCH) TO ADD HORIZONTAL TABULATOR



① 326012 Switch Assembly

FIGURE 38. 326013 MODIFICATION KIT TO PROVIDE PAPER-OUT ALARM (SPROCKET FEED)



① 306356 Switch Assembly

FIGURE 39. 306402 MODIFICATION KIT TO PROVIDE HORIZONTAL TABULATOR TRANSMITTER CONTROL FOR PRINTER




FIGURE 40. 306316 MODIFICATION KIT TO PROVIDE ON LINE BACKSPACE




FIGURE 41. 306406 MODIFICATION KIT TO ADD VERTICAL TABULATOR TRANSMITTER CONTROL




FIGURE 42. 319650 MODIFICATION KIT TO PROVIDE LOW PAPER ALARM (FRICTION FEED)




FIGURE 43. 328300 MODIFICATION KIT TO PROVIDE CHARACTER RECEIVED (OPEN CONTACT)




FIGURE 44. 330700 MODIFICATION KIT TO PROVIDE A POINTER AND MOUNTING FACILITIES FOR A PRINT POSITION SCALE FOR THE PRINTER

NUMERICAL INDEX

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
271M	Coil, Magnet 24	34432	Washer, Flat 13,21,38	80848	Spring 28
1118	Screw, 6-40 Shoulder 3	35826	Washer, Flat 36	80945	Spring 37
1172	Screw, 2-56 x 5/16 Fil 40	36318	Washer, Flat 12	81731	Spring 2,3,4,7
1214	Setscrew, 10-21 5	36358	Spring 23	81778	Screw, 4-40 x 3/16 Fil 24
1268	Screw, 6-40 x 5/16 Flat 3	41382	Spring 36	82249	Washer, Flat 7,10,13,35
1293	Screw, 4-40 x 1/8 Fil 33	41385	Spring 3	82463	Spring 33,34
2034	Washer, Flat 10	41663	Washer, Flat 3	82713	Screw, 4-40 x 9/32 Hex 21
2191	Lockwasher 2 to 8,10 to 15,17 to 31,33 to 37,39, 40,41	42661	Spring 12,23	82861	Spring 2
2201	Nut, 5/16-32 Hex 28	42823	Washer, Flat 40	83497	Washer, Flat 3
2438	Washer, Flat 24	42827	Screw, 3-48 x 1/4 Fil 14,24	83877	Spring 30
2539	Nut, 3/8-32 Hex 20,29	45104	Spring 8,13	84592	Shim, 0.004" Thk 3
2605	Spring 23	45815	Lockwasher 3,4,5,9,12, 13,21,22,28	84758	Spring 39
2669	Washer, Flat 4,36	55063	Spring 35	86079	Washer, Felt 7
2760	Spring 12	55064	Washer, Flat 23	86304	Spring 26,39
3288	Washer, Flat 2	55088	Spring 20	86742	Nut, 4-40 Hex 15
3598	Nut, 6-40 Hex 2 to 6,10 to 13,17,18,20,21,23 to 26,28,29,36,37	55669	Spring 40	87636	Screw, 2-56 x 3/16 Rd 24
3599	Nut, 4-40 Hex 7,23,24, 27,31,33,34	70071	Lockwasher 40	89096	Washer, Felt 15
3606	Nut, 6-40 Hex 3,6,7,14, 30,39,40	70314	Washer, Flat 23	89897	Nut, 10-32 Hex 5
3624	Washer, Flat 12,38	70388	Spring 20	90054	Spring 12,21,36
3640	Lockwasher 2,3,7,8,10 to 19,21,22,23,25,27,28,29, 33,34,35,38	71073	Washer, Flat 30	90260	Spring 12
3646	Lockwasher 21,28	72468	Spring 27	90361	Washer, Felt 33
4703	Spring 31,37	72522	Wick, Felt 32	90391	Washer, Felt 34
4704	Spring 10	72579	Washer, Flat 28	90437	Wick, Felt 23
4708	Spring 27	73175	Lockwasher 20,29	90504	Washer, Felt 4,6,30
5599	Nut, 8-32 Hex 28	73520	Wick, Felt 5	90517	Spring 32
5740	Screw, 2-56 x 1/4 Fil 30	74283	Washer, Spring 23	90573	Spring 5
6800	Screw, 6-40 Shoulder 20	74536	Setscrew, 6-40 23	90679	Washer, Felt 26
6970	Nut, 3/8-32 Hex 7,41	74547	Collar 3,20	90749	Shim, 0.010" Thk 6
7001	Washer, Flat 20	74701	Spring 20	90791	Lockwasher 15,24,40
7002	Washer, Flat 2 to 6,8, 12,13,15,20 to 29,34,36, 37,39,40,41	74755	Washer, Felt 3,22	90819	Washer, Felt 4,20,21,29
7603	Spring 20	74760	Spring 13	91120	Spring 7
8330	Washer, Flat 2,3,6,20, 30,35	74785	Roller 20	92682	Nut, 4-40 Spl 25
8449	Spacer 0.094" Thk 20,33	74882	Spring 7	93117	Lockwasher 6,12,15,30, 38,40
22015	Spring 33	75607	Washer, Flat 4,21	93118	Lockwasher 38, 39
27425	Screw, 2-56 x 5/32 Fil 15	76081	Washer, Flat 24	93356	Washer, Felt 2,20,29,37
31636	Spring 14	76099	Washer, Flat 24	93582	Washer, Flat 21,29
		76296	Spring 2	93758	Washer, Felt 20
		76379	Spring 37	93969	Screw, 4-40 x 3/16 Flat 35
		76421	Spring 23	95030	Nut, 6-40 Shoulder 38
		76422	Spring 12	95971	Screw, 4-40 x 1/2 Flat 5
		76461	Washer, Flat 6	96717	Screw, 4-40 Shoulder 23
		76544	Spacer 22	97481	Wick, Felt 29
		76800	Spring 35	97981	Spacer 3
		76806	Spring 2	98642	Lockwasher 3
		76834	Screw, 4-40 x 3/8 Flat 38	98832	Screw, 4-40 x 11/16 Fil 17
		79012	Insulator 24		
		80758	Spring 12		

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
100759	Screw, 4-40 x 3/16 Flat 4	119654	Ring, Retaining 2	150078	Nut, 4-40 Shoulder Hex 16
100832	Screw, No.0 x 3/16 Drive 6	119935	Lockwasher 28	150089	Screw, 4-40 x 1/2 Fil 5, 24
101386	Spring 28	120824	Washer, Felt 17	150096	Roller Assembly, Pressure 27
101796	Washer, Felt 2,3	121100	Spring 23	150193	Hub 5
103863	Spacer, .055" Thk 31	121242	Clamp, 1/8 ID Cable 24,40	150194	Plate 5
104807	Washer, Flat 7,21	121243	Clamp, 3/16 ID Cable 3,24	150196	Bail 5,37
107116	Lockwasher 2	121244	Clamp, 1/4 ID Cable 24	150197	Stud 22
108199	Wick, Felt 20,28	124681	Setscrew, 6-40 27	150203	Retainer 5
110334	Screw, 4-40 Shoulder 39	124999	Switch, Sensitive 38	150224	Pulley 15
110434	Screw, 4-40 x 3/16 Fil 16,35	125005	Screw, 2-56 x 3/16 Rd 6	150228	Spacer, 0.035" Thk 5
110435	Nut, 4-40 Hex 5,7,21,38	125011	Washer, Flat 7,12,16,22, 23,27 to 30,31,33,34,35, 40	150229	Retainer 5
110743	Lockwasher 5,18,19,23, 24,27,28,30,31,35,37,40	125015	Washer, Flat 4,6,20,21, 24,35,36,37	150233	Roller 5
110872	Spring, Compression 5	125236	Spring 21	150234	Roller 5
110879	Spring 37	125238	Spring 5	150235	Slide, Transfer 5
111342	Spring 37	125241	Spring 24	150237	Lever, Escapement 6
111640	Screw, 2-56 x 7/32 Fil 12	125733	Washer, Flat 20	150241	Spring 9,13,18,19
111767	Washer, Flat 20	125802	Washer, Flat 8,11,12	150265	Shaft 27
112626	Nut, 10-32 Hex 3,4,5,9, 12,13,21,22,36	126815	Screw, 2-56 x 15/64 Hex 30	150266	Lever, Guide 27
112627	Nut, 2-56 Hex 40	128357	Ring, Retaining 35	150267	Clamp 27
112629	Spring 37	129098	Screw, 6-40 x 11/32 Flat 14	150269	Roller, Pressure 27
112630	Spring 2,3	130667	Lockwasher 23	150270	Link 27
112634	Spring 26,33,34	130696	Washer, Felt 7	150271	Arm, Release 27
112787	Screw, 2-56 x 5/8 Fil 38	131017	Washer, Felt 21	150274	Bracket, Clamp 27
113077	Post, Spring 14	135716	Spring 20	150289	Stud 14
113441BK	Jumper, 1-1/4" Black 30	138033	Insulator, 0.031" Thk 40	150293	Plate, Retaining 14
114107	Spring 33,34	138034	Plate, Clamp 39,40	150301	Plate, Retaining 14
115122	Washer, Felt 8,28	142274BK	Jumper, 2-1/2" Black 30	150302	Shim, 0.006" Thk 14
115529	Screw, 6-40 x 11/16 Fil 36	145321	Tie, Cable 21	150304	Bracket, Guide 14
117529	Spacer, 0.281" Thk 22	150000	Drum, Clutch 18, 19	150310	Lever, Ribbon 33
119467	Insulator, 0.032" Thk 38	150001	Drum, Clutch 18	150311	Lever, Ribbon 34
119648	Ring, Retaining 8,10,11, 15,23,36	150029	Wick, Felt 9,13,18,19	150335	Gear, 12T 33
119649	Ring, Retaining 2,5,6, 28,32,33,34,36 to 39	150034	Disc, 2 Stop Clutch 18, 19	150336	Bushing 33,34
119650	Ring, Retaining 7,11,13	150040	Screw, 6-40 x 5/8 Fil 2, 3,11,18,20,35	150343	Lever 33
119651	Ring, Retaining 2,3,8, 12,13,15,25,26,27,33,34, 37,40	150043	Shoe, Secondary Clutch 9,13,18,19	150344	Lever 34
119652	Ring, Retaining 2,3,5,6, 7,12,13,20,21,23,25,26, 29,33,34,37	150044	Shoe, Primary Clutch 9, 13,18,19	150348	Shaft 20
119653	Ring, Retaining 4,5,6,9, 20,23,30,33,34,37	150045	Bearing, Clutch Sleeve 18,19	150352	Bushing 20
				150355	Latchlever 20
				150356	Lever, Trip 20
				150361	Spacer, 0.277" Thk 20
				150377	Arm 26
				150398	Stud, Pivot 29
				150401	Clamp 3
				150414	Bushing 29
				150419	Shaft 29
				150423	Stud, Pivot 29
				150431	Lever, Trip 20

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
150436	Bushing 4,27,33,35	150961	Bushing, Eccentric 3	151692	Screw, 6-40 x 3/16 Fil 26,30
150471	Stud 25	150970	Bearing, Ball 17	151703	Pin 27
150479	Stud 23	150975	Cup, Dashpot 5	151714	Spring 23
150482	Plate 25	150978	Screw, 6-40 x 1-1/8 Fil 24	151721	Screw, 6-40 x 3/4 Hex 17,29
150537	Ball, Bearing 5,14	150987	Spacer, 0.090" Thk 5	151722	Screw, 6-40 x 3/16 Hex 2,3,4,23,37
150538	Cylinder, Dashpot 5	150990	Washer, Felt 2,26	151724	Screw, 10-32 x 5/8 Hex 3
150543	Screw, 3-48 x 13/32 Fil 30	151073	Screw, 4-40 x 5/32 Fil 13,28,30	151728	Spring 23
150544	Handle 30	151152	Screw, 4-40 x 3/16 Hex 2,3,7,8,11,12,14,18,23, 25,33,34,40	151732	Screw, 4-40 x 11/32 Fil 19,22,23
150545	Bracket, Right 2	151233	Spacer, 0.065" Thk 12	151733	Screw, 4-40 x 9/16 Fil 18,19
150642	Bellcrank 28	151338	Spacer, 0.075" Thk 4	151736	Spring 18,19
150646	Screw, 6-40 Shoulder 28, 39	151346	Screw, 6-40 x 3/8 Fil 3, 11,13,17,22,28,29,35	151737	Screw, 4-40 x 11/64 Hex 15,18,19,28
150647	Eccentric 28	151354	Screw, 2-56 x 15/32 Fil 40	151739YA	Screw, Identification 30
150648	Eccentric 28	151442	Screw, 6-40 x 1/2 Hex 33	151794	Washer, Spring 18,19
150649	Washer, Spacing 28	151548	Spring, Compression 23	151880	Nut, 4-40 Hex 3,4,5,10, 13,15,20,25,37,39
150654	Guide 3	151603	Spacer 24	152089	Latch 32
150668	Collar, Spacing 5	151610	Washer, Flat 19,38	152129	Spring 12, 37
150673	Shaft 4	151618	Screw, 6-40 x 7/16 Fil 14	152140	Bail 26
150685	Plate 27	151619	Bushing 22	152147	Bearing, Ball 15
150689	Block, Guide 30	151629	Nut, 6-40 Lug 2,3,6,20, 30,35	152412	Link 23
150705	Bushing 15	151630	Screw, 6-40 x 1/4 Hex 2 to 6,8,14,15,17,20,21, 23,27,29,33,34,35,37,40	152415	Stud, Adjusting 24
150712	Rope, Draw Wire 22	151631	Screw, 6-40 x 5/16 Hex 3,6,11,21 to 25,37,39, 40	152420	Lamination, Magnet 24
150719	Retainer 28	151632	Screw, 6-40 x 3/8 Hex 3, 19,36	152421	Bracket, Shield Mounting 24
150720	Retainer 28	151637	Screw, 4-40 x 1/4 Fil 28,29,30	152423	Bracket, Armature Stop Mounting 24
150781	Stud 26	151657	Screw, 6-40 x 1/4 Fil 23,26,30,33,35	152425	Post, Spring 24
150796	Disc 22	151658	Screw, 6-40 x 5/16 Fil 4,23	152426	Nut, 6-40 Self-Locking 24
150798	Ratchet 22	151685	Screw, 4-40 x 5/16 Fil 2,7,20,21,28,29,37	152427	Latch w/Hub 40
150803	Spring, Flat 27	151686	Screw, 4-40 x 3/8 Fil 5, 24	152441	Washer, Flat 23
150804	Finger, Paper 27	151688	Screw, 4-40 x 5/8 Fil 24	152458	Shield, Terminal 24
150815	Bushing 27	151689	Screw, 4-40 x 3/4 Fil 27,30	152523	Spring, Washer 33,34
150821	Spacer, 0.156" Thk 34	151690	Screw, 10-32 x 5/16 Fil 17	152524	Bracket 33,34
150826	Guide, Paper Finger 27			152525	Hub 33,34
150830	Bushing, Shoulder 18,19			152526	Plate, Right 34
150831	Ring, Retaining 18,19			152527	Plate, Left 33
150841	Bearing 18,19			152528	Ratchet, Left Ribbon 33
150843	Plate, Hook 22			152529	Ratchet, Right Ribbon 34
150891	Block 2			152537	Clamp 17
150895	Arm, Trip 20			152547	Shaft 30
150903	Block, Left Paper Spindle 29			152571	Spacer, 0.250" Thk 33
150904	Block, Right Paper Spindle 29			152573	Retainer 17
150907	Spindle, Paper 29				
150909	Screw, 6-40 Shoulder 6				
150923	Washer, Felt 7,20				
150926	Washer, Felt 15				
150931	Spacer, 0.040" Thk 18				
150932	Bushing, Shoulder 33,34				
150937	Lever 33				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
152574	Plate 14	153367	Arm 37	154389	Cam, Eccentric 5
152582	Shaft 33	153368	Bail, Follower 37	154516	Ratchet 22
152583	Bearing, Sleeve 25	153375	Arm, Slide 37	154623	Ring, Retaining 22
152589	Clamp 3	153538	Screw, 6-40 x 7/16 Hex 11,17,34,36	154627	Drum, Spacing 22
152593	Housing, Bearing 2	153539	Screw, 6-40 x 11/16 Hex 2,3,6	154668	Shaft 32
152629	Washer, Friction 33,34	153553	Roller 29	154670	Screw, 6-40 Spl 22
152641	Lever, Function 32	153573	Bail 29	154688	Spring 29
152642	Lever, Function 32	153577	Washer, Felt 21,29	154698	Wick, Felt 37
152648	Stud 34	153582	Screw, 6-40 Shoulder 26	154765	Modification Kit 36
152651	Guideplate 30	153586	Guide 3	154872	Bracket 2
152653	Pawl, Function 32	153587	Guide 2	155046	Screw, 4-40 x 15/32 Hex 19
152660	Plate, Spring 32	153604	Pawl, Function 32	155099	Screw, 6-40 Shoulder 30
152723	Spring 27	153609	Roller 31	155446	Pallet, Type 16
152725	Spring 27	153634	Collar 27	155480	Pallet, Type 16
152818	Lever, Left Detent 33	153644	Stud 31	155566	Arm, Left 35
152819	Lever, Right Detent 34	153676	Lever, Function 32	155589	Plate w/Stud 25
152826	Pin, Detent 33,34	153678	Bail, Detent 3	155736	Lever, Function 32
152832	Shaft 27	153682	Bracket w/Shaft 35	155737	Lever, Function 32
152834	Spring, Torsion 33,34	153688	Bracket, Right 35	155751	Sleeve, 1/8 ID x 1" Lg Insulating 38
152871	Spring 28	153683	Bracket, Left 35	155752	Sleeve, 5/64 ID x 1/2 Lg Insulating 30,38,39
152887	Screw, 4-40 x 1/2 Hex 18	153685	Arm w/Hub 35	155753	Sleeve, 1/8 ID x 1/2 Lg Insulating 38
152889	Plate, Retaining 30	153689	Gear, 33T 28,35	155754	Sleeve, 1/16 ID x 1/2 Lg Insulating 30
152893	Screw, 4-40 x 1/4 Hex 12,23,37,38,40	153692	Gear, 33T 28,35	155865	Stud 29
152927	Bushing 36	153697	Bracket 35	155896	Finger, Left Paper 35
152938	Spacer, 0.125" Thk 36	153698	Cam, Feed 35	155897	Finger, Right Paper 35
152943	Screw, 10-32 Spl 36	153699	Cam, Feed 35	155933	Guideplate 31
153185	Gear, 30T 36	153794	Plate, Adjusting 35	155934	Plate 31
153188	Screw, 6-40 Shoulder 36	153799	Screw, 4-40 x 21/64 Hex 28,35	155935	Fork w/Post 31
153189	Spring, Compression 36	153817	Screw, 4-40 x 3/8 Hex 5, 15,17,27,35	155938	Slide 31
153192	Spring, Torsion 36	153819	Lockwasher 14,24	155954	Switch, Sensitive 40
153196	Handwheel 36	153823	Collar 17	156057	Washer, Flat 18,19,33, 34,38
153203	Gear, 66T 36	153824	Clamp 17	156450	Screw, 2-56 x 1/2 Fil 39
153235	Plate 19	153839	Screw, 6-40 x 4/8 Hex 6, 20,30,35,41	156467	Ring, Retaining 2,30
153256	Bracket 5	153841	Screw, 6-40 x 9/16 Hex 2,10,24,29,33	156501	Screw, 6-40 x 7/32 Fil 8,11,13,23,26
153262	Arm 39	153883	Gear, 33T 19	156536	Screw, 4-40 x 1/8 Fil 23
153294	Cam 30	153884	Gear, 11T 4	156574	Post, Spring 30
153295	Shaft 30	154290	Ring "O" 35	156576	Washer, Felt 21
153298	Bracket, Right 30	154320	Finger, Left Paper 35	156632	Screw, 6-40 x 13/32 Hex 2
153299	Bracket, Left 30	154323	Cam, Eccentric 5	156740	Screw, 6-40 x 7/32 Hex 2 to 6,12,13,14,20,21,22, 25,26,29,34,36,37,39,40
153301	Arm 30	154332	Shaft 33,34		
153304	Bushing, Shoulder 3	154333	Roller 33,34		
153305	Spring, Torsion 26	154352	Spring 9,13		
153311	Arm 26	154358	Hub, Platen 35		
153312	Lever 3	154380	Bracket w/Post 14		
153314	Bracket 26				
153321	Bracket, Tie 14				
153322	Guide 30				
153360	Stud 37				
153365	Arm, Cam 37				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
156875	Screw, 6-40 x 5/32 Fil 15,27	160500	Lever, Blocking 36	174327	Cover 40
157194	Retainer, Spring 24	160502	Slide, Form Out 36	176222	Platen, 7-5/8 Rubber 35
157237	Shield, Terminal 24	160503	Slide, Tab 36	176238	Platen 35
157238	Spring 16	160510	Disc, Retaining 36	176247	Bail, Blocking 32
157240	Spring 32	160532	Spring 36	179194	Bracket 36
157274	Clip 30	160578	Sleeve, Pinion 36	179782	Screw, 6-40 x 7/8 Hex 2, 23
157286	Clamp, Platen 35	160626	Insulator, 0.031" Thk 39	179999	Bail, Spring 33,34
157289	Bar, Cross 27	160627	Bushing, Insulating 39	182643	Terminal, Plug Type 24
157290	Bail, Pressure 27	160628	Spring, Contact 39	192342	Screw, 2-56 x 1-1/16 Fil 38
157291	Guide, Rear Paper 27	160630	Spring, Contact 39	192345	Spring, Torsion 38
157614	Pallet, Type 16	160631	Spring, Contact 39	193722	Bushing, Insulator 40
157647	Pallet, Type 16	160679	Spring 23	194017	Pallet, Type 16
157659	Pallet, Type 16	160843	Spring 20	194052	Plate, Form Stop 36
157726	Pallet, Type 16	161238	Connector, 36 Pt Receptacle 24	194868	Gear 48T 19
157790	Pallet, Type 16	161346	Washer, Felt 7,33,34	194870	Gear, 16T 28
157791	Pallet, Type 16	161347	Washer, Felt 29	194871	Disc, 6 Stop 19
157899	Arm, NC Contact 30	161440	Spring 15	194872	Disc, 6 Stop 19
157979	Link, Toggle 33	162573	Retainer 18,19	194884	Pallet, Type 16
158163	Switch, Sensitive 38	162728	Arm 26	194885	Pallet, Type 16
158182	Disc, Clutch Cam 18,19	162729	Bar, Guide 26,36,39	194956	Spring 19
158186	Screw, 4-40 x 7/32 Fil 7	162886	Screw, 4-40 x 7/32 Hex 7	194982	Clip, Connector 24
158317	Insulator, Switch 40	163181	Wheel, Horizontal Tab 37	195056	Spring 25
158334	Spring, Torsion 37	163182	Bracket, Stop 37	195240	Post 24
158335	Stud 5,37	163949	Bushing 28	195855	Pin, Sprocket Feed 35
158337	Plate w/Pin 37	163958	Washer, Flat 28	196007	Link 10
158339	Arm w/Pin 37	163960	Bushing 28	196009	Shaft 10
158340	Bracket, Stop 37	164386	Bracket, Magnet Mounting 24	196010	Link w/Post 10
158341	Plate, Stop 36,37	164958	Screw, 4-40 x 1/2 Hex 33,34	196014	Plate 8,11
158342	Arm 37	170004	Bracket w/Bushing 20	196017	Spacer, 0.156" Thk 10
158343	Bracket, Spring 37	170198	Arm, Stop 23	196018	Bushing 8,10,11
158344	Nut, 6-40 Shoulder 37	170232	Guide, Lower 23	196024	Spacer, 0.083" Thk 18
158347	Bracket 37	170265	Spacer 4	196032	Shaft w/Arm 2
158351	Pawl w/Stud 37	171555	Connector, 50 Pt Plug 24,30	196036	Ring, Retaining 18
158353	Bail, Stop 20	172566	Switch Assembly 30	196037	Lever, Cam Follower 20
158354	Arm, Extension 20	172575	Switch Assembly 30	106040	Clutch Assembly, Function 17,19
158357	Wheel, Horizontal Tab 37	172576	Switch Assembly 30	196043	Latchlever 20
158365	Blade, Reset 29	172586	Switch Assembly 30	196048	Clutch Assembly, Spacing 17,19
158893	Post, Spring 21	172591	Spring, Contact Arm 30	196049	Cam, Spacing 19
158907	Spring 23,25	172595	Plate, Contact 30	196050	Clutch Assembly, Codebar 17,18
158923	Bearing, Sleeve 18	172597	Block, Contact 30	196052	Cam, Trip 18
158924	Disc 18	173807	Setscrew, 6-40 3,20	196053	Clutch Assembly, Printing 17,18
159341	Bearing, Ball 17	173902	Spring, Compression 14	196054	Cam 19
159597	Washer, Flat 7	173974	Screw, 10-32 x 5/16 Hex 4,13	196057	Cam 18
160180	Armature w/Extension 24	173979	Head, Hammer 40	196058	Clamp 2,3
160184	Plate, Stop 24				
160186	Bushing, Shoulder 24				
160486	Bail 36				
160490	Pawl 36				
160499	Lever, Blocking 36				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
196059	Clamp 3	196168	Latch w/Bearing 8	196250	Pulley 6
196066	Frame, Carriage 7,41	196172	Plate, Horizontal Positioning 8	196251	Rail, Guide 6
196068	Pin 7	196175	Plate, Horizontal Positioning 8	196252	Post 4,6
196072	Shaft 7	196178	Plate, Horizontal Positioning 8	196254	Ring w/Roller 22
196073	Lever 7	196179	Lever, Shoe Release 9	196255	Bracket, Mounting 6,41
196074	Lever, Hammer 7	196182	Slide 8,11	196256	Shaft, Rocker 6
196075	Plate 7	196184	Bearing, Ball 4,8,11,12	196259	Post 3,5
196079	Bracket 7	196186	Lever w/Bushing 11	196260	Bracket, Spring 11
196080	Plate w/Roller 7	196187	Lever w/Bushing 11	196262	Link 9,10
196082	Roller 7	196188	Bail w/Pin 11	196264	Link w/Stud 2,6
196083	Stud, Eccentric 7	196189	Bail w/Pin 11	196265	Clamp 6
196084	Stud 7	196191	Bearing, Ball 10	196266	Clamp 6
196085	Stud 7	196193	Plate, Front 4,5,9,11, 22,37,39	196268	Spring 22
196086	Latchlever 7	196196	Link Assembly, Right 10	196269	Rope, Wire 22
196088	Lever, Trip 7	196197	Link Assembly, Left 10	196271	Guide 2
196089	Screw, 4-40 Shoulder 7	196203	Guide 8,11,12	196272	Spacer 2
196091	Guide, Hammer 7,41	196205	Latch w/Bearing 8	196274	Gear, 22T 2,3
196092	Plunger 7	196208	Plate 8	196278	Block, Guide 2
196094	Head, Print Hammer 7	196210	Post 4,8	196279	Block, Guide 3
196095	Bracket 7	196214	Screw, 4-40 Shoulder 10, 13	196280	Spacer 2
196098	Bracket 25	196215	Screw, 4-40 Shoulder 10, 13	196281	Spacer 3
196106	Shaft 25	196216	Ring, Retaining 19	196282	Screw, 6-40 Shoulder 3
196108	Bracket 14	196218	Screw, 4-40 Shoulder 10	196283	Screw, 6-40 Shoulder 2
196112	Plate 14	196220	Bearing, Sleeve 18,19	196285	Lever w/Stud 3
196113	Pin, Roll 25	196223	Shaft, Main 17	196286	Guide 2,3
196115	Bracket 14	196226	Spacer 19	196331	Screw, 6-40 Eccentric 15
196116	Guide, Eccentric 25	196230	Bracket, Left 14	196332	Plate, Clamp 15
196117	Washer, Felt 25	196231	Codebar, No. 1 and No. 5 14	196333	Track 15
196118	Link w/Studs 25	196232	Codebar, No. 2 14	196335	Gear, 84T 17
196121	Lever, No. 1 Transfer 25	196233	Codebar, No. 3 14	196336	Post 21
196122	Lever, No. 2 Transfer 25	196234	Codebar, No. 4 14	196337	Post 21
196123	Lever, No. 3 Transfer 25	196235	Codebar, Suppression 14	196338	Shaft 20,21,37
196124	Lever, No. 4 Transfer 25	196236	Codebar, No. 6 and No. 8 14	196339	Post, Spring 3
196125	Lever, No. 5 Transfer 25	196238	Bar 14	196342	Bar, Function 31
196126	Lever, No. 6 Transfer 25	196239	Bracket 15	196344	Link w/Stud 2
196127	Lever, No. 7 Transfer 25	196240	Spring, Flat 10,15	196351	Camshaft 29
196128	Lever, No. 8 Transfer 25	196241	Plate 10,15	196352	Bracket, Spring 21
196131	Lever, Front 25	196242	Bail 10	196353	Collar 17
196132	Lever, Rear 25	196244	Washer, Flat 6	196354	Plate, Stop 21
196133	Roller 25	196245	Stud 6	196355	Bracket 21,38
196134	Screw, 6-40 x 1-1/4 Flat 25	196247	Bracket, Spring 22	196357	Link w/Studs 21
196144	Wick, Felt 11	196248	Pulley 6	196361	Bracket, Spring 21
196145	Post 8,11	196249		196362	Lever, Trip 20
196148	Pinion, 32T 11			196363	Latchlever 20
196149	Gear, 40T 9			196366	Slide 15
196159	Washer, Thrust 8			196367	Plate, Clamp 15
196160	Cam 19			196369	Housing 11,26
196162	Drum, Clutch 9,13			196371	Clamp 21,30
196166	Bearing, Thrust 8			196373	Bearing, Ball 15
				196375	Link 29

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
196376	Link 21	196485	Toggle 12	306173	Shaft 3
196377	Lever w/Roller 2	196486	Link 12	306174	Bail 3
196378	Lever w/Roller 2	196487	Follower, Eccentric 12	306175	Link 3
196382	Bracket w/Bearing 29	196488	Pawl, Check 12	306176	Latch 21
196384	Bracket 26,39	196489	Pawl, Feed 12	306177	Stud 21
196386	Plate, Right 6,22	196490	Gear, 40T 12	306179	Slide 26
196387	Plate, Left 4,6,22	196495	Ratchet 12	306181	Drum, Spring 22
196392	Link 21,29	196505	Lever, Push 23	306185	Lever 26
196399	Bushing 21	196584	Spacer, Clutch 18	306186	Bail 26
196402	Lever w/Stud 13	199440	Screw, 6-40 x 5/8 Fil 18,19	306190	Frame, Right Side 2,17,25
196405	Link w/Bushing 13	304460	Spring 30	306191	Frame, Left Side 3,17
196406	Link w/Stud 13	304461	Bushing 30	306197	Spring 7
196407	Link w/Stud 13	305023	Lock, Shaft 35	306201	Bar, Function 31
196408	Link w/Stud 13	305024	Arm, Right 35	306202	Bar, Function 31
196413	Slide 12	305025	Retainer 35	306204	Bar, Function 31
196420	Link w/Post 13	305027	Arm, Right 35	306205	Bar, Function 31
196421	Link w/Bearing 13	305473	Bail 39	306206	Bar, Function 31
196423	Spacer 13	305541	Slide, Stripper 30	306207	Bar, Function 31
196424	Shoe 13	306102	Shaft 23	306208	Bar, Function 31
196425	Screw, 4-40 Shoulder 13	306107	Bracket 24	306209	Bar, Function 31
196426	Sleeve 13	306109	Lever, No. 1 Push 23	306214	Bar, Function 31
196427	Post w/Plate 13	306115	Bracket 23	306221	Bar, Function 31
196428	Lever, Shoe Release 13	306116	Lever, Auxiliary Push 23	306222	Link 9,10
196430	Latch 13	306117	Lever, Auxiliary Strip 23	306223	Link 9,10
196431	Link 13	306118	Bail, Stripper 23	306224	Link 9,10
196433	Link Assembly 13	306119	Bail, Start 23,40	306226	Bracket, Guide 12
196435	Gear, 17T 13	306121	Rack, Sector 23	306235	Gear, 30T 17
196436	Gear, 24T 17	306125	Lever, Lift 23,40	306236	Gear, 20T 11
196437	Gear, 34T 13	306126	Bracket, Guide 23	306237	Rail 15
196440	Disc 17	306127	Lever, Start 23	306240	Arm 15
196441	Disc 17	306128	Lever, No.2 thru No.8 Selector 23	306242	Block, Guide 4
196442	Washer, Felt 17	306129	Plate, Selector 23,24	306243	Bracket 4
196450	Bail w/Bushing 12	306130	Lever, No.1 Selector 23	306246	Bracket 24
196452	Guide 12	306131	Plate w/Studs 23	306262	Bail w/Bushing 12
196454	Plate 12,13	306148	Lubricator Assembly 23	306265	Link 13
196456	Plate 3,13	306153	Stud 23	306268	Latch w/Bearing 8
196457	Bracket w/Post 2,13	306154	Bracket 23	306269	Post 20
196461	Bushing 13	306156	Screw, 1/4-20 Spl 23	306270	Bearing 6
196464	Spacer 13,28	306158	Arm 23	306271	Plate, Nut 15
196465	Shaft 28	306160	Clutch Assembly, Selector 17,18	306273	Screw, 8-32 Adjusting 15
196466	Track 13	306163	Brace 3	306274	Clamp, Typebox 15
196467	Bracket 13	306166	Follower, Trip Cam 3,23	306275	Bar, Line Feed 28
196468	Rack, 17T Right 2	306167	Post, Spring 2	306278	Arm, Follower 20
196469	Rack, 17T Left 3	306168	Guide 23	306279	Clamp, Trip Lever 20
196471	Bearing 35	306169	Bushing 23	306280	Lever, Trip 20
196474	Plate w/Bushing 3,30	306172	Bracket, Trip 3	306281	Latchlever 20
196476	Ring, Retaining 22			306282	Housing w/Bearing 2
196478	Bracket, Stop 12			306284	Shaft w/Arm 2,25
196480	Plate, Trip 12			306286	Block w/Bearing 2
196484	Plate w/Post 12				

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
306290	Arm, No.1, No.2 and No.3 25	306390	Pointer 36	312939	Bail, Latch 25
306291	Arm, No.4 and No.5 25	306391	Bracket 39	312940	Bracket, Bail 25
306292	Arm, No.6, No.7 and No.8 25	306398	Bracket w/Post 33	312941	Shaft 25
306297	Post 25	306399	Spring, Torsion 25	312972	Cam 18
306298	Arm, Stop 25	306402	Modification Kit 1,38	312974	Lever, Space Lock 23
306299	Bracket 25	306406	Modification Kit 1,39	318777	Washer, 0.365" OD Sealing 23
306300	Camsleeve 18	306408	Spool w/Ribbon 1,33	319481	Lever 32
306314	Disc w/Gear 23	306409	Bracket, Left Spool 33	319498	Cable w/Terminals 24
306315	Arm 23	306411	Bracket, Right 34	319530	thru
306316	Modification Kit 1,39	306412	Bracket, Left 33	319543	Pallet, Type 16
306317	Bail 39	306416	Plate, Right 6	319545	thru
306324	Arm w/Hub 28	306417	Plate, Left 6	319561	Pallet, Type 16
306328	Handwheel 28	306418	Spacer 6	319563	Pallet, Type 16
306329	Lever 28	306419	Bracket 34	319564	Pallet, Type 16
306330	Post, Spring 28	306420	Bracket 33	319566	thru
306331	Spring, Torsion 3	306422	Bracket, Stop 26	319570	Pallet, Type 16
306333	Knob, Adjusting 7	306424	Link 33,34	319573	thru
306334	Screw, 6-40 Shoulder 7	306426	Lever, Feed 34	319579	Pallet, Type 16
306335	Spring 7	306427	Lever, Feed 33	319581	Pallet, Type 16
306339	Bracket, Right Spool 34	306459	Spool, Ribbon 34	319583	thru
306353	Terminal, Plug Type 30, 38,39,40	306488	Bracket 3	319607	Pallet, Type 16
306357	Insulator 24	306489	Spool w/Ribbon 1,33	319609	Pallet, Type 16
306358	Terminal, Receptacle Type 30,38,39	306527	Blade, Bail 30	319610	Pallet, Type 16
306359	Housing, Pin 30,38,39,40	306529	Shaft 8,11	319621	Pallet, Type 16
306360	Housing, Socket 30,38,39	306530	Bushing 8	319623	Pallet, Type 16
306361	Post, Spring 27	306531	Guard 8	319625	thru
306362	Bearing, Sleeve 28,35	306539	Plate, Identification 6	319638	Pallet, Type 16
306363	Spacer 28	306540	Plate, Identification 6	319650	Modification Kit 1,40
306364	Lever 27	306543	Link 5	319651	Bracket 40
306367	Platen 28	306545	Link 5	319652	Shaft 40
306369	Guide 27,40	306550	Post 5	319653	Lever 40
306370	Bracket, Mounting 38	306554	Bail 5	319671	Bail 26
306371	Link 38	306558	Link 4	319673	Guide, Right 27
306374	Post 37	306565	Cable 39	319674	Guide, Left 27
306375	Bracket 37	306571	Screw, 4-40 x 3/16 Hex 16	319675	Stud 27
306376	Plate w/Stud 37	306572	Spring, Torsion 6	319677	Bracket, Spring 17
306377	Bail, Latch 37	306598	Disc, Adjusting 18,19	319678	Screw, 4-40 Shoulder 3
306378	Arm, Slide 37	306599	Lever, Shoe Release 18,19	319681	Spacer 2
306379	Bracket w/Studs 37	307289	Lever 28	319682	Plate 12
306380	Lever w/Bushing 37	312912	Connector, 15 Pt Plug Type 24	319683	Plate, Stop 3
306381	Latch 37	312924	Lever w/Post 23	319685	Pawl, Stop 12
306382	Plate w/Studs 36,39	312926	Bracket, Spring 23	319688	Latch 12
306386	Lever w/Stud 36	312927	Bracket 23	319689	Stop 12
306387	Lever w/Stud 36	312928	Reservoir, Oil 23		
306388	Lever w/Hub 36	312929	Wick, Leather 23		
306389	Lever w/Hub 36	312931	Retainer, Wick 23		
		312932	Plate, Reservoir Top 23		
		312938	Bail, Latch 25		

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
319690	Nut, 6-40 Spl 39	319852	Cam 18	326048	Post 6
319691	Lever 39	319853	Post, Guide 4	326088	Spring 5
319692	Link 39	319854	Plate 4	326169	Screw, 4-40 Spl 18,19
319693	Bail 39	319855	Post 4	326185	Switch Assembly 39
319694	Pawl 39	319858	Arm 4	326191	Screw, 4-40 Spl 18
319695	Hanger, Spring 39	319859	Screw, 6-40 Shoulder 4	326401	Support, Copyholder 1,37
319696	Bracket 39	319861	Plate 4	326582	Bracket 24
319697	Bushing 15	319862	Block, Guide 4	327815	Cable Assembly 24
319698	Screw, 4-40 x 11/64 Spl 4,39	319863	Screw, 6-40 Spl 4	327817	Cable Assembly 30
319701		319864	Spring, Torsion 3	328293	Shaft 40
thru		319865	Post 11	328295	Rack 40
319752	Pallet, Type 16	319866	Lever 33	328296	Bracket 40
319755		319867	Lever 34	328298	Lever 40
thru		319868	Plate, Stop 33,34	328299	Contact Assembly 40
319762	Pallet, Type 16	319872	Shaft 35	328300	Modification Kit 1,40
319775	Typebox Arrangement AYE 1,16	319874	Hub, Platen 35	328717	Latchlever 35
319790	Bar, Function 31	319877	Bail w/Plate 12	328718	Lever w/Stud 27
319791	Bar, Function 31	319878	Codebar, No.1 14	330539	Bracket, Stop 40
319792	Bar, Function 31	319881	Clutch Assembly, Line Feed 17,19	330549	Plunger 40
319793	Bar, Function 31	319882	Plate, Front 16	330571	Rail, Guide 7
319796	Bar, Function 31	319883	Plate, Rear 16	330572	Bracket, Clamp 7
319798	Bar, Function 31	319885	Typebox Assembly, AYD 1,16	330573	Bail, Indicator 7
319799	Bar, Function 31	319894	Lever, Function 32	330574	Screw, 4-40 x 9/32 Spl 15
319800	Bar, Function 31	319895	Latch 32	330696	Spring, Torsion 40
319801	Bar, Function 31	319896	Lever, Blocking 32	330700	Modification Kit 1,41
319802	Bar, Function 31	319897	Guide, Bar 30	330701	Support, Left Scale 41
319821	Pawl, Feed 5	319898	Stud 32	330702	Support, Right Scale 41
319822	Pawl, Feed 5	319898	Stud 32	330703	Scale 41
319823	Arm 3	319899	Bracket 3	330704	Screw, 6-40 Thumb 41
319824	Bracket 3	320408	Terminal, Spade Type 24	330705	Pointer 41
319825	Bracket, Guide 4	320410	Terminal, Spade Type 24,30	330709	Scale 41
319826	Clamp, Housing 3,4	323051	Plate w/Post 38	330786	Jumper, 11" Black 40
319827	Spring, Flexible Control 3,4	323052	Guide, Paper 35	330979	Screw, 6-40 Spl 7
319830	Ratchet, 18T 22	323077	Spacer 38	330980	Block, Mounting 7
319832	Spacer 2	323078	Lever w/Hub 38	332096	Indicator 7
319833	Bail 2	326010	Modification Kit 1,37	332157	Retainer 5
319839	Lever 2	326011	Stripper 30	332158	Cylinder, Dash Pot 5
319840	Roller 2	326012	Switch Assembly 38	332199	Plate 15
319841	Disc 2	326013	Modification Kit 1,38	332318	Stop 22
319842	Hub 2	326014	Guide, Paper 35	332456	Stud 16
319843	Lever 3	326020	Disc, Adjusting 19	332497	Guide 16
319846	Post 3	326023	Screw, 4-40 x 9/32 Hex 8,11,12	332498	Guide, Ribbon 28
319847	Plate 3	326024	Roller, Detent 3,4	332499	Screw, 4-40 Spl 28
319848	Disc 4	326026	Lever, Line Feed 6	333006	Spring 5
319849	Arm 15	326027	Lever, Carriage Return 6	333008	Shoe, Secondary Clutch 18,19
319850	Shaft w/Bearing 2,3	326028	Bracket 6	333009	Shoe, Primary Clutch 18, 19
319851	Spring 4	326029	Bracket 6	333174	Latch w/Hub 23

NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
333179	Guidepost 23	334254	Retainer 19	334287	Switch w/Cable 40
333538	Spring, Contact 40	334259	Spring 22	334351	Washer, Flat 18,19
333539	Spring, Contact 40				