

37 TELETYPEWRITER TABLES

DESCRIPTION AND OPERATION

CONTENTS	PAGE
1. GENERAL	1
2. DESCRIPTION	1
TECHNICAL DATA	1
A. Double Compartment Table	1
B. Single Compartment Tables	1
3. OPERATION	1
FRONT PANEL	1
FRONT DOOR	1

1. GENERAL

1.01 This section provides description and operation information for late design, front and rear loading 37 teletypewriter tables. The tables, which support a typing unit and enclose its associated equipment, are available in three variations: a double compartment table and two single compartment tables, which differ primarily in the overall depth dimension. This section is reissued to incorporate engineering changes and comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted. Refer to Section 574-323-100TC for information on early design, rear loading tables.

2. DESCRIPTION

TECHNICAL DATA

A. Double Compartment Table

Weight	88 pounds
Height	26-1/4 inches
Width	32-1/2 inches
Depth	23-3/32 inches

B. Single Compartment Tables

	<u>Standard Depth</u>	<u>Narrow Depth</u>
Weight	70 pounds	68 pounds
Height	26-1/2 inches	26-1/2 inches
Width	22-1/2 inches	22-1/2 inches
Depth	23-3/32 inches	17-7/32 inches

2.01 The features of the tables are described in Figures 2, 3, and 4.

3. OPERATION

FRONT PANEL

3.01 The front panel is secured to the table by a latch. Pressing downward on the latch releases the panel. The front panel is removed by opening the panel to just beyond the front edge of the table top and lifting.

FRONT DOOR

3.02 The front door is secured to the table by a latch on the left side of the pedestal. Pressing inward on the latch releases the front door. The door may be removed, when open, by lifting.




Figure 1 - Double Compartment Table





Figure 2 - Double Compartment Table (Front View)

TABLE TOP

- Plastic laminate to protect against wear.

COVER WELL

- Shaped to cover.
- Prevents cover from slipping forward.



LEGS

- Adjustable for height leveling.

REAR PANEL

- Removable to accept paper handling equipment.

Figure 3 - Double Compartment Table (Rear View)

COVER WELL

- Shaped to accommodate typing unit cover.

PAPER ENTRY SLOT

CABLE ENTRY SLOT

AIR VENT

TABLE TOP

- Plastic laminate to protect against wear.

FRONT PANEL

- Provides access to electrical service unit and interconnecting cables.
- Removable.

LEGS

- Adjustable for height leveling.





Figure 4 - Single Compartment Tables (Front Views)