

43 KSR STATION

PARTS

CONTENTS	PAGE
1. GENERAL .....	1
2. PARTS .....	2
NUMERICAL INDEX.....	3
1. GENERAL	
1.01 Information on maintenance spare parts is provided in this section for the 43 Teleprinter Basic KSR Station.	
1.02 Whenever this section is reissued, the reason for reissue will be listed in this paragraph.	
1.03 This section is provided to identify the Teletype Corporation or Western Electric Company part number and location of recom-	


mended spares that should be available and may be required to correct a trouble.

1.04 Part numbers are listed in the index in numerical order and indicate the page on which the parts appear. Asterisked numbers, stocked as "List 1", indicate a maintenance spare stocking ratio of one spare for the first ten stations and an additional spare for each additional 30 stations in a maintenance area. Part numbers without asterisks, stocked as "List 2", indicate that one spare should be available in each maintenance area.

1.05 When ordering replacement components, unless indicated as a Western Electric Company part, prefix each part number with "TP" (ie, TP410055).

1.06 Troubleshooting, disassembly and reassembly information for these parts are covered in Sections 574-500-300 and 574-500-720 respectively.

2. PARTS



## NUMERICAL INDEX

*Note*: One spare should be available in each maintenance area, unless otherwise specified in parenthesis.

Part Number	Description and Page Number	Part Number	Description and Page Number
43K101/CAA*	Operator Console (Unit Code) 2	143307* (5)	Fuse 0.6 A SLOW-BLOW (L. Card) F3 2
153A1*	Terminal Data Unit (TDU) (Western Electric Co.) 2	410740*	Logic Card 2
120139* (5)	Fuse 1.0 A (Power Supply) F2 2	430554 (2)	Clip 2
143306* (5)	Fuse 1.0 A SLOW-BLOW (R. Frame) F1 2	430610	Cable to Power Supply 2
		430611	Cable to TDU 2
		430700*	Power Supply Assembly 2

\*A maintenance spare stocking ratio of one spare for each ten stations and one additional spare for each additional 30 stations in a maintenance area.