





43 PRINTER


PARTS

CONTENTS	PAGE	
1. GENERAL	1	
2. PARTS	2	
NUMERICAL INDEX.....	7	
1. GENERAL		
1.01 Information on maintenance spare parts is provided in this section for the 43 printer.		
1.02 Whenever this section is reissued, the reason for reissue will be listed in this paragraph.		
		1.03 Part numbers are listed in the index in numerical order and indicate the page on which the parts appear. Asterisked numbers, stocked as "List 1", indicate a maintenance spare stocking ratio of one spare for the first ten stations and an additional spare for each additional 30 stations in a maintenance area. Part numbers without asterisks, stocked as "List 2", indicate that one spare should be available in each maintenance area.
		1.04 When ordering replaceable components, unless otherwise specified, prefix each part number with "TP" (ie, TP430019).
		1.05 Troubleshooting and disassembly/reassembly information for these parts is provided in Section 574-501-300 and Section 574-501-702, respectively.



2. PARTS




① 410013 Card w/Cable
Part of 430850




① 430047 Motor w/Cable and Encoder





SECTION 574-501-800



NUMERICAL INDEX

Note: One spare should be available in each maintenance area, unless otherwise specified in parentheses.

Part Number	Description and Page Number	Part Number	Description and Page Number
183321 (2)	Sprocket w/Pins 2	430107	Bracket, Left 6
188406	Switch, Actuator 6	430113*	Coil Assembly 3
410013	Card Assembly 2	430114	Plunger w/Pin 3
430010	Rod, Guide 4	430117	Cable Assembly 3
430011	Tray, Paper 6	430118*	Spring, Compression 3
430012	Shaft, Paper Tray 6	430142	Clip, Platen 2
430013 (2)	Bearing, Platen 2	430143*	Pulley, 42T Platen 2,3
430016	Post, Lever 4	430144*	Pulley w/Flange, 24T 3
430017	Lever w/Stud 4	430145*	Belt, Timing 2,3
430019*	Roller w/Bearing 4	430151 (2)	Mount, Rear 5
430020 (2)	Bearing, Housing 4	430152 (2)	Stud 5
430021*	Spring 4	430153 (2)	Clip 5
430026*	Bearing, Outer 4	430154*	Motor w/Cable 3
430027*	Bearing, Inner 4	430163	Cable Assembly 6
430028	Spring, Compression 4	430166	Bracket, Bell 3
430029	Screw, Lead 3	430167	Bracket, Bell 3
430030	Spring, Compression 2	430169	Strip, Insulator 5
430031*	Nut, Special 2	430178	Housing 3
430032*	Belt, Timing 4	430179	Guide 6
430033*	Pulley, 81T 4	430180	Bracket, Right 5
430034	Fastener 4	430190	Motor w/Cable 3
430045	Lever, Switch 6	430198 (2)	Clamp 5
430046	Bracket, Switch 6	430205 (2)	Bumper 5
430047*	Motor w/Cable and Encoder 3	430206	Spacer 2
430055	Cable Assembly 3	430212	Bracket, Margin 6
430058	Cover 3	430213	Nut, Speed 3
430061	Disc, Encoder 3	430214*	Pulley w/Clip 3
430063	Fastener 3	430215	Carriage w/Post 2
430068	Nut 8-32, Spl 2	430216	Collar w/Link 2
430069	Handle, Locking 2	430217*	Bridge Assembly 2
430088	Plate 2	430218	Bracket Assembly, Left 6
430098 (2)	Clip, Sprocket 2	430219	Plate Assembly, Left 6
430100	Guide, Left Paper 6	430231	Shield, Ribbon 4
430101	Guide, Right Paper 5	430625 (10)	Supports 3
430102	Bracket w/Posts 5	430803	Cable Assembly 2
430103	Bracket, Right 5	430804	Insulator 2
430104 (2)	Stripper, Paper 5,6	430829	Cover 2
430105	Post 6	430832	Switch 2
430106	Bracket w/Post, Left 6	430850*	Head Assembly, Print 2

*A maintenance spare stocking ration of one spare for each ten stations and one additional spare for each additional 30 stations in a maintenance area.