


43 BASIC KEYBOARD

WIRING


CONTENTS	PAGE	
1. GENERAL .....	1	1.03 Wiring information for the 50K122/AAE and AAF unitized keyboards is not provided since these keyboards are not field serviceable.
2. WIRING .....	2	
1. GENERAL		1.04 For additional wiring information, plug or cable locations, refer to 43 Basic Teletypewriter Wiring, Section 574-500-400.
1.01 This section provides wiring information for the 43 Basic Keyboard.		
1.02 This section is reissued to change the title and change references from operator console to keyboard.		1.05 Where possible, small notes indicating voltage levels have been added to aid in troubleshooting.

2. WIRING


KSR Keyboard



RO Keyboard



CABLE TERMINATION (ON CIRCUIT CARD):



KEYSWITCH TYPES

