

43 OPERATOR CONSOLE

PARTS

CONTENTS	PAGE
1. GENERAL	1
2. PARTS	2
NUMERICAL INDEX.....	3

1. GENERAL

1.01 The parts in this section are maintenance spares for the 43 operator console. They should be available, in the quantities shown in parentheses in the numerical index, to correct troubles in the operator console.

1.02 Whenever this section is reissued, the reason for reissue will be listed in this paragraph.

1.03 When ordering replaceable components, unless otherwise specified, prefix each part number with the letters "TP" (ie, TP41055).

1.04 Troubleshooting and disassembly/reassembly information for these parts is provided in Section 574-502-300 and Section 574-502-720, respectively.

NUMERICAL INDEX

Note: One spare should be available in each maintenance area, unless otherwise specified in parenthesis.

Part Number	Description and Page Number	Part Number	Description and Page Number
340720 (3)	Keyswitch 2	346359	Keyswitch 2
340722	Keyswitch 2	346395	Cable 2
341098	Keyswitch 2	346397 (2)	Bushing 2