

43 TELEPRINTER 5-LEVEL PAPER TAPE PUNCH ASSEMBLY

WIRING

1. GENERAL

1.01 This section provides wiring information for the 43 Teleprinter 5-Level Paper Tape Punch Assembly.



1.02 Whenever this section is reissued, the reason will be listed in this paragraph.

1.03 Related wiring information and cable connections to the logic card are shown in Section 574-504-400.




1.04 Designations on punch assembly wiring diagrams do not appear on the components.

1.05 When ordering, replaceable parts or components, unless otherwise specified, prefix each part number with the letter "TP" (ie, TP410055).

2. PUNCH WIRING



Note: Terminals numbered as viewed from connector end.



CONNECTOR P-301  
TERMINAL NUMBERS

