

43 TELEPRINTER 5-LEVEL PAPER TAPE POWER SUPPLY


WIRING

1. GENERAL


- 1.01 This section provides wiring information for the 43 Teleprinter 5-Level Paper Tape Power Supply.
- 1.02 Whenever this section is reissued, the reason will be listed in this paragraph.
- 1.03 Related wiring information and cable connections are shown in Section 574-504-400.
- 1.04 Designations on wiring diagrams do not appear on the components.
- 1.05 When ordering replaceable parts or components, unless otherwise specified, prefix each part number with the letters "TP" (ie, TP410055).

2. WIRING

P501 CONNECTOR
(341801)




J601 RECEPTACLE
(400921)




P701 CONNECTOR
(400628)



LOW-TAPE SWITCH
(188406)





Wiring of P501 Connector