

Lucent Technologies
Bell Labs Innovations



U.S. English Announcement/Fragments for
DEFINITY® Release 3.2 / INTUITY™ Mach 4 AUDIX®

585-310-593
Issue 1
May 1997

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a1	IF (NUMBER==0) THEN f776: the system greeting ELSE NUMBER ENDIF, f745: active. f823: ...for all calls
a2	f936: Partial entry deleted.
a3	(f350+NUMBER(3)),(f310+NUMBER(1)),a905(NUMBER(2))
a4	f46: To access your mailbox, press star R. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T.
a5	f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a6	f561: You are addressing your message. f285: To add a member, enter extension f224: and pound sign. f328: To delete the previous entry, press star D. To add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star A.
a7	f561: You are addressing your message. f286: To add a member, enter last name f224: and pound sign. f328: To delete the previous entry, press star D. To add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star A.
a8	f46: To access your mailbox, press star R. f291: To transfer to another extension, press star T.
a9	f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a10	f306: You are changing your password. f212: Please enter password again for confirmation. To delete the password you just entered, press *D f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a11	f233: Previous login incorrect. Please re-enter

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	extension f224: and pound sign.
a12	f233: Previous login incorrect. Please re-enter extension f224: and pound sign. f330: Or enter just the pound sign if it's your phone.
a13	f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a14	f306: You are changing your password. f210: Please enter a new password f224: and pound sign. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a15	f555: To access your mailbox, press star R. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a16	f306: You are changing your password. f212: Please enter password again for confirmation. To delete the password you just entered, press *D f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a17	f555: To access your mailbox, press star R. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a18	f555: To access your mailbox, press star R. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a19	f327: You are creating a mailing list. f285: To add a member, enter extension f224: and pound sign. f328: To delete the previous entry, press star D. To add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star A. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a20	f327: You are creating a mailing list. f286: To add a member, enter last name f224: and pound sign. f328: To delete the previous entry, press star D. To

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound.</p> <p>f148: For extension addressing, press star A.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a21	f821: You are administering call types.
a22	<p>f821: You are administering call types.</p> <p>f798: Prime time is TIME, f524: to TIME(2), f788: To identify calls as out-of-hours, press 3. f789: Otherwise, press 4.</p>
a23	<p>f821: You are administering call types.</p> <p>f785: Same greeting used for all calls.</p> <p>f786: To identify calls as internal and external, press 1.</p> <p>f787: To identify calls as busy and no answer, press 2.</p>
a24	<p>f503: You are administering your attendant menu.</p> <p>f502: To record attendant menu, press 1. To listen to attendant menu, press 0.</p> <p>f550: To rewind your attendant menu, press two. To delete it, press star D. To stop playback of your attendant menu, press three.</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a25	<p>f373: You are choosing whether to attach a copy of original message to your reply. To include the original, press Y for yes. To send only your reply, press N for no.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a26	<p>f299: You are administering your greeting.</p> <p>f5: To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound.</p> <p>f39: To delete, press star D. To stop playback, press 3.</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a27	f46: To access your mailbox, press star R.
a28	<p>f529: You are changing your outcalling options.</p> <p>f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3.</p> <p>f528: To turn on, press y. To turn off, press n.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a29	<p>f347: You are adding a list.</p> <p>f111: Please enter list id</p> <p>f224: and pound sign.</p> <p>f366: To specify a different owner by extension, press star D.</p> <p>f363: To approve the list you are creating, press pound.</p>
a30	<p>f302: You are recording announcement fragments. Enter fragment id followed by pound sign. Refer to admin manual for correct id.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a31	<p>f347: You are adding a list.</p> <p>f111: Please enter list id</p> <p>f224: and pound sign.</p> <p>f367: To specify a different owner by name, press star D.</p> <p>f363: To approve the list you are creating, press pound.</p>
a32	<p>f303: You are recording names. Enter extension</p> <p>f224: and pound sign.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a33	<p>f382: You are scheduling your message for delivery.</p> <p>f341: Enter the number of the month, one through twelve, then two digits for the day of the month, then the pound sign.</p> <p>f487: To delete time, press star D. To default rest of the delivery time, press pound.</p>
a34	f108: You are recording a message.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f167: To approve, press pound. To record from here, press 1. To playback, press 2-3.</p> <p>f24: To delete, press star D.</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p>
a35	<p>f816: You are listening to a personal greeting.</p> <p>f753: Enter greeting number.</p> <p>f913: If finished, press pound.</p>
a36	<p>f817: You are recording a personal greeting.</p> <p>f753: Enter greeting number.</p> <p>f913: If finished, press pound.</p>
a37	f820: You are selecting which greeting to activate.
a38	<p>f368: You are entering the number for a new list. Please enter a number up to six digits long</p> <p>f224: and pound sign.</p> <p>f369: To replace an existing list, enter that list's number,</p> <p>f224: and pound sign.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a39	<p>f358: You are identifying a list as private or public.</p> <p>f14: To make private, press 1. To make public, press 2.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a40	<p>f370: These are entries in your list.</p> <p>f294: To add entries, press 1.</p> <p>f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f372: To skip to next entry, press pound. To delete current entry, press star D.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a41	<p>f360: You are scanning mailing lists. To review list members, press 0. To rewind to previous list, press 2. To continue scanning lists, press 3.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f361: To skip to next list, press pound. To delete list, press star D.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a42	f587: You are reviewing a list. f388: To skip, press the pound key. f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a43	f359: You are changing the status of your list. To modify status, press Y for yes or N for no. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a44	f370: These are entries in your list. f333: To add entries to the list or to change status of list, press 1. f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f372: To skip to next entry, press pound. To delete current entry, press star D. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a45	f327: You are creating a mailing list. f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a46	f815: You are administering your personal greetings.
a47	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	9. Slower, press 8.
a48	f549: You are administering your attendant menu. To create attendant menu, press 1. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a49	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN f108: You are recording a message. IF (NUMBER > 0) THEN f1004: To bypass voice recording and create a fax only message, press pound. ENDIF, f13: To record, press 1. After recording, press 1 again. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. ELSE f108: You are recording a message. f13: To record, press 1. After recording, press 1 again. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. ENDIF
a50	f299: You are administering your greeting. f36: To record a personal greeting, press 1. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a51	f306: You are changing your password. f210: Please enter a new password f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a52	f591: To change your outcalling phone number, press one. To hear further instructions on programming a pager, press y. To return to outcalling administration, press n.
a53	f566: You are responding to an outcall notifying you of new messages. f551: To access your messages, f223: Please enter extension f224: and pound sign. f543: To avoid further notification of these messages, press star pound.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f567: Either logging in or pressing star pound will result in the outcall being canceled for the new messages currently in your mailbox. If additional new messages arrive, another outcall will be scheduled."
a54	f347: You are adding a list. f362: If you own the list, press pound. If someone else owns the list f364: enter owner's extension f224: and pound sign. f298: To specify owner by name, press star A.
a55	f347: You are adding a list. f362: If you own the list, press pound. If someone else owns the list f365: enter owner's name f224: and pound sign. f297: To specify owner by extension, press star A.
a56	f220: Enter password f224: and pound sign.
a57	f307: You are playing announcements. f221: Enter announcement id and pound sign. Refer to admin manual for correct id. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a58	f308: You are playing announcement fragments. f222: Enter fragment id and pound sign. Refer to admin manual for correct id. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a59	f309: You are playing names. f223: Please enter extension f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a60	f223: Please enter extension f224: and pound sign.
a61	f357: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star D. To change to extension addressing and delete your entry, press star A. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a62	f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f41: To forward message with comment at beginning, press 2.</p> <p>f126: To forward message with comment at end, press 3.</p> <p>f8: To record a new message, press 4.</p> <p>f1434: To return to getting messages, press pound.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a63	<p>f348: You are specifying a mailing list to review.</p> <p>f111: Please enter list id</p> <p>f224: and pound sign.</p> <p>f366: To specify a different owner by extension, press star D.</p> <p>f363: To approve the list you are creating, press pound.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a64	<p>f348: You are specifying a mailing list to review.</p> <p>f111: Please enter list id</p> <p>f224: and pound sign.</p> <p>f367: To specify a different owner by name, press star D.</p> <p>f363: To approve the list you are creating, press pound.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a65	<p>f348: You are specifying a mailing list to review.</p> <p>f362: If you own the list, press pound. If someone else owns the list</p> <p>f364: enter owner's extension</p> <p>f224: and pound sign.</p> <p>f298: To specify owner by name, press star A.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a66	<p>f348: You are specifying a mailing list to review.</p> <p>f362: If you own the list, press pound. If someone else owns the list</p> <p>f365: enter owner's name</p> <p>f224: and pound sign.</p> <p>f297: To specify owner by extension, press star A.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	finished, please hang up or to disconnect AUDIX, press star star X.
a67	<p>f348: You are specifying a mailing list to review.</p> <p>f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9.</p> <p>f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name.</p> <p>f224: and pound sign.</p> <p>f148: For extension addressing, press star A.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a68	<pre># VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. IF (NUMBER > 0) THEN f1004: To bypass voice recording and create a fax only message, press pound. ENDIF, f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f46: To access your mailbox, press star R. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound.</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f46: To access your mailbox, press star R.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a69	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f46: To access your mailbox, press star R.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f516: To leave a message that will be delivered as soon as possible,</p> <p>f380: Please wait.</p>
a70	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f46: To access your mailbox, press star R.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f274: Please make entry soon, or be disconnected.</p>
a71	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f46: To access your mailbox, press star R.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f515: To be transferred to an operator,</p> <p>f380: Please wait.</p>
a73	<pre># VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER(3) == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(4) - 1 fax enabled, 0 - fax disabled IF (VERSION > 2) THEN f378: You are checking the status of your outgoing messages. # INTUITY 3.0 IF (NUMBER(3) == 1) THEN</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> #Voice only f1462: To listen to the message, press 0. ELSE IF (NUMBER(3) == 2) THEN #FAX only IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #Voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF ENDIF, f1039: To change or send again, press one. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. IF (NUMBER(3) != 2) THEN f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ELSE # DEFINITY AUDIX 3.0, 3.1 f378: You are checking the status of your outgoing messages. f474: To listen, press 0. To change or send again, press 1. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ENDIF </pre>
a74	<pre> f819: You are scanning your personal greetings. f781: To skip to the next greeting, press the pound sign. f756: To listen to greeting NUMBER, f760: press 0. f24: To delete, press star D. f839: To rewind to the previous greeting, press 2. f707: If finished, press star pound. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p>
a75	<p>f385: To approve delivery time, press pound. To modify delivery time, press star D and listen for further instructions.</p>
a76	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # all174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. all174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f983: To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greeting heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a77	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # all174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. all174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f984: To record and send voice mail messages, press 1. To get messages, press 2. To administer attendant menu, press 3. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R.</p> <p>f291: To transfer to another extension, press star star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a78	<p>f324: You are selecting which greeting will be played to callers. If you want your personal greeting to be played, press Y for yes. If you press N for no, the system greeting will be used.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a79	<p>f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator.</p> <p>f545: To delete own time, press star D.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a80	<p>f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator.</p> <p>f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a81	<p>f378: You are checking the status of your outgoing messages.</p> <p>f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f379: To delete status information, press star D.</p>
a83	<p>f326: You are doing system administration. To record names, press 4. To play names, press 5. To record a</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>machine name, press 6. To play a machine name, press 7. To record fragments, press 1. To play fragments, press 2. To play announcements, press 3. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a84	<p>f382: You are scheduling your message for delivery. f488: To specify immediate delivery, press pound. Otherwise f340: Enter the hour, one through twelve, then two digits for the minutes, then A for AM or P for PM, and the pound sign.</p>
a85	<p>f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a86	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER(3) == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(4) - 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN f378: You are checking the status of your outgoing messages. # INTUITY 3.0 IF (NUMBER(3) == 1) THEN #Voice only f1462: To listen to the message, press 0. ELSE IF (NUMBER(3) == 2) THEN #FAX only IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #Voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p style="text-align: center;">ENDIF</p> <p>ENDIF, f1038: To re-record message before delivery, press one. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D.</p> <p>ELSE</p> <p># DEFINITY AUDIX 3.0, 3.1 f378: You are checking the status of your outgoing messages. f381: To listen to the message, press 0. To re-record message before delivery, press 1. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D.</p> <p>ENDIF</p>
a87	f223: Please enter extension f224: and pound sign. f330: Or enter just the pound sign if it's your phone.
a88	f818: You have just recorded f754: Greeting NUMBER, f766: To use this greeting for all calls, press 1. f913: If finished, press pound.
a90	f384: Please enter number of month, then two digits for day, and pound sign.
a92	f910: You are playing an announcement which need additional input before it can be played. f384: Please enter number of month, then two digits for day, and pound sign.
a93	f307: You are playing announcements. f254: To play the active version, press 1. f338: To play the admin version, press 2. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a94	f308: You are playing announcement fragments. f254: To play the active version, press 1. f338: To play the admin version, press 2. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a96	f503: You are administering your attendant menu. f502: To record attendant menu, press 1. To listen to attendant menu, press 0. f550: To rewind your attendant menu, press two. To delete it, press star D. To stop playback of your attendant menu, press three. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a97	f529: You are changing your outcalling options. f105: To restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n. f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a98	f11: You are recording machine names. f6: Enter machine voice ID. f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a99	f549: You are administering your attendant menu. To create attendant menu, press 1. f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a100	f138: You are listening to machine names. f6: Enter machine voice ID. f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a101	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. IF (NUMBER > 0) THEN f1004: To bypass voice recording and create a fax only message, press pound. ENDIF, f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f555: To access your mailbox, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f555: To access your mailbox, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a102	<pre> f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f555: To access your mailbox, press star R. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. f516: To leave a message that will be delivered as soon as possible, f380: Please wait. </pre>
a103	<pre> f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f555: To access your mailbox, press star R.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f274: Please make entry soon, or be disconnected.</p>
a104	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f555: To access your mailbox, press star R.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f515: To be transferred to an operator,</p> <p>f380: Please wait.</p>
a105	<p>f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator.</p> <p>f545: To delete own time, press star D.</p> <p>f105: To restart at the activity menu, press star R.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a106	<p>f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator.</p> <p>f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.</p> <p>f105: To restart at the activity menu, press star R.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a108	<p>f529: You are changing your outcalling options.</p> <p>f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3.</p> <p>f528: To turn on, press y. To turn off, press n.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a109	<p>f669: With the current settings, this login announcement will be interruptible and the login announcement has an expiration date of. DATE</p>
a110	<p>f663: Message waiting notification is not active and this message has an expiration date of. DATE</p>
a111	<p>f668: With the current settings, this login announcement will be non-interruptible and the login</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	announcement has an expiration date of. DATE
a112	f664: Message waiting notification is active and this message has an expiration date of. DATE
a113	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1016: To administer your greeting, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f23: To record messages, press 1. To get messages, press 2. To administer your greeting, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a114	<pre># VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f305: You are at the activity menu. f984: To record and send voice mail messages, press 1. To get messages, press 2. To administer attendant menu, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a115	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f986: To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greetings heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a116	<pre> f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star A. f105: To restart at the activity menu, press star R. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a117	<pre> f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star A. f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a118	<pre> f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one. f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>category, press star pound. f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D.</p>
all19	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # all174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. all174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f985: To record and send voice mail messages, press 1. To get messages, press 2. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> press star star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a120	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f984: To record and send voice mail messages, press 1. To get messages, press 2. To administer attendant menu, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> messages automatically, press 7. To re-logon, press star star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a121	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f986: To record and send voice mail messages, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>press 1. To get messages, press 2. To record or change the greetings heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a122	<p>f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one.</p> <p>f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.</p> <p>f577: To hold the message in its current category, press star star H</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f377: To delete message, press star D.</p>
a123	<p>f323: You are responding to a piece of incoming mail.</p> <p>f41: To forward message with comment at beginning, press 2.</p> <p>f126: To forward message with comment at end, press 3.</p> <p>f8: To record a new message, press 4.</p> <p>f1434: To return to getting messages, press pound.</p> <p>f235: To restart at the activity menu, press star R. To transfer to another extension, press star T.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a124	<p>f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1.</p> <p>f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.</p> <p>f577: To hold the message in its current category, press star star H</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f377: To delete message, press star D.</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a125	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f985: To record and send voice mail messages, press 1. To get messages, press 2. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> disconnect AUDIX, press star star X. ENDIF </pre>
a126	<pre> f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a127	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f983: To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greeting heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a128	<pre> f323: You are responding to a piece of incoming mail. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a129	<pre> # VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p style="margin-left: 40px;">THEN</p> <p style="margin-left: 80px;">f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star R.</p> <p style="margin-left: 40px;">ELSE</p> <p style="margin-left: 80px;">f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star R.</p> <p style="margin-left: 40px;">ENDIF,</p> <p style="margin-left: 40px;">f291: To transfer to another extension, press star T.</p> <p style="margin-left: 40px;">f117: To reach the covering extension, press star zero.</p> <p style="margin-left: 40px;">f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ELSE</p> <p style="margin-left: 40px;">f305: You are at the activity menu.</p> <p style="margin-left: 40px;">f985: To record and send voice mail messages, press 1. To get messages, press 2.</p> <p style="margin-left: 40px;">f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star R.</p> <p style="margin-left: 40px;">f291: To transfer to another extension, press star T.</p> <p style="margin-left: 40px;">f117: To reach the covering extension, press star zero.</p> <p style="margin-left: 40px;">f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a130	f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance.
a131	<p>f725: You are adding entries to your personal directory.</p> <p>f832: Please enter extension and pound sign.</p> <p>f833: To delete current entry, press star D.</p> <p>f58: For name addressing, press star A.</p> <p>f913: If finished, press pound.</p>
a132	<p>f725: You are adding entries to your personal directory.</p> <p>f118: Enter last name</p> <p>f224: and pound sign.</p> <p>f833: To delete current entry, press star D.</p> <p>f148: For extension addressing, press star A.</p> <p>f913: If finished, press pound.</p>
a133	f657: You are choosing options for this broadcast message.
a134	f654: the message will be broadcast and private.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a135	f649: the message will be broadcast.
a136	f723: You are administering your personal directory. f706: To add entries, press 1. To review all entries, press 2. To review a specific entry, press 3. f913: If finished, press pound.
a137	f325: You are administering your lists. To create a mailing list, press 1. To play a summary of all your lists, press 2. To review a particular list, press 3.
a138	f665: You are choosing options for this login announcement.
a139	f650: the message will be a login announcement.
a140	f652: A broadcast message is delivered to every subscriber on this machine. You may also address a broadcast message to subscribers on other machines.
a141	f655: A login announcement will be played each time any subscriber logs onto this machine. You may also address a login message to subscribers on other machines.
a142	f670: Non-interruptible status forces each subscriber to listen to the entire login announcement every time they log onto this machine.
a143	f670: Non-interruptible status forces each subscriber to listen to the entire login announcement every time they log onto this machine. f626: To specify expiration date, press 2. f671: Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date. f661: To approve these options, press pound. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a144	f646: A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.
a145	f645: Private messages cannot be forwarded by the recipients.
a146	f662: Message waiting notification is active. f628: To deactivate message waiting notification, press 1. f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance. f626: To specify expiration date, press 2.
a147	f288: You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star A. f277: To exit directory, press pound. f105: To restart at the activity menu, press star R. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a148	f666: With the current settings, this login announcement will be non-interruptible.
a149	f643: You are choosing options for this message. There are no options currently set. f612: To make private, press 1. f645: Private messages cannot be forwarded by the recipients.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a150	f610: You are recording your name. After you record your name, you can access other AUDIX features. As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1 and at the tone, please speak your first and last name as you would like others to hear it. After speaking your name, press 1 again.
a151	f611: You are recording your name. To record your name, press 1. After recording, press 1 again. To playback name, press 2-3. To approve, press pound.
a152	f322: You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star A. f277: To exit directory, press pound. f105: To restart at the activity menu, press star R. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a153	f838: You are selecting which messages will receive outcalls.
a154	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN IF (NUMBER > 0) THEN f1005: Load your document into the FAX machine. To send, press pound or enter an option. f1002: To hear a list of options, press 0. ELSE f916: To send message, press pound or enter an option, to hear a list of options, press zero. ENDIF ELSE f916: To send message, press pound or enter an option, to hear a list of options, press zero. ENDIF
a155	f644: You are choosing options for this message. With the current settings,
a156	f648: the message will be priority.
a157	f726: You are reviewing all entries in your personal directory. f372: To skip to next entry, press pound. To delete current entry, press star D. f852: To rewind to the current entry, press two. To rewind to previous entries, press two as many times as necessary.
a158	f729: You are reviewing a specific entry in your personal directory. To delete the current entry, press star D. To review another entry, enter the alias followed by the pound sign.
a159	# VERSION > 2 INTUITY 3.0. # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. # CAD = Call Answer Disable and ABR = Address Before

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> Record. XEROX Features # Introduced in INTUITY 3.0 # NUMBER(2) is CAD and 0 is inactive and 1 is active. # NUMBER(3) is ABR and 0 is inactive and 1 is active. # a1174 is called by this announcement to determine the appropriate # fragment to be played depending on what features were active. IF (VERSION > 2) THEN f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. a1174(NUMBER,NUMBER(2),NUMBER(3)), IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f305: You are at the activity menu. f986: To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greetings heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a160	<pre> f660: Expiration date specifies the last day this broadcast message will be available to subscribers. The </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date.</p> <p>f661: To approve these options, press pound.</p> <p>f774: If you have addressed this message and wish to deliver it immediately, press star star pound.</p>
a161	<p>f800: You are specifying the expiration date.</p> <p>f660: Expiration date specifies the last day this broadcast message will be available to subscribers. The expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date.</p> <p>f384: Please enter number of month, then two digits for day, and pound sign.</p> <p>f831: To exit the expiration date options, press star pound.</p> <p>f774: If you have addressed this message and wish to deliver it immediately, press star star pound.</p>
a163	<p>f671: Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date.</p> <p>f661: To approve these options, press pound.</p> <p>f774: If you have addressed this message and wish to deliver it immediately, press star star pound.</p>
a164	f651: the message will be private and priority.
a165	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature # (ABR) -(XEROX feature) # introduced in INTUITY 3.0 # NUMBER(2) == 0 for addressing options not allowed, 1 # for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) # (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, # 1 for call answer # options allowed. # This is the help at subscriber admin w/o "record name" # fragment. IF (VERSION > 2) THEN f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF ELSE f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. f701: To change your password, press 4. ENDIF </pre>
a166	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record(ABR)-(XEROX feature) # introduced in INTUITY 3.0 # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed. IF (VERSION > 2) THEN f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. f702: To record your name, press 5. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF ELSE f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. f701: To change your password, press 4. f702: To record your name, press 5. ENDIF </pre>
a167	<pre> f736: You are recording your name. As you use AUDIX </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>your name will be included in system announcements that you and other people will hear. f608: At the tone, please speak your name. After speaking your name, press 1.</p>
a168	<p>f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a169	<p>f323: You are responding to a piece of incoming mail. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a170	<p>f323: You are responding to a piece of incoming mail. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a171	<p>f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star A. f105: To restart at the activity menu, press star R. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a172	<p>f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star A. f105: To restart at the activity menu, press star R. f282: To have system wait, press star W. To access the</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a173	NAME
a174	NAME, f822: As you use AUDIX your name will be included in system announcements that you and other people will hear. At the tone, please speak your name. After speaking your name, press one.
a175	NAME, f146: To continue, press pound. f143: To step back again, press 2.
a176	NAME, f146: To continue, press pound.
a177	NAME, f680: is busy. Sorry, you cannot leave a message now because this user's mailbox is full.
a178	NAME, f197: Cannot step back.
a179	NAME, f75: To skip, press pound. To delete, press star D. f294: To add entries, press 1.
a180	NAME, f388: To skip, press the pound key.
a181	NAME, f74: deleted.
a182	NAME, f679: is not available. Sorry, you cannot leave a message now because this user's mailbox is full.
a183	# VERSION > 2 is INTUITY 3.0 FAX. Calling a new announcement was cleaner # then trying to change this one. NUMBER(4) == number of fax messages. NAME, IF (VERSION > 2) THEN a1169(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4)) ELSE IF (VERSION>1) THEN IF (NUMBER(2)>0) THEN #password is about to expire a1153(NUMBER(3)) ENDIF ENDIF, NUMBER, f63: new f601: Priority IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF ENDIF
a184	# VERSION > 2 is INTUITY 3.0 FAX. Calling a new

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> announcement was cleaner # then trying to change this one. NUMBER(5) == number of fax messages. NAME, IF (VERSION>2) THEN a1167(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(5)) ELSE IF (VERSION>1) THEN IF (NUMBER(3)>0) THEN #password is about to expire a1153(NUMBER(4)) ENDIF ENDIF, NUMBER + NUMBER(2), f63: new f345: Voice mail IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, f17: including NUMBER, f601: Priority IF (NUMBER == 1) THEN f160: message ELSE f168: messages. ENDIF ENDIF </pre>
a185	<pre> NAME, IF (VERSION>1) THEN IF (NUMBER(2)>0) THEN #password is about to expire a1153(NUMBER(3)) ENDIF ENDIF, IF (VERSION > 2) THEN NUMBER, f63: new IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1011: with fax. ENDIF ELSE NUMBER, f63: new f345: Voice mail IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF ENDIF </pre>
a186	NAMEEXT
a187	NAMEEXT, f74: deleted.
a188	NAMEEXT, f722: was not added to your personal directory.
a190	<pre> # VERSION > 2 is INTUITY 3.0 FAX. Calling a new announcement was cleaner # then trying to change this one. NUMBER(3) == number of fax messages. IF (VERSION > 2) THEN a1168(NUMBER, NUMBER(2), NUMBER(3)) ELSE NUMBER + NUMBER(2), f63: new f345: Voice mail IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, f17: including NUMBER, f601: Priority IF (NUMBER == 1) THEN f160: message ELSE f168: messages. ENDIF ENDIF </pre>
a191	<pre> f158: Transfer cannot be completed. f236: Try again f109: later. f95: Please disconnect. </pre>
a192	<pre> #NUMBER: 0 is stacked response off, 1 is stacked response on #NUMBER(2): 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(3): 0 if sender doesn't exist, 1 if sender exits #NUMBER(4): 1 if FAX enabled, 0 if FAX is not enabled. #NUMBER(5): 1 is voice only, 2 is fax only, 3 is voice </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> and fax # VERSION > 2 INTUITY MACH 3.0 Fax Feature # IF (VERSION<2) THEN #Definity Audix 3.0 f234: To respond or forward, press 1. ELSE #Definity Audix 3.1 IF (NUMBER==0) THEN #stacked response feature off IF (NUMBER(2)==0) THEN #no forwarding f252: To respond to this message, press 1. ELSE #forwarding f234: To respond or forward, press 1. ENDIF ELSE #stacked response feature on IF (NUMBER(3)==1) THEN #sender of message exists, may reply f1463: To reply to sender by voice mail, press 1, 7. ENDIF, IF (NUMBER(2)==1) THEN #forwarding allowed f1464: To forward with comment, press 1, 2. ENDIF, f1465: To record a new message, press 1, 4. ENDIF ENDIF, IF (VERSION > 2) THEN # INTUITY 3.0 IF (NUMBER(5) != 1) THEN # Not voice only IF (NUMBER(4) == 1) THEN # fax enabled, prompt for printing f1073: To print, press star 1. ENDIF ENDIF ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. </pre>
a193	<pre> f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f117: To reach the covering extension, press star zero. f115: To transfer using names instead, press star A. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a194	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f117: To reach the covering extension, press star zero. f115: To transfer using names instead, press star A. f335: When finished, press pound.
a195	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f115: To transfer using names instead, press star A.
a196	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f115: To transfer using names instead, press star A. f335: When finished, press pound.
a197	f94: Good-bye.
a199	f592: AUDIX passwords must now be NUMBER, f81: digits. f593: Please choose a new password of NUMBER(2), f81: digits. f173: Please enter new password f224: and pound sign.
a200	f105: To restart at the activity menu, press star R. f238: To review another list,
a201	f213: Re-enter password f224: and pound sign.
a202	f18: To forward with comment, press 2. f8: To record a new message, press 4.
a204	f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4.
a205	f8: To record a new message, press 4.
a206	f252: To respond to this message, press 1. f24: To delete, press star D. f388: To skip, press the pound key.
a207	f930: Accessed Messages
a208	f625: To activate message waiting notification, press 1.
a210	f246: Message addressed to NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF
a211	f336: To review addressees, press star 1. f247: To add to list,
a212	f334: When finished addressing, press pound.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a213	f464: Enter extensions f224: and pound sign.
a214	f118: Enter last name f224: and pound sign.
a215	f832: Please enter extension and pound sign. f708: If finished adding entries, press pound.
a216	f118: Enter last name f224: and pound sign. f708: If finished adding entries, press pound.
a218	f464: Enter extensions f224: and pound sign. f335: When finished, press pound.
a219	f464: Enter extensions f224: and pound sign. f121: When finished, approve list by pressing pound.
a220	f131: To send to others not on your list,
a222	f118: Enter last name f224: and pound sign. f335: When finished, press pound.
a223	f118: Enter last name f224: and pound sign. f121: When finished, approve list by pressing pound.
a224	f711: Alias BUTTONS, f712: defined for NAME
a225	f711: Alias BUTTONS, f712: defined for NAMEEXT, f74: deleted.
a226	f711: Alias BUTTONS, f712: defined for NAMEEXT, f197: Cannot step back.
a227	f631: Message waiting notification activated. f632: Expiration date will be DATE
a228	f711: Alias BUTTONS, f712: defined for NAMEEXT, f372: To skip to next entry, press pound. To delete current entry, press star D.
a229	f711: Alias BUTTONS, f185: not found.
a230	f744: For all calls,... IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f745: active.
a231	f716: Alias must be ten or fewer numerals.
a232	f716: Alias must be ten or fewer numerals. f727: Enter alias and pound sign.
a233	f717: Alias already defined.
a234	f709: Enter alias for NAME, f224: and pound sign.
a235	# The VERSION > 2 was introduced in INTUITY 3.0 FAX feature. # NUMBER(2) == number of fax messages. f2: and NUMBER, f63: new f601: Priority IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (VERSION > 2) THEN IF (NUMBER(2) > 0) THEN NUMBER(2), f1011: with fax. ENDIF ENDIF
a236	IF (VERSION > 2) THEN f2: and NUMBER, f602: other f63: new IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(2) > 0) THEN NUMBER(2), f1011: with fax. ENDIF ELSE f2: and NUMBER, f602: other f63: new f345: Voice mail IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	ENDIF
a237	f540: and from TIME, f524: to TIME(2)
a238	f16: Enter announcement id f224: and pound sign.
a239	f627: To approve broadcast options, press pound.
a240	f634: To approve login announcement options, press pound.
a241	f606: To re-record your name, press 1. To approve, press pound.
a242	f791: Calls identified as busy and no answer. f792: Calls identified as out-of-hours.
a243	f791: Calls identified as busy and no answer. f793: Calls not identified as out-of-hours.
a244	f790: Calls identified as internal and external. f792: Calls identified as out-of-hours.
a245	f790: Calls identified as internal and external. f793: Calls not identified as out-of-hours.
a246	f502: To record attendant menu, press 1. To listen to attendant menu, press 0. f105: To restart at the activity menu, press star R.
a247	f506: Menu approved and activated.
a248	f505: You have selected an invalid option.
a249	f27: To attach original, press Y for yes or N for no.
a250	f580: Cannot attach a private message
a251	f580: Cannot attach a private message f581: Press N now
a252	f504: Transferring to an operator,
a253	f508: Attendant Service not available, try again later. f95: Please disconnect.
a254	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1-Fax , 0-no Fax. IF (VERSION > 2) THEN f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3. IF (NUMBER==1) THEN f1040: To print all new faxes, press 4. ENDIF ELSE f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3. ENDIF
a255	f29: Returned to checking status of outgoing messages.
a256	f640: Message cannot be both a login announcement and priority.
a257	f641: Message cannot be both a login announcement and private.
a258	f272: Contact administrator for help.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f95: Please disconnect.
a259	f642: Message cannot be both broadcast and a login announcement
a260	f639: Message cannot be both broadcast and priority.
a261	f31: Date not understood. f384: Please enter number of month, then two digits for day, and pound sign.
a262	f32: You must enter your extension to logon.
a263	f100: Invalid Entry.
a264	f35: Login incorrect.
a265	f35: Login incorrect. f236: Try again
a266	f40: Time not understood. f383: Please enter hour, then two digits for minutes, then A for am or P for pm, and pound sign.
a267	f13: To record, press 1. After recording, press 1 again.
a268	f683: Broadcaster has deleted this broadcast message.
a269	# VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1065: Broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1066: Broadcast voice and fax message from ELSE f682: Broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f682: Broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER) ENDIF
a270	# VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2)

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN f1065: Broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1066: Broadcast voice and fax message from ELSE f682: Broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f682: Broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a271	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1065: Broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1066: Broadcast voice and fax message from ELSE f682: Broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f682: Broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>a873(NUMBER),EXTENSION ENDIF</pre>
a272	<pre># VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1065: Broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1066: Broadcast voice and fax message from ELSE f682: Broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ELSE f682: Broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ENDIF</pre>
a273	<pre># VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1128: Broadcast fax message to ELSE IF (NUMBER(2) == 3) THEN f1129: Broadcast voice and fax message to ELSE f1127: Broadcast message to ENDIF ENDIF, f1117: all local subscribers.</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f693: Broadcast message to all local subscribers ENDIF, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a274	f653: For broadcast options, press star M.
a275	f623: Broadcast.
a276	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(2) == 1 if fax enabled, 0 if fax is disabled. IF (VERSION > 2) THEN IF (NUMBER == 1) THEN f21: To listen, press 0. f24: To delete, press star D. f388: To skip, press the pound key. ELSE IF (NUMBER == 2) THEN IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. ELSE f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. ENDIF ENDIF ELSE f21: To listen, press 0. f24: To delete, press star D. f388: To skip, press the pound key. ENDIF </pre>
a277	f917: To schedule delivery, press 3.
a278	<pre> f749: For busy calls,... IF (NUMBER==0) THEN f776: the system greeting </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f754: Greeting NUMBER ENDIF, f745: active. </pre>
a279	<pre> # VERSION > 2 is INTUITY FAX feature. FAX enabled NUMBER == 1, # FAX not enable NUMBER == 0 # NUMBER(2) is used for Call Answer Disable/Enable Xerox Feature # NUMBER(2) == 1 if call answer disabled turned on, 0 if off. IF (VERSION > 2) THEN # INTUITY 3.0 IF (NUMBER(2) == 1) THEN f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f513: Begin your message by saying the name and telephone number of the person you are calling. Someone will listen to the start of your message, and then forward the complete message to the person you called. IF (NUMBER == 1) THEN #Fax enabled f1140: When finished you may attach a fax by pressing pound. ENDIF ENDIF ELSE # DEFINITY AUDIX 3.0 and 3.1 f513: Begin your message by saying the name and telephone number of the person you are calling. Someone will listen to the start of your message, and then forward the complete message to the person you called. ENDIF </pre>
a280	f51: Entries deleted, please re-enter delivery time.
a281	f74: deleted.
a282	<pre> f43: Your call is being answered by AUDIX. f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. f239: followed by the pound sign. </pre>
a283	f5: To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound.
a284	f42: The return address for this message is not a mailbox on this system.
a285	<pre> # announcement changed for Intuity MACH3 FAX Feature # VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature # NUMBER 0 is no message, 1 is message was left IF (VERSION > 2) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN # Intuity 3.0 VERSION is 3 IF (NUMBER==1) THEN f56: Thank you for leaving your message. ENDIF, f46: To access your mailbox, press star R. f973: If you are finished, please hang up, or press star, star X. ELSE # Definity Audix 3.1 VERSION = 2 f56: Thank you for leaving your message. f46: To access your mailbox, press star R. f973: If you are finished, please hang up, or press star, star X. ENDIF </pre>
a286	<pre> f47: Call from NAME, f262: received TIME,DATE,a873(NUMBER) </pre>
a287	<pre> f47: Call from NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER) </pre>
a288	<pre> f43: Your call is being answered by AUDIX. NAME, f680: is busy. Sorry, you cannot leave a message now because this user's mailbox is full. </pre>
a289	<pre> # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(2) is used for Call Answer Disable/Enable Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (VERSION > 2) THEN #INTUITY 3.0 a1178(NUMBER,NUMBER(2),NUMBER(3),NAME) ELSE IF (NUMBER == 0) THEN f43: Your call is being answered by AUDIX. NAME, f44: is not available. To leave a message, wait for the tone. ENDIF, IF (NUMBER == 1) THEN f71: To leave a message, wait for the tone. ENDIF, IF (NUMBER == 2) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> NAME, f44: is not available. To leave a message, wait for the tone. ENDIF ENDIF </pre>
a290	<pre> # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(2) is used for Call Answer Disable/Enable Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (VERSION > 2) THEN #INTUITY 3.0 a1177(NUMBER,NUMBER(2),NUMBER(3),NAME) ELSE IF (NUMBER == 0) THEN f43: Your call is being answered by AUDIX. NAME, f45: is busy. To leave a message, wait for the tone. ENDIF, IF (NUMBER == 1) THEN f71: To leave a message, wait for the tone. ENDIF, IF (NUMBER == 2) THEN NAME, f45: is busy. To leave a message, wait for the tone. ENDIF ENDIF ENDIF </pre>
a291	<pre> # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(2) is used for Call Answer Disable/Enable Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (VERSION > 2) THEN #INTUITY 3.0 a1175(NUMBER,NUMBER(2),NUMBER(3),NAME) ELSE IF (NUMBER == 0) THEN f43: Your call is being answered by AUDIX. NAME, f45: is busy. To leave a message, wait for the tone. ENDIF, IF (NUMBER == 1) THEN f71: To leave a message, wait for the tone. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ENDIF, IF (NUMBER == 2) THEN NAME, f45: is busy. To leave a message, wait for the tone. ENDIF, f112: Otherwise, for assistance, press zero now. ENDIF </pre>
a292	<pre> # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(2) is used for Call Answer Disable/Enable Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (VERSION > 2) THEN #INTUITY 3.0 a1176(NUMBER,NUMBER(2),NUMBER(3),NAME) ELSE IF (NUMBER == 0) THEN f43: Your call is being answered by AUDIX. NAME, f44: is not available. To leave a message, wait for the tone. ENDIF, IF (NUMBER == 1) THEN f71: To leave a message, wait for the tone. ENDIF, IF (NUMBER == 2) THEN NAME, f44: is not available. To leave a message, wait for the tone. ENDIF, f112: Otherwise, for assistance, press zero now. ENDIF </pre>
a293	<pre> f43: Your call is being answered by AUDIX. NAME, f679: is not available. Sorry, you cannot leave a message now because this user's mailbox is full. </pre>
a294	<pre> f156: Maximum length recorded. </pre>
a295	<pre> f50: Call NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER) </pre>
a296	<pre> f50: Call f262: received TIME,DATE,a873(NUMBER) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a297	<pre># VERSION > 2 is INTUITY FAX feature. FAX enabled NUMBER == 1, # FAX not enable NUMBER == 0 IF (VERSION > 2) THEN # INTUITY 3.0 f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. IF (NUMBER == 1) THEN #Fax enabled f1140: When finished you may attach a fax by pressing pound. ENDIF ELSE # 3.0 and 3.1 DEFINITY AUDIX f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. ENDIF</pre>
a298	<pre>f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. f274: Please make entry soon, or be disconnected.</pre>
a299	<pre>f511: If you do not have a touch tone phone, f380: Please wait.</pre>
a300	<pre>f794: To change identification to busy and no answer, press 2.</pre>
a301	<pre>f911: Enter buttons followed by pound.</pre>
a302	<pre>f912: Enter number followed by pound.</pre>
a303	<pre>f630: To change expiration date from DATE, f762: press 2.</pre>
a304	<pre>f795: To change to identification internal and external, press 1.</pre>
a305	<pre>f910: You are playing an announcement which need additional input before it can be played. f911: Enter buttons followed by pound.</pre>
a306	<pre>f910: You are playing an announcement which need additional input before it can be played. f912: Enter number followed by pound.</pre>
a307	<pre>f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n.</pre>
a308	<pre>f60: Changed.</pre>
a309	<pre>f565: Outcall canceled for new messages currently in mailbox.</pre>
a310	<pre># VERSION > 2 is INTUITY 3.0 FAX feature. # NUMBER = 1 is voice only msg, 2 Fax only msg, 3 Voice/Fax msg. # NUMBER(2) = 1 - fax is enabled, 0 - fax is disabled IF (VERSION > 2) THEN IF (NUMBER == 1) THEN f12: To re-record, press 1. After</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> recording, press 1 again. To delete, press star D. To playback, press 2-3. To approve as is, press pound. ELSE IF (NUMBER == 2) THEN IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f1007: To playback, press 2-3. f157: To approve as is, press the pound key. ELSE IF (NUMBER == 3) THEN f13: To record, press 1. After recording, press 1 again. IF(NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f1007: To playback, press 2-3. f157: To approve as is, press the pound key. ENDIF ENDIF ENDIF ELSE f12: To re-record, press 1. After recording, press 1 again. To delete, press star D. To playback, press 2-3. To approve as is, press pound. ENDIF </pre>
a311	f628: To deactivate message waiting notification, press 1.
a313	f931: Delivered Messages
a314	f801: To respond to this notification, press one. To delete, press star D. To skip, press pound.
a315	f24: To delete, press star D. f388: To skip, press the pound key.
a316	f77: Deleted.
a317	f77: Deleted. f173: Please enter new password f224: and pound sign.
a318	f77: Deleted. f22: To deliver now, press pound. To schedule delivery time enter hour, minutes, A or P, and pound sign.
a319	f706: To add entries, press 1. To review all entries, press 2. To review a specific entry, press 3. f913: If finished, press pound.
a320	f705: Directory contains NUMBER,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER==1) THEN f84: entry. ELSE f83: entries. ENDIF </pre>
a321	f724: Personal directory review completed.
a322	f140: Entry already deleted. To delete more entries, press star 1.
a324	f145: List has no entries.
a325	f538: Enter the ending hour, minutes, A or P, and pound sign.
a326	f472: To approve, press pound. To record from here, press 1. f24: To delete, press star D.
a327	f727: Enter alias and pound sign. f833: To delete current entry, press star D. f148: For extension addressing, press star A. f913: If finished, press pound.
a328	f727: Enter alias and pound sign. f833: To delete current entry, press star D. f58: For name addressing, press star A. f913: If finished, press pound.
a329	f727: Enter alias and pound sign. f913: If finished, press pound.
a330	f713: Enter next extension and pound sign. f708: If finished adding entries, press pound.
a331	f710: Enter next name and pound sign. f708: If finished adding entries, press pound.
a332	f85: Erased. f13: To record, press 1. After recording, press 1 again.
a333	f632: Expiration date will be DATE
a334	f86: extension BUTTONS, f552: is not authorized to receive messages.
a335	f86: extension BUTTONS, f552: is not authorized to receive messages. f553: You may enter another number
a336	f86: extension BUTTONS, f552: is not authorized to receive messages. f95: Please disconnect.
a337	f86: extension BUTTONS, f841: not defined
a338	f86: extension f202: not valid.
a339	<pre> f748: For external calls,... IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	NUMBER ENDIF, f745: active.
a340	f971: To send, press #.
a341	f971: To send, press #. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a342	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1125: Fax message to ELSE IF (NUMBER(2) == 3) THEN f1126: Voice and fax message to ELSE f258: Message to ENDIF ENDIF, f1117: all local subscribers. ELSE f739: Message sent to all local subscribers. ENDIF, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a343	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1119: Private fax message to ELSE IF (NUMBER(2) == 3) THEN f1120: Private voice and fax message to ELSE f696: Private message to ENDIF ENDIF, ENDIF, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1117: all local subscribers. ELSE f740: Private message sent to all local subscribers. ENDIF, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a344	<pre> # NUMBER = length of voice portion # NUMBER(2) = 1 for voice, 2 for fax and 3 for voice and # NUMBER(3) is length of fax portion in pages. # VERSION introduced in INTUITY 3.0 Fax featrue. VERSION # = 3. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN #Private, priority fax message to f1109: Private, priority fax message to ELSE IF (NUMBER(2) == 3) THEN # Private priority voice and fax message to f1110: Private, priority voice and fax message to ELSE #Private priority message to f695: Private, priority message to ENDIF ENDIF ELSE f741: Private, priority message sent to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a345	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1115: Priority fax message to ELSE IF (NUMBER(2) == 3) THEN f1116: Priority voice and fax message to ELSE f698: Priority message to ENDIF ENDIF ELSE f743: Priority message sent to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a346	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(2) = 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN # INTUITY 3.0 IF (NUMBER == 1) THEN #Voice only f21: To listen, press 0. ELSE IF (NUMBER == 2) THEN #FAX only IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF ELSE IF (NUMBER == 3) THEN #Voice and FAX f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> star 1. ENDIF ENDIF ENDIF ENDIF, f1039: To change or send again, press one. f388: To skip, press the pound key. ELSE # DEFINITY AUDIX 3.0, 3.1 f474: To listen, press 0. To change or send again, press 1. f388: To skip, press the pound key. ENDIF </pre>
a347	f932: Filed Messages
a348	<pre> f89: First message. f197: Cannot step back. f142: To listen to the header, press 3. </pre>
a349	<pre> f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name. </pre>
a350	<pre> f807: For busy... f2: and f812: no answer f814: calls. IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active. </pre>
a351	<pre> f807: For busy... f812: no answer f813: and out-of-hours f814: calls. IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active. </pre>
a352	<pre> f805: For internal... f2: and f810: external f814: calls. IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active. </pre>
a353	f805: For internal...

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f810: external f813: and out-of-hours f814: calls. IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active.</pre>
a354	<pre>f90: Enter fragment id f224: and pound sign.</pre>
a355	<pre># VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1062: Private broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1063: Private broadcast voice and fax message from ELSE f684: Private, broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f684: Private, broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER) ENDIF</pre>
a356	<pre># VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1062: Private broadcast fax message from ELSE IF (NUMBER(2)==3)</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN f1063: Private broadcast voice and fax message from ELSE f684: Private, broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f684: Private, broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a357	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1062: Private broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1063: Private broadcast voice and fax message from ELSE f684: Private, broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f684: Private, broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION ENDIF </pre>
a358	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1062: Private broadcast fax message from ELSE IF (NUMBER(2)==3) THEN f1063: Private broadcast voice and fax message from ELSE f684: Private, broadcast message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ELSE f684: Private, broadcast message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a360	f715: Cannot add new entries because your directory is full.
a361	f715: Cannot add new entries because your directory is full. NAMEEXT, f722: was not added to your personal directory.
a362	f93: You have no personal greeting, system greeting used.
a364	f243: Rewound.
a365	f754: Greeting NUMBER, f771: approved and active f823: ...for all calls
a366	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f2: and f812: no answer f814: calls.
a367	f754: Greeting NUMBER,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f771: approved and active f827: ...for busy f813: and out-of-hours f814: calls.
a368	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f814: calls.
a369	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a370	f754: Greeting NUMBER, f771: approved and active f826: ...for external f813: and out-of-hours f814: calls.
a371	f754: Greeting NUMBER, f771: approved and active f826: ...for external f814: calls.
a372	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f2: and f810: external f814: calls.
a373	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f813: and out-of-hours f814: calls.
a374	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f814: calls.
a375	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a376	f754: Greeting NUMBER, f771: approved and active f828: ...for no answer f813: and out-of-hours f814: calls.
a377	f754: Greeting

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	NUMBER, f771: approved and active f828: ...for no answer f814: calls.
a378	f754: Greeting NUMBER, f771: approved and active f829: ...for out-of-hours f814: calls.
a379	f754: Greeting NUMBER, f74: deleted.
a380	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f823: ...for all calls
a381	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f2: and f812: no answer f814: calls.
a382	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f813: and out-of-hours f814: calls.
a383	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f814: calls.
a384	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a385	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f826: ...for external f813: and out-of-hours f814: calls.
a386	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f826: ...for external

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f814: calls.
a387	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f2: and f810: external f814: calls.
a388	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f813: and out-of-hours f814: calls.
a389	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f814: calls.
a390	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a391	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f828: ...for no answer f813: and out-of-hours f814: calls.
a392	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f828: ...for no answer f814: calls.
a393	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f829: ...for out-of-hours f814: calls.
a394	f754: Greeting NUMBER, f214: Approved.
a395	f754: Greeting NUMBER, f755: not recorded.
a396	f754: Greeting NUMBER, f765: recorded, but not active
a397	f754: Greeting

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	NUMBER, f770: recorded and active f823: ...for all calls
a398	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f2: and f812: no answer f814: calls.
a399	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f813: and out-of-hours f814: calls.
a400	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f814: calls.
a401	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a402	f754: Greeting NUMBER, f770: recorded and active f826: ...for external f813: and out-of-hours f814: calls.
a403	f754: Greeting NUMBER, f770: recorded and active f826: ...for external f814: calls.
a404	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f2: and f810: external f814: calls.
a405	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f813: and out-of-hours f814: calls.
a406	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f814: calls.
a407	f754: Greeting

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	NUMBER, f770: recorded and active f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a408	f754: Greeting NUMBER, f770: recorded and active f828: ...for no answer f813: and out-of-hours f814: calls.
a409	f754: Greeting NUMBER, f770: recorded and active f828: ...for no answer f814: calls.
a410	f754: Greeting NUMBER, f770: recorded and active f829: ...for out-of-hours f814: calls.
a411	f754: Greeting NUMBER, f745: active. f823: ...for all calls
a412	f754: Greeting NUMBER, f745: active. f827: ...for busy f2: and f812: no answer f814: calls.
a413	f754: Greeting NUMBER, f745: active. f827: ...for busy f813: and out-of-hours f814: calls.
a414	f754: Greeting NUMBER, f745: active. f827: ...for busy f814: calls.
a415	f754: Greeting NUMBER, f745: active. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a416	f754: Greeting NUMBER, f745: active. f826: ...for external f813: and out-of-hours f814: calls.
a417	f754: Greeting NUMBER,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f745: active. f826: ...for external f814: calls.
a418	f754: Greeting NUMBER, f745: active. f825: ...for internal f2: and f810: external f814: calls.
a419	f754: Greeting NUMBER, f745: active. f825: ...for internal f813: and out-of-hours f814: calls.
a420	f754: Greeting NUMBER, f745: active. f825: ...for internal f814: calls.
a421	f754: Greeting NUMBER, f745: active. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a422	f754: Greeting NUMBER, f745: active. f828: ...for no answer f813: and out-of-hours f814: calls.
a423	f754: Greeting NUMBER, f745: active. f828: ...for no answer f814: calls.
a424	f754: Greeting NUMBER, f745: active. f829: ...for out-of-hours f814: calls.
a425	f752: To listen to a greeting, press 0. To create, change, or delete a greeting, press 1. To scan all your greetings, press 2. To activate a greeting, press 3. To administer call types, press 4. If finished, press pound.
a426	f756: To listen to greeting NUMBER, f772: again f760: press 0.
a427	f756: To listen to greeting NUMBER, f760: press 0.
a428	f753: Enter greeting number.
a429	f757: To re-record, press 1.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f24: To delete, press star D. f913: If finished, press pound.
a430	f757: To re-record, press 1. f759: To review status, press 2. f24: To delete, press star D. f913: If finished, press pound.
a431	f88: Cannot use the guest password f173: Please enter new password f224: and pound sign.
a432	f788: To identify calls as out-of-hours, press 3.
a433	f747: For internal calls,... IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active.
a434	f737: Login announcement will be interruptible.
a435	f136: Line busy.
a436	f149: All circuits busy.
a437	f99: Invalid announcement.
a438	f637: Invalid date.
a439	f637: Invalid date. DATE, f678: is past the expiration date, please reschedule.
a440	f637: Invalid date. DATE, f638: is prior to delivery date, please re-schedule.
a441	f101: Invalid fragment.
a442	f10: That is not a valid machine voice ID.
a443	f579: Password must be NUMBER, f81: digits. f173: Please enter new password f224: and pound sign.
a444	f579: Password must be NUMBER, f211: to fifteen digits f173: Please enter new password f224: and pound sign.
a445	f102: That is not a valid extension.
a446	f128: To request another transfer, press star T. f129: or leave a message for NAME
a447	f104: Message delivered, cannot listen to a delivered message.
a448	f492: Owner erased.
a449	f110: list BUTTONS
a450	f110: list BUTTONS, f142: To listen to the header, press 3.
a451	f110: list BUTTONS,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f65: contains NUMBER, IF (NUMBER<=1) THEN f84: entry. ELSE f83: entries. ENDIF</pre>
a452	<pre>f110: list BUTTONS, f65: contains NUMBER, IF (NUMBER<=1) THEN f159: member. ELSE f150: members. ENDIF</pre>
a453	<pre>f110: list BUTTONS, f74: deleted.</pre>
a454	<pre>f110: list BUTTONS, f197: Cannot step back. f142: To listen to the header, press 3.</pre>
a455	<pre>f110: list BUTTONS, f485: has NUMBER, IF (NUMBER<=1) THEN f159: member. ELSE f150: members. ENDIF, f15: and is f226: private</pre>
a456	<pre>f110: list BUTTONS, f485: has NUMBER, IF (NUMBER<=1) THEN f159: member. ELSE f150: members. ENDIF, f15: and is f227: public</pre>
a457	<pre>f110: list BUTTONS, f226: private f61: To modify status, press Y for yes or N for no.</pre>
a458	<pre>f110: list BUTTONS, f227: public</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f61: To modify status, press Y for yes or N for no.
a459	f110: list BUTTONS, f74: deleted. f130: because there were no entries.
a460	f110: list BUTTONS, f120: too large to include. f132: You can store your list as is by pressing star pound or add up to NUMBER, f139: additional members,
a462	f110: list BUTTONS, f120: too large to include. f134: You can store your list or delete members, but you cannot add members.
a463	f110: list BUTTONS, f120: too large to include. f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.
a465	f110: list BUTTONS, f208: is not a public list.
a466	f110: list BUTTONS, f202: not valid. f498: Please enter a new list id f224: and pound sign.
a467	f110: list f185: not found.
a468	f110: list f185: not found. f295: To re-enter list, press star L.
a469	f110: list BUTTONS, f219: owned by NAME, f65: contains NUMBER, f150: members.
a470	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f132: You can store your list as is by pressing star pound or add up to NUMBER, f139: additional members,
a471	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f134: You can store your list or delete members, but you cannot add members.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a472	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.
a473	f110: list BUTTONS, f219: owned by NAME, f74: deleted.
a474	f110: list BUTTONS, f219: owned by NAME, f208: is not a public list.
a476	f124: No more list space. f970: To continue reviewing, press 3. To delete an entry, press star D. If finished reviewing, press pound.
a477	f110: list BUTTONS, f219: owned by NAME, f208: is not a public list. f295: To re-enter list, press star L.
a478	f111: Please enter list id f224: and pound sign.
a479	f141: No more lists.
a480	f124: No more list space. f133: To continue reviewing, press 3. To delete an entry, press star D. If finished reviewing, press star pound.
a481	f116: List is full. f133: To continue reviewing, press 3. To delete an entry, press star D. If finished reviewing, press star pound.
a482	f116: List is full. f349: To approve list as is, press pound. f241: To review list, press star 1.
a483	f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.
a484	f113: You already have a list BUTTONS, f114: To replace list, re-enter id and pound sign. To create a new list, enter new list id f224: and pound sign.
a485	f154: Cannot create new list, you have maximum lists allowed. To select lists to be deleted, press 5-1-2 and follow instructions.
a486	f155: Cannot create new list, total number of members in all your lists equals maximum allowed.
a487	f122: List space nearly full. You may enter NUMBER, f123: new members.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a488	f468: To continue playing, press 3.
a489	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER)
a490	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2)
a491	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION
a492	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2)
a493	f697: Login announcement to all local subscribers IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF
a494	f656: For login announcement options, press star M.
a495	f624: Login announcement.
a496	f100: Invalid Entry. f96: For help, press star H.
a497	f364: enter owner's extension f224: and pound sign. f471: If it's your list, press pound.
a498	f470: Enter owner's last name f224: and pound sign. f471: If it's your list, press pound.
a501	f240: To skip, press pound. To listen, press 0. f24: To delete, press star D.
a502	f14: To make private, press 1. To make public, press 2.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a503	f704: To create lists, press 1. To scan lists, press 2. To review and modify lists, press 3.
a504	# VERSION > 2 introduced in INTUITY 3.0 # Call anser disabled/enabled feature - XEROX IF (VERSION > 2) THEN # INTUITY 3.0 IF (NUMBER == 1) THEN NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f82: Please leave a message for NAME ENDIF ELSE #DEFINITY AUDIX 3.1 and INTUITY 2.0 f82: Please leave a message for NAME ENDIF
a505	f152: Leave Word Calling from NAME, f262: received TIME,DATE
a506	f152: Leave Word Calling from NAME, f262: received TIME,DATE, f86: extension BUTTONS
a507	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1-voice only, 2-fax only, 3-voice and fax. # NUMBER(2) - 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN IF (NUMBER == 1) THEN f474: To listen, press 0. To change or send again, press 1. f24: To delete, press star D. f388: To skip, press the pound key. ELSE IF (NUMBER == 2) THEN IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f24: To delete, press star D. f388: To skip, press the pound key.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE IF (NUMBER == 3) THEN f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f24: To delete, press star D. f388: To skip, press the pound key. ENDIF ENDIF ELSE f474: To listen, press 0. To change or send again, press 1. f24: To delete, press star D. f388: To skip, press the pound key. ENDIF </pre>
a508	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER is 1 if prompting to change, 0 if not. # NUMBER(2) is 1 is fax enabled 0 if fax disabled. IF (VERSION > 2) THEN #INTUITY 3.0 IF (NUMBER == 1) THEN # Prompt to change. f30: To change, press 1. ENDIF, IF (NUMBER(2) == 1) THEN # FAX enabled. f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. ELSE #Definity Audix 3.0 and 3.1 f30: To change, press 1. f24: To delete, press star D. f388: To skip, press the pound key. ENDIF </pre>
a509	<pre> f6: Enter machine voice ID. f224: and pound sign. </pre>
a510	<pre> f153: Maximum length recorded. To re-record, press 2- 1. To approve as is, press pound. </pre>
a511	<pre> f125: Must be six or fewer numerals. f111: Please enter list id f224: and pound sign. </pre>
a512	<pre> f570: Recorded name too long </pre>
a513	<pre> f156: Maximum length recorded. f157: To approve as is, press the pound key. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a514	f582: AUDIX passwords must now be at least NUMBER, f81: digits. f593: Please choose a new password of NUMBER(2), f588: or more digits. f173: Please enter new password f224: and pound sign.
a515	f614: To make broadcast, press 8.
a516	f615: To make a login announcement, press 9.
a517	f633: To make non-interruptible, press 1.
a518	f613: To make priority, press 2.
a519	f612: To make private, press 1.
a520	f386: Cannot change a delivered message.
a521	f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign.
a522	f777: Cannot listen to system greeting.
a523	f778: Cannot modify system greeting.
a524	f780: Personal greetings review completed.
a525	f781: To skip to the next greeting, press the pound sign. f756: To listen to greeting NUMBER, f760: press 0. f24: To delete, press star D. f707: If finished, press star pound.
a527	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(2) = 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN f165: Returned to getting messages. IF (NUMBER == 1) THEN f21: To listen, press 0. f24: To delete, press star D. f388: To skip, press the pound key. ELSE IF (NUMBER == 2) THEN IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. ELSE f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. ENDIF ENDIF

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ENDIF ELSE f165: Returned to getting messages. f21: To listen, press 0. f24: To delete, press star D. f388: To skip, press the pound key. ENDIF </pre>
a528	f91: At end.
a529	f844: End of message.
a530	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(2) = 1 - fax enabled, 0 fax disabled IF (VERSION > 2) THEN f165: Returned to getting messages. # INTUITY 3.0 IF (NUMBER == 1) THEN #Voice only f21: To listen, press 0. f255: To delete this message, press star D. ELSE IF (NUMBER == 2) THEN #FAX only IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f255: To delete this message, press star D. ELSE IF (NUMBER == 3) THEN #Voice and FAX f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f255: To delete this message, press star D. ENDIF ENDIF ENDIF, f388: To skip, press the pound key. ELSE # DEFINITY AUDIX 3.0, 3.1 f165: Returned to getting messages. f21: To listen, press 0. f255: To delete this message, press star D. f388: To skip, press the pound key. ENDIF </pre>
a531	f166: At end. To playback, press 2-3.
a532	f473: filed

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a533	f167: To approve, press pound. To record from here, press 1. To playback, press 2-3.
a534	f170: Delivery scheduled
a535	f170: Delivery scheduled TIME,DATE, f66: If correct, press pound. If not, press star D and re-enter time.
a536	f631: Message waiting notification activated.
a537	f198: Partial name deleted.
a538	f603: You also have f34: Electronic Text f168: messages.
a539	f172: You have new f343: Leave word calling f168: messages.
a540	f603: You also have f343: Leave word calling f2: and f34: Electronic Text f168: messages.
a541	f603: You also have f343: Leave word calling f2: and f342: Electronic document communication f168: messages.
a542	f172: You have new f343: Leave word calling f2: and f342: Electronic document communication f168: messages.
a543	f603: You also have f343: Leave word calling f2: and f344: Message Center Service f168: messages.
a544	f172: You have new f343: Leave word calling f2: and f344: Message Center Service f168: messages.
a545	f603: You also have f343: Leave word calling f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a546	f172: You have new f343: Leave word calling f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a548	f172: You have new f34: Electronic Text f168: messages.
a549	f603: You also have f342: Electronic document communication f168: messages.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a550	f172: You have new f342: Electronic document communication f168: messages.
a551	f603: You also have f344: Message Center Service f168: messages.
a552	f172: You have new f344: Message Center Service f168: messages.
a553	f603: You also have f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a554	f172: You have new f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a555	f603: You also have f343: Leave word calling f168: messages.
a556	f928: New Messages
a557	f600: new Broadcast messages.
a558	f845: Next message.
a559	f105: To restart at the activity menu, press star R. f67: To create another list, f111: Please enter list id f224: and pound sign.
a560	f830: You must approve your recording. f167: To approve, press pound. To record from here, press 1. To playback, press 2-3.
a561	f53: Message deleted, no delivery will occur.
a562	f180: Nothing to approve.
a563	f850: Broadcast and Login Message services are not available.
a564	f636: Login announcement will be non-interruptible.
a565	f842: Announcement not recorded. Try again later. f95: Please disconnect.
a566	f203: No room in your mailbox for a recording. f62: Please delete unneeded messages.
a569	f215: No room to retain a copy. f62: Please delete unneeded messages.
a570	f1443: Voice filesystem is out of space. f1444: Please contact the administrator.
a571	f207: Message too long to add comment. To record a new message, press star R-1.
a572	f209: Cannot modify another subscriber's list.
a573	f92: Nothing to advance.
a574	f177: Cannot listen to a delivered message.
a575	f178: No addressees identified.
a576	f178: No addressees identified. f74: deleted.
a577	f169: Admin version not specified, please do so using administrator's terminal.
a579	f750: For no answer calls,... IF (NUMBER==0) THEN

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active.
a581	f180: Nothing to approve. f13: To record, press 1. After recording, press 1 again.
a582	f548: You have no attendant menu.
a583	f609: No room to save Broadcast message so it will be retained in the new message category.
a584	f186: To record messages, press 1. To get messages, press 2. To check your outgoing messages, press 4.
a585	f182: Nothing to delete.
a586	f182: Nothing to delete. f173: Please enter new password f224: and pound sign.
a587	f714: Directory has no entries.
a589	f184: Nothing to erase. f13: To record, press 1. After recording, press 1 again.
a590	f575: Cannot forward a private message
a592	f188: Passwords do not match. Please re-enter new password f224: and pound sign.
a593	f189: You have no mailbox. f272: Contact administrator for help.
a594	f190: Message delivered, you cannot change it now.
a595	f191: No more messages.
a596	f779: No greetings recorded.
a597	f192: No messages.
a598	f193: No name recorded.
a599	f193: No name recorded. f608: At the tone, please speak your name. After speaking your name, press 1.
a600	f194: No new messages.
a601	f509: System not administered for outcalling.
a603	f49: No operator defined.
a604	f196: You have no personal greeting.
a605	f199: Nothing to rewind.
a606	f199: Nothing to rewind. f256: At beginning. To re-record, press 1. To playback, press 2-3.
a607	f199: Nothing to rewind. f142: To listen to the header, press 3. f143: To step back again, press 2.
a608	f3: No new remote subscribers can be addressed.
a609	f200: No time entered, nothing to delete. f22: To deliver now, press pound. To schedule delivery time enter hour, minutes, A or P, and pound sign.
a610	f571: Non-existent subscriber
a611	f232: Recording stopped. f180: Nothing to approve.
a612	f173: Please enter new password f224: and pound sign.
a613	f223: Please enter extension

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f224: and pound sign. f237: Or press star R.
a614	f510: Number f202: not valid.
a615	f510: Number f202: not valid. f95: Please disconnect.
a616	f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.
a617	f530: Outcalling f522: turned off to restart at the activity menu, press star R.
a618	f530: Outcalling f521: turned on f835: for all new messages
a619	f530: Outcalling f521: turned on f836: only for new priority messages
a620	f532: To change your outcalling phone number, press 1 and enter the number to be called followed by the pound sign. Anything you enter will be interpreted as a part of the called number. No global commands such as star H will be accepted at this time. IF (VERSION<2) THEN #Definity AUDIX 3.0 doesn't allow # signs in the middle of the #outcall number f557: In most cases, entering a star or pound as the first digit will result in the star or pound being outputted. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row. f560: If you are programming a number to call a pager that requires a pound sign termination, press y to hear further help. Otherwise, press n to return to outcalling administration. ELSE #Definity AUDIX 3.1 allows # signs in the middle of the #outcall number f1284: In all cases, entering a star or pound as the first digit will result in the star or pound being outputted. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row. f1285: If you are programming a number to call a pager that requires a pound sign in or at the end of the digit string, press y to hear further help. Otherwise, press n to return to outcalling administration. ENDIF
a621	f531: Enter outcalling number f224: and pound sign. f556: To exit, press star pound now.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a622	<pre> IF (VERSION<2) THEN #Definity AUDIX 3.0 doesn't allow # signs in the middle of the #outcall number f589: For pagers requiring a pound sign termination, start your number with a double pound sign. This will result in a single pound being outpulsed at the end of the digit string. Then, a star or pound in the next position will be interpreted as part of the outcalling number. f590: A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row. ELSE #Definity AUDIX 3.1 allows # signs in the middle of the #outcall number f1286: Wherever a pound sign is required in the digit string, enter star pound. For pagers requiring a pound sign termination, end your digit string with star pound pound. f1452: A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. f1287: If a pause is required before a pound sign, enter star star pound. f1471: Up to 60 characters may be entered. ENDIF </pre>
a623	<pre> f534: Your outcalling number is DIALSTR </pre>
a624	<pre> f544: Outcalling specified for f525: any time f526: subject to administrator restrictions </pre>
a625	<pre> f544: Outcalling specified for TIME, f524: to TIME(2), f526: subject to administrator restrictions </pre>
a626	<pre> f544: Outcalling specified for TIME, f524: to TIME(2), f526: subject to administrator restrictions f66: If correct, press pound. If not, press star D and re-enter time. </pre>
a627	<pre> f500: This is AUDIX. NAME, f172: You have new f168: messages. f551: To access your messages, f223: Please enter extension f224: and pound sign. f543: To avoid further notification of these messages, press star pound. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a628	f519: You are not authorized for outcalling.
a629	f520: Your outcalling number, DIALSTR, f522: turned off to restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n.
a630	f520: Your outcalling number, DIALSTR, f521: turned on f835: for all new messages f523: for f525: any time f526: subject to administrator restrictions f105: To restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n.
a631	f520: Your outcalling number, DIALSTR, f521: turned on f835: for all new messages f523: for TIME, f524: to TIME(2), f526: subject to administrator restrictions f105: To restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n.
a632	f520: Your outcalling number, DIALSTR, f521: turned on f836: only for new priority messages f523: for f525: any time f526: subject to administrator restrictions f105: To restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press y. To turn off, press n.
a633	f520: Your outcalling number, DIALSTR, f521: turned on f836: only for new priority messages f523: for TIME, f524: to TIME(2), f526: subject to administrator restrictions f105: To restart at the activity menu, press star R. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	press 3. f528: To turn on, press y. To turn off, press n.
a634	f837: To turn on Outcalling for all new messages, press 1. To turn on outcalling only for new priority messages, press 2.
a635	f929: Old Messages
a636	f840: Option f841: not defined
a637	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), IF (NUMBER==1) THEN f264: Message not delivered because mailbox was full. ELSE f265: Message not delivered because their mailboxes were full. ENDIF
a638	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f265: Message not delivered because their mailboxes were full. f689: Expiration time is TIME(3),DATE(3)
a639	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f98: Message not delivered due to transmission problems.
a640	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f98: Message not delivered due to transmission problems. f689: Expiration time is TIME(3),DATE(3)
a641	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f387: Message not delivered because recipient not found.
a642	f216: originally f259: scheduled for

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f387: Message not delivered because recipient not found. f689: Expiration time is TIME(3),DATE(3)
a643	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f584: Message not delivered because special feature denied on recipients machine.
a644	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f584: Message not delivered because special feature denied on recipients machine. f689: Expiration time is TIME(3),DATE(3)
a645	f751: For out-of-hours calls,... IF (NUMBER==0) THEN f776: the system greeting ELSE f754: Greeting NUMBER ENDIF, f745: active.
a647	f681: Sorry, cannot leave a message now because this user's mailbox is full.
a648	f214: Approved.
a649	f1: Someone is changing your greeting, please try again later.
a650	f607: Name cannot be saved at this time, please continue
a651	f720: Alias entered not followed by pound and not added to the directory.
a652	f719: Extension entered not followed by pound and not added to the directory.
a653	f718: Name entered not followed by pound and not added to the directory.
a654	f37: Extension entered not followed by pound f187: and not added to the list. f464: Enter extensions f224: and pound sign. f349: To approve list as is, press pound.
a655	f38: Name entered not followed by pound f187: and not added to the list. f118: Enter last name f224: and pound sign. f349: To approve list as is, press pound.
a656	f798: Prime time is TIME,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f524: to TIME(2)
a657	f798: Prime time is TIME, f524: to TIME(2), f788: To identify calls as out-of-hours, press 3. f789: Otherwise, press 4.
a658	f226: private f47: Call from NAME, f262: received TIME,DATE,a873(NUMBER)
a659	f226: private f47: Call from NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER)
a660	f226: private f50: Call NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER)
a661	f226: private f50: Call f262: received TIME,DATE,a873(NUMBER)
a662	f226: private f110: list
a663	# VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1068: Private fax message from ELSE IF (NUMBER(2)==3) THEN f1069: Private voice and fax message from ELSE f686: Private message from ENDIF ENDIF, NAME,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f686: Private message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER) ENDIF </pre>
a664	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1068: Private fax message from ELSE IF (NUMBER(2)==3) THEN f1069: Private voice and fax message from ELSE f686: Private message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f686: Private message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a665	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1068: Private fax message from ELSE IF (NUMBER(2)==3) THEN f1069: Private voice and fax message from ELSE f686: Private message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f686: Private message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION ENDIF </pre>
a666	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1068: Private fax message from ELSE IF (NUMBER(2)==3) THEN f1069: Private voice and fax message from ELSE f686: Private message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ELSE f686: Private message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	ENDIF
a667	f918: To re-schedule delivery, press 3.
a668	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1057: Priority fax message from ELSE IF (NUMBER(2)==3) THEN f1058: Priority voice and fax message from ELSE f690: Priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f690: Priority message from NAME, f262: received TIME,DATE,a873(NUMBER) ENDIF </pre>
a669	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1057: Priority fax message from ELSE IF (NUMBER(2)==3) THEN f1058: Priority voice and fax message from ELSE f690: Priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f690: Priority message from </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> NAME, f262: received TIME,DATE,a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a670	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1057: Priority fax message from ELSE IF (NUMBER(2)==3) THEN f1058: Priority voice and fax message from ELSE f690: Priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f690: Priority message from NAME, f262: received TIME,DATE,a873(NUMBER),EXTENSION ENDIF </pre>
a671	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1057: Priority fax message from ELSE IF (NUMBER(2)==3) THEN f1058: Priority voice and fax message from ELSE f690: Priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE, a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f689: Expiration time is TIME(2),DATE(2) ELSE f690: Priority message from NAME, f262: received TIME,DATE,a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a672	<pre> f919: To file a copy, press 4. </pre>
a673	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1115: Priority fax message to ELSE IF (NUMBER(2) == 3) THEN f1116: Priority voice and fax message to ELSE f698: Priority message to ENDIF ENDIF ELSE f698: Priority message to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a674	<pre> f227: public f110: list </pre>
a675	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1122: Private broadcast fax message to ELSE IF (NUMBER(2) == 3) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN f1123: Private broadcast voice and fax message to ELSE f1121: Private broadcast message to ENDIF ENDIF, f1117: all local subscribers. ELSE f694: Private, broadcast message to all local subscribers ENDIF, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a676	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1059: Private, priority fax message from ELSE IF (NUMBER(2)==3) THEN f1060: Private, priority voice and fax message from ELSE f685: Private, priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f685: Private, priority message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER) ENDIF </pre>
a677	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1059: Private, priority fax message from ELSE IF (NUMBER(2)==3) THEN f1060: Private, priority voice and fax message from ELSE f685: Private, priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE, a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f685: Private, priority message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a678	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1059: Private, priority fax message from ELSE IF (NUMBER(2)==3) THEN f1060: Private, priority voice and fax message from ELSE f685: Private, priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f685: Private, priority message from NAME, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION ENDIF </pre>
a679	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1059: Private, priority fax message from ELSE IF (NUMBER(2)==3) THEN f1060: Private, priority voice and fax message from ELSE f685: Private, priority message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ELSE f685: Private, priority message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a680	<pre> f242: Returned to the f57: accessed f164: category. f142: To listen to the header, press 3. </pre>
a681	<pre> f242: Returned to the f59: delivered f164: category. f142: To listen to the header, press 3. </pre>
a682	<pre> f242: Returned to the f473: filed f164: category. f142: To listen to the header, press 3. </pre>
a683	<pre> f242: Returned to the f63: new f164: category. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f142: To listen to the header, press 3.
a684	f242: Returned to the f64: old f164: category. f142: To listen to the header, press 3.
a685	f242: Returned to the f68: undeliverable f164: category. f142: To listen to the header, press 3.
a686	f242: Returned to the f69: undelivered f164: category. f142: To listen to the header, press 3.
a687	f242: Returned to the f70: unopened f164: category. f142: To listen to the header, press 3.
a688	f228: Record at the tone.
a689	f229: You will have up to NUMBER, f230: seconds to record.
a690	f604: As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1, and at the tone, please speak your name. After speaking your name, press 1 again.
a691	f232: Recording stopped.
a692	f232: Recording stopped. f193: No name recorded. f608: At the tone, please speak your name. After speaking your name, press 1.
a693	f486: To reply to sender by voice mail, press 1. f18: To forward with comment, press 2. f8: To record a new message, press 4.
a694	f127: Returned to previous activity. f96: For help, press star H.
a695	f19: To review from beginning, press star 1. If finished, press star pound.
a696	f147: Review completed.
a697	f147: Review completed. f569: To modify, press one. If finished, press star pound.
a698	f147: Review completed. f19: To review from beginning, press star 1. If finished, press star pound.
a699	f256: At beginning. To re-record, press 1. To playback, press 2-3.
a700	f619: To remove broadcast status, press 8.
a701	f620: To remove login announcement status, press 9.
a702	f635: To remove non-interruptible status, press 1.
a703	f796: To remove out-of-hours identification, press 4.
a704	f618: To remove priority status, press 2.
a705	f617: To remove private status, press 1.
a706	f244: Rewound to previous message. f142: To listen to the header, press 3.
a707	f802: Cannot send a message to the broadcast mailbox.
a708	f245: Please return call.
a709	f245: Please return call. f86: extension

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	BUTTONS
a710	f785: Same greeting used for all calls.
a711	f785: Same greeting used for all calls. f786: To identify calls as internal and external, press 1. f787: To identify calls as busy and no answer, press 2.
a712	f511: If you do not have a touch tone phone, f236: Try again f109: later. f514: otherwise f274: Please make entry soon, or be disconnected.
a713	f248: scheduled TIME,DATE, f249: To change delivery time, press star D; To approve, press pound.
a714	f250: To change delivery time, press star D.
a715	f22: To deliver now, press pound. To schedule delivery time enter hour, minutes, A or P, and pound sign.
a716	f629: Please enter month, day, and pound sign.
a717	f477: Press 1 to select NAME
a718	f905: <.5 second pause> f478: 2 to select NAME
a719	f905: <.5 second pause> f479: 3 to select NAME
a722	f23: To record messages, press 1. To get messages, press 2. To administer your greeting, press 3.
a723	f501: To record messages, press one. To get messages, press two. To administer attendant menu, press 3.
a724	f482: Press pound to select NAME, f483: or enter more characters f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a725	f482: Press pound to select NAME, f483: or enter more characters f224: and pound sign.
a726	f482: Press pound to select NAMEEXT, f483: or enter more characters f224: and pound sign. f235: To restart at the activity menu, press star R. To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	star star X.
a727	f257: To use personal greeting, press Y. To use system greeting, press N.
a728	f775: To record messages, press one. To get messages, press two. To administer personal greetings, press 3.
a729	f674: Due to sending restrictions, you cannot send messages to NAME
a730	f388: To skip, press the pound key.
a731	f626: To specify expiration date, press 2.
a732	f626: To specify expiration date, press 2. f634: To approve login announcement options, press pound.
a733	f243: Rewound. f142: To listen to the header, press 3. f143: To step back again, press 2.
a734	f537: Enter the starting hour, minutes, A or P, and pound sign.
a735	f466: created TIME,DATE
a736	f259: scheduled for TIME,DATE
a737	f259: scheduled for TIME,DATE, f689: Expiration time is TIME(2),DATE(2)
a738	f259: scheduled for TIME,DATE, f730: Message not delivered because the broadcast mailbox was not defined.
a739	f259: scheduled for TIME,DATE, f699: Message not delivered because another login announcement is active.
a740	f259: scheduled for TIME,DATE, f738: Message not delivered due to sending restrictions.
a741	f259: scheduled for TIME,DATE, f98: Message not delivered due to transmission problems.
a742	f259: scheduled for TIME,DATE, f387: Message not delivered because recipient not found.
a743	f259: scheduled for TIME,DATE, f584: Message not delivered because special feature denied on recipients machine.
a744	f259: scheduled for TIME,DATE, f264: Message not delivered because mailbox was full.
a745	f262: received

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	TIME,DATE
a746	f262: received TIME,DATE, f689: Expiration time is TIME(2),DATE(2)
a748	f920: To not file a copy, press 4.
a749	f472: To approve, press pound. To record from here, press 1. f468: To continue playing, press 3.
a750	f499: When finished recording, press # to approve, or 1 to edit your message.
a751	f475: To file a copy, press Y for yes or N for no.
a752	f977: Name not found.
a754	f270: subscriber id f202: not valid.
a755	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) is 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) is 0 for call answer options not allowed, 1 for call answer options # allowed. IF (VERSION > 2) THEN f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF ELSE f700: To administer mailing lists, press 1. To administer personal directory, press 2. f701: To change your password, press 4. ENDIF
a756	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) is 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) is 0 for call answer options not allowed, 1 for call answer options

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # allowed. IF (VERSION > 2) THEN f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. f702: To record your name, press 5. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF ELSE f700: To administer mailing lists, press 1. To administer personal directory, press 2. f701: To change your password, press 4. f702: To record your name, press 5. ENDIF </pre>
a757	<pre> f26: To record names, press 4. To play names, press 5. To record machine names, press 6. To play machine names, press 7. </pre>
a758	<pre> f539: The system allows outcalls from TIME, f524: to TIME(2) </pre>
a759	<pre> f18: To forward with comment, press 2. f8: To record a new message, press 4. f163: To call sender, press zero. </pre>
a760	<pre> f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f163: To call sender, press zero. </pre>
a761	<pre> f8: To record a new message, press 4. f163: To call sender, press zero. </pre>
a762	<pre> f274: Please make entry soon, or be disconnected. </pre>
a763	<pre> f96: For help, press star H. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. f274: Please make entry soon, or be disconnected. </pre>
a764	<pre> f533: Too many digits. </pre>
a765	<pre> f276: Time requested has passed, please re-schedule delivery. f22: To deliver now, press pound. To schedule delivery time enter hour, minutes, A or P, and pound sign. </pre>
a766	<pre> f275: Cannot get your messages now, due to multiple logins to your mailbox. f95: Please disconnect. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a767	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1109: Private, priority fax message to ELSE IF (NUMBER(2) == 3) THEN f1110: Private, priority voice and fax message to ELSE f695: Private, priority message to ENDIF ENDIF ELSE f695: Private, priority message to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a768	<pre> f486: To reply to sender by voice mail, press 1. f18: To forward with comment, press 2. f8: To record a new message, press 4. f163: To call sender, press zero. </pre>
a769	<pre> f128: To request another transfer, press star T. </pre>
a770	<pre> f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f251: To transfer using extension instead, press star A. </pre>
a771	<pre> f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f251: To transfer using extension instead, press star A. f335: When finished, press pound. </pre>
a772	<pre> f512: Your call is being transferred to an operator. </pre>
a773	<pre> f118: Enter last name f224: and pound sign. f251: To transfer using extension instead, press star </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	A.
a774	f118: Enter last name f224: and pound sign. f251: To transfer using extension instead, press star A. f335: When finished, press pound.
a775	f515: To be transferred to an operator, f380: Please wait.
a776	f933: Undeliverable Messages
a777	f934: Undelivered Messages
a778	f688: An undeliverable message was returned to your outgoing mailbox. To access your outgoing mailbox, press star R 4.
a779	f687: Undeliverable message notification received TIME,DATE
a780	f935: Unopened Messages
a781	f541: Up to NUMBER, f542: digits may be used.
a783	f766: To use this greeting for all calls, press 1. f913: If finished, press pound.
a784	f783: To activate another greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place. f784: To activate system greeting, enter zero. f913: If finished, press pound.
a785	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2.
a786	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2. f913: If finished, press pound.
a787	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2.
a788	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2. f913: If finished, press pound.
a789	f782: To activate a greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place. f784: To activate system greeting, enter zero. f913: If finished, press pound.
a790	f331: Personal greeting used.
a791	f797: To use same greeting for all calls, press 5. f913: If finished, press pound.
a792	f332: System greeting used.
a793	f332: System greeting used. f823: ...for all calls
a794	f332: System greeting used. f827: ...for busy f2: and f812: no answer f814: calls.
a795	f332: System greeting used. f827: ...for busy f813: and out-of-hours f814: calls.
a796	f332: System greeting used.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f827: ...for busy f814: calls.
a797	f332: System greeting used. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a798	f332: System greeting used. f826: ...for external f813: and out-of-hours f814: calls.
a799	f332: System greeting used. f826: ...for external f814: calls.
a800	f332: System greeting used. f825: ...for internal f2: and f810: external f814: calls.
a801	f332: System greeting used. f825: ...for internal f813: and out-of-hours f814: calls.
a802	f332: System greeting used. f825: ...for internal f814: calls.
a803	f332: System greeting used. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a804	f332: System greeting used. f828: ...for no answer f813: and out-of-hours f814: calls.
a805	f332: System greeting used. f828: ...for no answer f814: calls.
a806	f332: System greeting used. f829: ...for out-of-hours f814: calls.
a808	# VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1071: Fax message from ELSE IF (NUMBER(2)==3) THEN f1072: Voice and fax message from ELSE f281: Message from ENDIF

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)) ELSE f281: Message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER) ENDIF </pre>
a809	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1071: Fax message from ELSE IF (NUMBER(2)==3) THEN f1072: Voice and fax message from ELSE f281: Message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)), f689: Expiration time is TIME(2),DATE(2) ELSE f281: Message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>
a810	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN f1071: Fax message from ELSE IF (NUMBER(2)==3) THEN f1072: Voice and fax message from ELSE f281: Message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION ELSE f281: Message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION ENDIF </pre>
a811	<pre> # VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion # NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax. # NUMBER(3) is length of fax portion in pages. IF (VERSION > 2) THEN IF (NUMBER(2)==2) THEN f1071: Fax message from ELSE IF (NUMBER(2)==3) THEN f1072: Voice and fax message from ELSE f281: Message from ENDIF ENDIF, NAME, f262: received TIME,DATE, f905: <.5 second pause> a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ELSE f281: Message from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2) ENDIF </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a812	f87: This call is experiencing difficulties. f1007: To playback, press 2-3.
a813	f380: Please wait.
a814	f283: Your mailbox is more than NUMBER, f284: percent full. Please delete unneeded messages or greetings.
a815	f287: Welcome to AUDIX. f97: For help at any time, press star H.
a816	f179: Warning, if you do not supply an addressee list, message will be deleted immediately.
a817	f293: Nothing to playback.
a818	a902(NUMBER(1)),a903(NUMBER(2)),a904(NUMBER(1),NUMBER(2))
a819	TIME, f253: Please enter month, day f224: and pound sign.
a820	IF (NUMBER<=60) THEN (f390+NUMBER) ELSE IF (NUMBER<=100) THEN (f450+((NUMBER-60)/10)), IF (NUMBER%10>0) THEN (f390+(NUMBER%10)) ENDIF ELSE a901(NUMBER) ENDIF ENDIF
a821	f86: extension BUTTONS
a822	f20: Remote extension BUTTONS
a823	f463: star
a824	f462: pound
a825	f546: pause
a826	f277: To exit directory, press pound.
a827	f482: Press pound to select NAMEEXT, f483: or enter more characters
a828	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2. f773: To activate for out-of-hours calls, press 3. f913: If finished, press pound.
a829	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2. f773: To activate for out-of-hours calls, press 3. f913: If finished, press pound.
a830	f818: You have just recorded f754: Greeting

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	NUMBER
a831	f658: Message waiting notification is currently not active. f625: To activate message waiting notification, press 1. f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance. f626: To specify expiration date, press 2.
a832	f628: To deactivate message waiting notification, press 1. f626: To specify expiration date, press 2. f627: To approve broadcast options, press pound.
a833	f625: To activate message waiting notification, press 1. f626: To specify expiration date, press 2. f627: To approve broadcast options, press pound.
a834	f87: This call is experiencing difficulties. f236: Try again f109: later. f95: Please disconnect.
a836	f110: list BUTTONS, f142: To listen to the header, press 3. f143: To step back again, press 2.
a837	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == is 0 if no new fax, 1 if new fax is present in the mailbox. IF (VERSION > 2) THEN f846: You are selecting an option for Automatic Message Scan. f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3. IF (NUMBER == 1) THEN f1040: To print all new faxes, press 4. ENDIF ELSE f846: You are selecting an option for Automatic Message Scan. f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3. ENDIF
a838	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1125: Fax message to ELSE

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(2) == 3) THEN f1126: Voice and fax message to ELSE f258: Message to ENDIF ENDIF ELSE f258: Message to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a840	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1119: Private fax message to ELSE IF (NUMBER(2) == 3) THEN f1120: Private voice and fax message to ELSE f696: Private message to ENDIF ENDIF ELSE f742: Private message sent to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a841	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2) THEN IF (NUMBER(2) == 2) THEN f1119: Private fax message to ELSE IF (NUMBER(2) == 3) THEN f1132: Private voice and fax message to ELSE f696: Private message to ENDIF ENDIF ELSE f696: Private message to ENDIF, NAME, IF (NUMBER>0) THEN f2: and NUMBER, IF (NUMBER==1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a842	f647: the message will be private.
a843	f390: oh
a844	f391: one
a845	f392: two
a846	f393: three
a847	f394: four
a848	f395: five
a849	f396: six
a850	f397: seven
a851	f398: eight
a852	f399: nine
a853	f308: You are playing announcement fragments. f279: Enter announcement set and pound sign.
a854	f307: You are playing announcements. f279: Enter announcement set and pound sign.
a855	f900: Standard US English
a856	f901: Announcement set does not exist
a857	f902: Announcement set
a858	f909: Announcement BUTTONS, f906: <1.0 second pause>
a859	f910: You are playing an announcement which need additional input before it can be played. f832: Please enter extension and pound sign. f58: For name addressing, press star A.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a860	f910: You are playing an announcement which need additional input before it can be played. f710: Enter next name and pound sign. f148: For extension addressing, press star A.
a861	f910: You are playing an announcement which need additional input before it can be played. f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign.
a862	f383: Please enter hour, then two digits for minutes, then A for am or P for pm, and pound sign.
a863	f910: You are playing an announcement which need additional input before it can be played. f383: Please enter hour, then two digits for minutes, then A for am or P for pm, and pound sign.
a864	f914: not filed.
a865	f915: No options menu available.
a866	f226: private
a867	f969: You are choosing between announcement sets whose names match your entry. To indicate no announcement sets match, delete entry by pressing star D.
a868	f921: To make private, press 1. To send, press #.
a869	f922: To access the Delivery Options Menu, press # after recording your message.
a870	f923: Press # to approve your message and access the Delivery Options Menu
a871	f926: <error sound>
a872	f937: Sorry you are having difficulty. Please get help and try again later. f94: Good-bye.
a873	IF (NUMBER<100) THEN IF (NUMBER%10==0) THEN IF (NUMBER==0) THEN f585: Zero f924: seconds ELSE a820(NUMBER), f924: seconds ENDIF ELSE a972(NUMBER) ENDIF ELSE a820((NUMBER+30)/60), f925: minutes ENDIF
a874	f4: not private.
a875	f601: Priority
a876	f622: not Priority.
a877	f158: Transfer cannot be completed.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f236: Try again f109: later.
a878	f263: You are recording a subscriber name. f980: To record from here, press 1 f979: After recording, press 1 again
a879	f346: You are recording a machine name. f13: To record, press 1. After recording, press 1 again.
a880	f263: You are recording a subscriber name. f980: To record from here, press 1 f979: After recording, press 1 again f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a881	f346: You are recording a machine name. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a882	f73: You have NUMBER, f854: seconds to finish recording.
a883	f232: Recording stopped. f570: Recorded name too long f608: At the tone, please speak your name. After speaking your name, press 1.
a886	f978: unknown f861: AMIS f510: Number
a889	f25: List id not followed by pound. f498: Please enter a new list id f224: and pound sign.
a890	f37: Extension entered not followed by pound f364: enter owner's extension f224: and pound sign. f471: If it's your list, press pound.
a891	f38: Name entered not followed by pound f470: Enter owner's last name f224: and pound sign. f471: If it's your list, press pound.
a892	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1-voice only, 2-fax only, 3-voice and fax. # NUMBER(2) - 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN IF (NUMBER == 1) THEN f856: This is a recorded message from NAME,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f21: To listen, press 0. f24: To delete, press star D. ELSE IF (NUMBER == 2) THEN f1044: This is a fax message from NAME, IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. ELSE IF (NUMBER == 3) THEN f1045: This is a voice and fax message from NAME, f21: To listen, press 0. IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. ENDIF ENDIF ENDIF ELSE f856: This is a recorded message from NAME, f21: To listen, press 0. f24: To delete, press star D. ENDIF </pre>
a893	<pre> f856: This is a recorded message from NAME, f21: To listen, press 0. f24: To delete, press star D. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a894	<pre> f562: Enter the f855: remote AMIS mailbox id f224: and pound sign. </pre>
a895	<pre> f867: You are entering the f855: remote AMIS mailbox id f868: Mailbox id must be less than or equal to 16 digits. f833: To delete current entry, press star D. </pre>
a896	<pre> f259: scheduled for TIME,DATE, f862: It could not be delivered because the recipient appears to be a wrong number. </pre>
a897	<pre> f259: scheduled for TIME,DATE, f863: It could not be delivered after multiple attempts to deliver the message. </pre>
a898	<pre> f864: Automated call, please press 1 to disconnect. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a899	f865: Your number was dialed by mistake. We are sorry for this inconvenience. To prevent this from recurring, this call has been reported as a misdialed call.
a901	<pre> IF (NUMBER>1000) THEN a906(NUMBER) ELSE a820(NUMBER/100), f454: hundred IF (NUMBER%100>0) THEN a820(NUMBER%100) ENDIF ENDIF ENDIF </pre>
a902	<pre> IF (NUMBER==0) THEN a820(12) ELSE IF (NUMBER>12) THEN a820(NUMBER-12) ELSE a820(NUMBER) ENDIF ENDIF ENDIF </pre>
a903	<pre> IF (NUMBER>0) THEN IF (NUMBER<10) THEN f390: oh ENDIF, a820(NUMBER) ENDIF ENDIF </pre>
a904	<pre> IF (NUMBER>12) THEN f301: P. M. ELSE IF (NUMBER==12) THEN IF (NUMBER(2)==0) THEN f201: noon. ELSE f301: P. M. ENDIF ELSE IF (NUMBER==0&&NUMBER(2)==0) THEN f161: midnight. ELSE f300: A. M. ENDIF ENDIF ENDIF ENDIF </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a905	(f938 + (NUMBER - 1))
a906	<pre> IF (NUMBER(1)>1000000) THEN f456: million ELSE a820(NUMBER/1000), f455: thousand IF ((NUMBER%1000)>0) THEN a820(NUMBER%1000) ENDIF ENDIF ENDIF </pre>
a907	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 1-voice only, 2-fax only, 3-voice and fax. IF (VERSION > 2) THEN IF (NUMBER == 1) THEN f858: To replay, press 0. f24: To delete, press star D. ELSE IF (NUMBER == 2) THEN f1046: This is a fax message. f1047: To print f1012: Press START on your fax machine now. f24: To delete, press star D. ELSE IF (NUMBER == 3) THEN f858: To replay, press 0. f1047: To print f1012: Press START on your fax machine now. f24: To delete, press star D. ENDIF ENDIF ENDIF ELSE f858: To replay, press 0. f24: To delete, press star D. ENDIF </pre>
a908	<pre> f74: deleted. f95: Please disconnect. </pre>
a909	f859: Mailbox id not followed by pound.
a910	f860: Mailbox id not valid.
a911	f866: AMIS casual subscribers cannot be added to your list.
a912	<pre> f561: You are addressing your message. f285: To add a member, enter extension f224: and pound sign. f869: If the extension entered belongs to a casual AMIS subscriber, you will be prompted for a mailbox id. f868: Mailbox id must be less than or equal to 16 digits. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f328: To delete the previous entry, press star D. To add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star A.
a913	NAME, f75: To skip, press pound. To delete, press star D. f333: To add entries to the list or to change status of list, press 1.
a914	f9: star R not available.
a915	f861: AMIS BUTTONS, f86: extension BUTTONS(2)
a916	TIME
a917	f711: Alias BUTTONS, f712: defined for NAMEEXT
a918	DATE
a919	f617: To remove private status, press 1. f971: To send, press #.
a920	# announcement changed for Intuity MACH3 FAX Feature # VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature # NUMBER 0 is no message, 1 is message was left IF (VERSION > 2) THEN # Intuity 3.0 VERSION = 3 IF (NUMBER == 1) THEN f56: Thank you for leaving your message. ENDIF, f46: To access your mailbox, press star R. f291: To transfer to another extension, press star T. f973: If you are finished, please hang up, or press star, star X. ELSE # Definity Audix 3.1 VERSION = 2 f56: Thank you for leaving your message. f46: To access your mailbox, press star R. f291: To transfer to another extension, press star T. f973: If you are finished, please hang up, or press star, star X. ENDIF
a921	# announcement changed for Intuity MACH3 FAX Feature # VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature # NUMBER 0 is no message, 1 is message was left

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (VERSION > 2) THEN # Intuity 3.0 VERSION = 3 IF (NUMBER == 1) THEN f56: Thank you for leaving your message. ENDIF, f46: To access your mailbox, press star R. f291: To transfer to another extension, press star T. f972: To reach the covering extension, press zero. f973: If you are finished, please hang up, or press star, star X. ELSE # Definity Audix 3.1 VERSION = 2 f56: Thank you for leaving your message. f46: To access your mailbox, press star R. f291: To transfer to another extension, press star T. f972: To reach the covering extension, press zero. f973: If you are finished, please hang up, or press star, star X. ENDIF </pre>
a922	f974: Not broadcast.
a923	f975: Not login announcement.
a924	<pre> f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star H f377: To delete message, press star D. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. </pre>
a925	<pre> f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a926	<pre> f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D.</p>
a927	<p>f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D.</p>
a928	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER(3) - 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(4) - 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN f378: You are checking the status of your outgoing messages. # INTUITY 3.0 IF (NUMBER(3) == 1) THEN #Voice only f1462: To listen to the message, press 0. ELSE IF (NUMBER(3) == 2) THEN #FAX only IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #Voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF ENDIF, f1038: To re-record message before delivery, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ELSE # DEFINITY AUDIX 3.0, 3.1 f378: You are checking the status of your outgoing messages. f381: To listen to the message, press 0. To re- record message before delivery, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ENDIF </pre>
a929	<pre> # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER(3) == 1 if voice only, 2 if fax only, 3 if voice and fax. # NUMBER(4) - 1 - fax enabled, 0 - fax disabled IF (VERSION > 2) THEN f378: You are checking the status of your outgoing messages. # INTUITY 3.0 IF (NUMBER(3) == 1) THEN #Voice only f1462: To listen to the message, press 0. ELSE IF (NUMBER(3) == 2) THEN #FAX only IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #Voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF ENDIF, f1039: To change or send again, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f143: To step back again, press 2. f578: To skip to the next category, press star pound. IF (NUMBER(3) != 2) THEN f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ELSE # DEFINITY AUDIX 3.0, 3.1 f378: You are checking the status of your outgoing messages. f474: To listen, press 0. To change or send again, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ENDIF </pre>
a930	<pre> f378: You are checking the status of your outgoing messages. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f379: To delete status information, press star D. </pre>
a931	<pre> f674: Due to sending restrictions, you cannot send messages to f861: AMIS BUTTONS </pre>
a932	<pre> f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star A. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a933	<pre> f493: You are requesting a transfer. f562: Enter the NUMBER, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star A. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a934	f288: You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star A. f277: To exit directory, press pound. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a935	f322: You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star A. f277: To exit directory, press pound. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a936	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star A. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a937	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star A. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a938	f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a939	f357: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star D. To change to extension addressing and delete your entry, press star A. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.
a940	f482: Press pound to select NAME,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>f483: or enter more characters f224: and pound sign. f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a941	<p>f482: Press pound to select NAMEEXT, f483: or enter more characters f224: and pound sign. f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a942	<p>f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a943	<pre># VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. IF (NUMBER > 0) THEN f1004: To bypass voice recording and create a fax only message, press pound. ENDIF, f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>your message, press star D. To approve your message, press pound.</p> <p>f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.</p> <p>f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>ENDIF</p>
a944	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f516: To leave a message that will be delivered as soon as possible,</p> <p>f380: Please wait.</p>
a945	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f274: Please make entry soon, or be disconnected.</p>
a946	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f515: To be transferred to an operator,</p> <p>f380: Please wait.</p>
a947	<p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a948	<p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a949	<p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p>
a951	<p>f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.</p> <p>f117: To reach the covering extension, press star zero.</p> <p>f291: To transfer to another extension, press star T.</p> <p>f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X.</p> <p>f515: To be transferred to an operator,</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f380: Please wait.
a952	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. f516: To leave a message that will be delivered as soon as possible, f380: Please wait.
a953	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. f274: Please make entry soon, or be disconnected.
a954	f56: Thank you for leaving your message. f95: Please disconnect.
a955	f56: Thank you for leaving your message. f291: To transfer to another extension, press star T. f973: If you are finished, please hang up, or press star, star X.
a956	f56: Thank you for leaving your message. f291: To transfer to another extension, press star T. f972: To reach the covering extension, press zero. f973: If you are finished, please hang up, or press star, star X.
a957	f291: To transfer to another extension, press star T.
a958	f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T.
a959	f95: Please disconnect.
a960	f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a961	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0 IF (VERSION > 2) THEN f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. IF (NUMBER > 0) THEN f1004: To bypass voice recording and create a fax only message, press pound. ENDIF, f13: To record, press 1. After recording, press 1

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. ELSE f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star T. f80: To have system wait, press star W. If finished, please hang up or to disconnect AUDIX, press star star X. ENDIF </pre>
a962	f853: Messages skipped, retained as new.
a963	f477: Press 1 to select
a964	f905: <.5 second pause> f478: 2 to select
a965	f905: <.5 second pause> f479: 3 to select
a968	f96: For help, press star H.
a969	<pre> IF (NUMBER / 1000 > 12) THEN f99: Invalid announcement. ELSE IF (NUMBER < 1000) THEN f99: Invalid announcement. ELSE a973(NUMBER) ENDIF ENDIF, a971(NUMBER) </pre>
a970	f(NUMBER / 100), f(NUMBER % 100)

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a971	f((NUMBER/10)%100)
a972	<pre> IF (NUMBER<10) THEN f400: ten f924: seconds ELSE IF (NUMBER%10>=5) THEN a820((NUMBER+10)-(NUMBER%10)), f924: seconds ELSE a820((NUMBER)-(NUMBER%10)), f924: seconds ENDIF ENDIF </pre>
a973	<pre> IF (NUMBER % 10 == 2) THEN f((NUMBER / 1000) % 12) ELSE IF (NUMBER % 10 == 7) THEN IF (NUMBER / 1000 != 12) THEN f12: To re-record, press 1. After recording, press 1 again. To delete, press star D. To playback, press 2-3. To approve as is, press pound. + (NUMBER / 1000) ELSE f(NUMBER / 1000) ENDIF ELSE f99: Invalid announcement. ENDIF ENDIF </pre>
a974	<pre> f259: scheduled for TIME,DATE, f981: Message not delivered because it was longer than the 8 minute AMIS message limit. </pre>
a978	<pre> # New announcement introduced in INTUITY 3.0 Fax feature # NUMBER == the size of the fax message in number of pages f1104: Print request to... NAMEEXT </pre>
a979	<pre> # New announcement introduced in INTUITY 3.0 Fax feature f1032: Subscriber cannot receive fax. </pre>
a980	f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a981	f1020: No message to send.
a982	f1019: Cannot replace or modify an existing fax.
a983	f1015: Fax will not be included.
a984	f1014: Fax will be included.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a985	f971: To send, press #.
a986	f1018: Load your document into the FAX machine, To send, press pound.
a987	f1017: A login announcement must be voice only.
a988	f1008: To include a fax, press 5.
a989	f1009: To no longer include a fax, press 5.
a990	<pre> IF (NUMBER==0) THEN f499: When finished recording, press # to approve, or 1 to edit your message. ELSE f988: To send only a fax, press pound. f514: otherwise f499: When finished recording, press # to approve, or 1 to edit your message. ENDIF </pre>
a991	f1012: Press START on your fax machine now.
a992	<pre> # New announcement for FAX feature, introduced in INTUITY MACH 3.0 f108: You are recording a message. f1004: To bypass voice recording and create a fax only message, press pound. f13: To record, press 1. After recording, press 1 again. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. </pre>
a993	f1031: A fax must be addressed before it can be created.
a994	<pre> # New announcement introduced in 3.0 of Intuity. Fax Feature # NUMBER == default print destination exists IF (NUMBER > 0) THEN f1087: To print to destination... BUTTONS, f1088: press pound ENDIF, f1089: To specify destination, enter digits followed by the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f1090: To print on the fax machine from which you are calling, press star 6. </pre>
a995	<pre> # New announcement introduced in 3.0 of Intuity. Fax Feature # NUMBER == default print destination exists f1091: You are specifying where your documents will be printed IF (NUMBER > 0) THEN f1087: To print to destination... BUTTONS, f1088: press pound ELSE f1092: A default print destination has not been </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>assigned. f1093: To assign a default print destination press star R, 5-3.</p> <p>ENDIF, f1094: To specify a default destination, enter digits then press the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f1095: This destination will be used for the remainder of this call. When you hang up, your default destination will be restored. f1090: To print on the fax machine from which you are calling, press star 6. f1096: If you choose this option, the document will begin to print. You will not be able to access your mailbox while the document is printing. You will be able to call into your mailbox again after printing is complete.</p>
a996	<p># New announcement introduced in 3.0 of Intuity. Fax Feature f1097: Print scheduled.</p>
a997	<p># New announcement introduced in 3.0 of Intuity. Fax Feature f1092: A default print destination has not been assigned. f1094: To specify a default destination, enter digits then press the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f1090: To print on the fax machine from which you are calling, press star 6.</p>
a998	<p># New announcement introduced in 3.0 of Intuity. Fax Feature BUTTONS, f1098: To approve, press pound. f1099: Or re-enter print destination number and pound sign.</p>
a999	<p># New announcement introduced in 3.0 of Intuity. Fax Feature f1100: Invalid. BUTTONS, f1101: Re-enter print destination number and pound sign. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.></p>
a1000	<p># New announcement introduced in 3.0 of Intuity. Fax Feature f1102: Too many print requests, try again later.</p>
a1001	<p># New announcement introduced in 3.0 of Intuity. Fax Feature f1103: Fax extension for NAME</p>
a1002	<p># New announcement introduced in INTUITY 3.0 Fax feature f1035: Message delivered, cannot print a delivered</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	message.
a1003	# New announcement introduced in INTUITY 3.0 Fax feature f1033: Cannot print a delivered message.
a1004	# New announcement introduced in INTUITY 3.0 Fax feature f1034: Cannot get your messages now, due to an active print request.
a1005	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER: 0 - no new faxes, 1 - new faxes # NUMBER(2): 0 - only public faxes, 1 - only private faxes, 2 - both private # and public IF (NUMBER == 0) THEN f1041: There are no new faxes. ELSE IF (NUMBER(2) == 1) THEN f1042: Private fax messages will not be printed, no other faxes to print. ELSE IF (NUMBER(2) == 2) THEN f1043: Private fax messages will not be printed, print scheduled for all other faxes. ELSE f1097: Print scheduled. ENDIF ENDIF ENDIF
a1006	# New announcement introduced in INTUITY 3.0 Fax feature f1053: Fax not enabled for your mailbox, for help press star H.
a1007	# New announcement introduced in INTUITY 3.0 Fax feature f1056: System not administered for fax.
a1008	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER is 0 for no default destination, 1 for default destination # NUMBER(2) 0 for autoprt inactive, 1 for autoprt active # NUMBER(3) 0 for autodelete inactive, 1 for autodelete active IF (NUMBER==0) THEN f1092: A default print destination has not been assigned. ELSE f1061: Your default print destination is... BUTTONS, IF (NUMBER(2) == 1) THEN IF (NUMBER(3) == 1) THEN f1136: Autoprinting is turned on.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1139: Autodelition is turned on. ELSE f1136: Autoprinting is turned on. f1138: Autodeletion is turned off. ENDIF ELSE f1137: Autoprinting is turned off. ENDIF ENDIF, f105: To restart at the activity menu, press star R. f1075: To change the default print destination, press 1. IF (NUMBER(2) == 0) THEN f1076: To have your faxes printed automatically, press Y for Yes. ELSE f1077: To cancel automatic printing of your faxes, press N for no. f1078: To change autodeletion option, press 9. ENDIF </pre>
a1009	<pre> # New announcement for INTUITY 3.0 FAX feature. # NUMBER is number of fax pages. IF (NUMBER==0) THEN f585: Zero f1029: pages. ELSE a820(NUMBER), IF (NUMBER==1) THEN f1028: page. ELSE f1029: pages. ENDIF ENDIF </pre>
a1010	<pre> # New announcement for INTUITY 3.0 FAX feature. # NUMBER is number of seconds of voice in message. # NUMBER(2) == media type, 1-voice only, 2-fax only, 3- voice fax. # NUMBER(3) is length of pages of fax in message. IF (NUMBER(2)==1) THEN a873(NUMBER) ENDIF, IF (NUMBER(2)==2) THEN f905: <.5 second pause> a1009(NUMBER(3)) ENDIF, IF (NUMBER(2)==3) THEN a873(NUMBER), f905: <.5 second pause> a1009(NUMBER(3)) ENDIF </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a1011	<pre># New announcement introduced in INTUITY 3.0 Fax feature # NUMBER = fax page length # NUMBER(2) = 1 - fax enabled, 0 - fax disabled f1049: Fax of IF (NUMBER == 0) THEN f585: Zero f1029: pages. ELSE NUMBER, IF (NUMBER == 1) THEN f1028: page. ELSE f1029: pages. ENDIF ENDIF, IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key.</pre>
a1012	<pre># New announcement introduced in INTUITY 3.0 Fax feature # Number of pages for fax. # NUMBER(2), 0 fax is disabled, 1 fax is enabled # NUMBER(3), 0 forwarding is allowed, 1 forwarding is allowed f1050: Message does not contain voice. f1049: Fax of NUMBER, IF (NUMBER == 1) THEN f1028: page. ELSE f1029: pages. ENDIF, IF (NUMBER(3) == 0) THEN f252: To respond to this message, press 1. ELSE f234: To respond or forward, press 1. ENDIF, IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key.</pre>
a1013	<pre># New announcement introduced in INTUITY 3.0 Fax feature # Message does not contain fax. f1048: Nothing to print.</pre>
a1014	<pre># New announcement introduced in INTUITY 3.0 Fax feature f1051: Voice and fax message.</pre>
a1015	<pre># New announcement introduced in INTUITY 3.0 Fax feature</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f1079: Enter your default print destination followed by the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f556: To exit, press star pound now.
a1016	# New announcement introduced in INTUITY 3.0 Fax feature f1061: Your default print destination is... BUTTONS
a1017	# New announcement introduced in INTUITY 3.0 Fax feature f1080: Invalid destination.
a1018	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER is 0 for autoprt inactive, 1 for autoprt active f1075: To change the default print destination, press 1. IF (NUMBER == 0) THEN f1076: To have your faxes printed automatically, press Y for Yes. ELSE f1077: To cancel automatic printing of your faxes, press N for no. f1078: To change autodeletion option, press 9. ENDIF, f105: To restart at the activity menu, press star R.
a1019	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER: 0 for autoprt inactive, 1 for autoprt active IF (NUMBER == 1) THEN f1136: Autoprinting is turned on. ELSE f1137: Autoprinting is turned off. f1138: Autodeletion is turned off. ENDIF
a1020	# New announcement introduced in INTUITY 3.0 Fax feature f1081: After a fax only message is printed automatically, should it also be deleted from your mailbox? Press Y for yes or N for No. f105: To restart at the activity menu, press star R.
a1021	# New announcement introduced in INTUITY 3.0 Fax feature f1136: Autoprinting is turned on. f1139: Autodelition is turned on.
a1022	# New announcement introduced in INTUITY 3.0 Fax feature f1136: Autoprinting is turned on. f1138: Autodeletion is turned off.
a1023	# New announcement introduced in INTUITY 3.0 Fax feature f1083: You must enter a default print destination before autoprinting can be used.
a1024	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER: 0 no default number assigned, 1- default print number assigned.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(2): 0 autoprint off, 1-autoprint on. f1084: You are changing your fax print options. f1086: The default print destination is where documents are normally printed. f1085: To change or add default print destination, press 1. IF (NUMBER == 0) THEN f1135: A default print destination must be assigned before autoprinting can be used. ENDIF, IF (NUMBER(2) == 0) THEN f1076: To have your faxes printed automatically, press Y for Yes. ELSE f1077: To cancel automatic printing of your faxes, press N for no. ENDIF, f1124: When autoprinting is turned on, all non-private faxes that are received will automatically attempt to print at the default destination. IF (NUMBER(2) == 1) THEN f1078: To change autodeletion option, press 9. ENDIF </pre>
a1025	<pre> # New announcement introduced in INTUITY 3.0 Fax feature f1111: You are in the autodeletion menu. f1114: If autodeletion is turned on, fax only messages will be deleted after they are automatically printed. f1082: To turn on autodeletion, press Y. To turn off, press N. </pre>
a1026	<pre> # New announcement introduced in INTUITY 3.0 Fax feature f1118: You are specifying the default print destination for fax items. f1143: The default print destination should be set to the destination where you normally send your documents for printing. f1124: When autoprinting is turned on, all non-private faxes that are received will automatically attempt to print at the default destination. f1130: This is also used as the default print destination when scanning fax messages. f1133: It must be a valid call delivery number. f1134: To enter destination, enter digits followed by the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> </pre>
a1027	<pre> # New announcement introduced in INTUITY 3.0 # NUMBER(4) is 1 if fax enabled, 0 is fax disabled. # NUMBER(5) - 1 is voice only, 2 fax only, 3 voice and fax f252: To respond to this message, press 1. f24: To delete, press star D. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(5) != 1) THEN IF (NUMBER(4) == 1) THEN #Fax Enabled f1073: To print, press star 1. ENDIF ENDIF, f388: To skip, press the pound key. </pre>
a1028	<pre> # New announcement introduced in INTUITY 3.0 f1019: Cannot replace or modify an existing fax. </pre>
a1029	<pre> # New announcement for INTUITY 3.0 - XEROX ABR Feature. # # NUMBER == 0 Address Before Record is off. # NUMBER == 1 Address Before Record is on. IF (NUMBER == 1) THEN f1152: Address Before Record turned on. f1153: To turn off, press 1. ELSE f1154: Address Before Record turned off. f1155: To turn on, press 1. ENDIF </pre>
a1030	<pre> # New announcement for INTUITY 3.0 - XEROX ABR Feature. # # NUMBER == 0 Address Before Record is off. # NUMBER == 1 Address Before Record is on. IF (NUMBER == 1) THEN f1152: Address Before Record turned on. ELSE f1154: Address Before Record turned off. ENDIF </pre>
a1031	<pre> # New announcement for INTUITY 3.0 - XEROX ABR Feature. # If the subscriber tries to create a fax before addressing it. # The announcement states A fax must be addressed before it can be created. f1031: A fax must be addressed before it can be created. </pre>
a1032	<pre> # New announcement for INTUITY 3.0 - XEROX ABR Feature. # # NUMBER == 0 Address Before Record is off. # NUMBER == 1 Address Before Record is on. f1157: You are administering Addressing options. IF (NUMBER == 1) THEN f1152: Address Before Record turned on. f1153: To turn off, press 1. ELSE f1154: Address Before Record turned off. f1155: To turn on, press 1. ENDIF, f105: To restart at the activity menu, press star R. </pre>
a1033	<pre> # New announcement for INTUITY 3.0 - XEROX CAD Feature. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # # NUMBER == 0 Call Answer Disabled is off. # NUMBER == 1 Call Answer Disabled is on. IF (NUMBER == 0) THEN f1164: Call answer messages will be accepted. f1158: To prevent callers from leaving messages, press 1. ELSE f1159: Call answer messages will not be accepted. f1160: To allow callers to leave messages, press 1. ENDIF </pre>
a1034	<pre> # New announcement for INTUITY 3.0 - XEROX CAD Feature. # # NUMBER == 0 Call Answer Disabled is off. # NUMBER == 1 Call Answer Disabled is on. IF (NUMBER == 0) THEN f1164: Call answer messages will be accepted. ELSE f1159: Call answer messages will not be accepted. ENDIF </pre>
a1035	<pre> # New announcement for INTUITY 3.0 - XEROX CAD Feature. # # NUMBER == 0 Call Answer Disabled is off. # NUMBER == 1 Call Answer Disabled is on. f1161: You are administering Call Answer options. IF (NUMBER == 1) THEN f1164: Call answer messages will be accepted. f1158: To prevent callers from leaving messages, press 1. ELSE f1159: Call answer messages will not be accepted. f1160: To allow callers to leave messages, press 1. ENDIF, f105: To restart at the activity menu, press star R. </pre>
a1036	<pre> # New announcement introduced in 3.0 of Intuity. Fax Feature f1167: Only 25 faxes printed. </pre>
a1037	<pre> # New announcement introduced in INTUITY 3.0 f1049: Fax of IF (NUMBER==0) THEN f585: Zero f1029: pages. ELSE a820(NUMBER), IF (NUMBER == 1) THEN #Page f1028: page. ELSE #Pages f1029: pages. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ENDIF ENDIF </pre>
a1038	<pre> # New announcement introduced in INTUITY 3.0 # Call Answer Enable/Disable feature - XEROX f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. </pre>
a1039	<pre> # New announcement introduced in INTUITY 3.0 # Address Before Record feature - XEROX f1031: A fax must be addressed before it can be created. </pre>
a1067	<pre> f1278: We were unable to reach the paging service. </pre>
a1068	<pre> f1215: To try to reach NAME, IF (NUMBER == 0) THEN f1216: please press two now, or hold to leave a message. ELSE f1308: please press two now, followed by your PIN, or hold to leave a message. ENDIF </pre>
a1069	<pre> NAME, f1217: was not available at the number you called. To try to reach NAME, f1218: at an alternate number, please press two. To leave a voice mail message instead, press one. If you don't press anything, you will also be able to leave a message. </pre>
a1070	<pre> f1219: To review or change your reach options, press 7. </pre>
a1071	<pre> f1276: A reach attempt is about to be made. f1306: You will be put on hold while we dial the number where the person you were calling can be reached. If they answer, you will be connected with them. f1279: Please stay on the line as we try to reach NAME, f1277: This may take up to a873(NUMBER), f1280: Or, press 1 to leave a message. </pre>
a1072	<pre> f1221: Your reach number IF (NUMBER > 0) THEN DIALSTR ENDIF, IF (NUMBER(2) == 0) THEN f1223: is turned off ELSE f1222: is turned on ENDIF </pre>
a1073	<pre> f1226: To change reach number, press 1. f1227: To retrieve messages, press 2 f1228: To change call screening status, press 3. f96: For help, press star H. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f973: If you are finished, please hang up, or press star, star X.
a1074	<pre> f1221: Your reach number IF (NUMBER > 0) THEN DIALSTR ENDIF, IF (NUMBER(2) ==0) THEN f1223: is turned off ELSE f1222: is turned on ENDIF, f1229: When your reach number is turned on, incoming calls will attempt to be forwarded to it. IF (NUMBER(3) == 0) THEN f1225: To change reach number information, press 1. ELSE f1224: Call screening is turned on. ENDIF, f1232: When call screening is turned on, callers who are trying to contact you will need to enter a personal identification number, or PIN, that you have given them, before the call will be forwarded to your reach number or allow the caller to page you. IF (NUMBER(4) == 0) THEN f1231: Paging is turned off. ELSE f1230: Paging is turned on. ENDIF, f1220: When paging is turned on, callers who are unable to contact you at your reach number will have the option to transfer to your paging service. f1233: To change your reach number, press 1. IF (NUMBER(5) == 1) THEN f1227: To retrieve messages, press 2 ENDIF, f1228: To change call screening status, press 3. f1300: To review or change the personal identification numbers used by callers when you have call screening turned on, press 4. f1266: To change paging status, press 5. f1302: To hear this help message again, press star H. IF (NUMBER(5) == 1) THEN f973: If you are finished, please hang up, or press star, star X. ELSE f913: If finished, press pound. ENDIF </pre>
a1075	<pre> f1234: To turn your present reach number on, press pound. f1235: To turn your present reach number off, press </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>zero pound. f1236: To enter and turn-on a new reach number, enter that number, followed by the pound sign. f96: For help, press star H.</p>
a1076	<p>DIALSTR, f1237: is not a valid telephone number or speed dial code. f96: For help, press star H.</p>
a1077	<p>f1238: You are updating the status of your reach number. IF (NUMBER == 0) THEN f1242: You do not presently have a reach number. ELSE f1239: Your present reach number is DIALSTR, f1234: To turn your present reach number on, press pound. f1229: When your reach number is turned on, incoming calls will attempt to be forwarded to it. f1235: To turn your present reach number off, press zero pound. ENDIF, f1236: To enter and turn-on a new reach number, enter that number, followed by the pound sign. f1240: The number you enter may be a valid telephone number, entered as though you were dialing from your office phone. f1241: Or the number you enter may be a single-digit speed-dial code. The only valid speed-dial codes are the digits one through six. For help setting up or changing the speed-dial codes for this account, please contact your system administrator." f1284: In all cases, entering a star or pound as the first digit will result in the star or pound being outputted. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row. f1286: Wherever a pound sign is required in the digit string, enter star pound. For pagers requiring a pound sign termination, end your digit string with star pound pound. f1287: If a pause is required before a pound sign, enter star star pound. f1311: Up to 29 characters may be entered. f1312: To repeat this help, press *H *H.</p>
a1078	<p>f1243: To turn call screening on, press pound. f1244: To turn call screening off, press zero pound.</p>
a1079	<p>f1245: You are being prompted to turn call screening on or off. f1232: When call screening is turned on, callers who are trying to contact you will need to enter a personal identification number, or PIN, that you have given them, before the call will be forwarded to your reach number or allow the caller to page you.</p>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a1080	f84: entry. NUMBER, f1247: in your caller PIN list is BUTTONS, f1248: To skip to the next PIN, press pound. f1249: To delete this PIN, press star D. f1250: To add a new PIN, press 1. IF (NUMBER(2) == 0) THEN f707: If finished, press star pound. ENDIF, f96: For help, press star H.
a1081	f1251: You are reviewing your list of caller personal identification numbers. f1253: When call screening is turned on, callers will need to enter one of these PIN's in order to contact you or have you paged.
a1082	f1252: You are being prompted to add a caller personal identification number to your list. f1253: When call screening is turned on, callers will need to enter one of these PIN's in order to contact you or have you paged. f1254: Caller PIN's must contain between three and ten digits f1255: and cannot contain the star or pound characters.
a1083	f1257: Your list already contains the maximum number of caller PIN's. You must delete an existing PIN before adding a new one.
a1084	f1256: To add a caller PIN to your list, enter the PIN, followed by the pound sign. f707: If finished, press star pound.
a1085	f1258: Caller PIN BUTTONS, f1259: added to list
a1086	f1260: Duplicate entry. f1261: The caller PIN you just entered is already contained in your list. f1262: Please enter a different number.
a1087	f1254: Caller PIN's must contain between three and ten digits f1264: Caller PIN's cannot contain more than
a1088	f1220: When paging is turned on, callers who are unable to contact you at your reach number will have the option to transfer to your paging service.
a1089	IF (NUMBER ==0) THEN f1279: Please stay on the line as we try to reach NAME ELSE f1273: Please stay on the line. ENDIF, f1277: This may take up to a873(NUMBER(2))
a1090	IF (NUMBER == 0) THEN f1267: Incoming external call for NAME ENDIF,

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER > 0 && NUMBER < 4) THEN f1283: Incoming call for NAME, f857: IF (NUMBER == 1) THEN BUTTONS ENDIF, IF (NUMBER == 2) THEN NAME(2) ENDIF, IF (NUMBER == 3) THEN f0: <NULL fragment, 0.0 second pause> ENDIF ENDIF, IF (NUMBER != 3) THEN f1269: To speak with the calling party, please enter your password, followed by the pound sign. IF (NUMBER(2) == 1) THEN f907: <2.0 second pause> ENDIF ENDIF </pre>
a1091	<pre> f1270: This is an automatic system, trying to forward a call to NAME, f1271: A password must be entered to complete the call. f1272: Please enter the password, followed by the pound sign. </pre>
a1092	<pre> f1307: No PINs active. f96: For help, press star H. </pre>
a1093	<pre> f1274: Please enter your PIN now. IF (NUMBER > 0) THEN f112: Otherwise, for assistance, press zero now. ENDIF </pre>
a1094	<pre> f1213: You are being prompted whether you want to paging service of the person you were calling. </pre>
a1095	<pre> f0: <NULL fragment, 0.0 second pause> </pre>
a1096	<pre> f1275: Please re-enter the PIN or press 1 to leave a message. </pre>
a1097	<pre> f1281: To transfer to the paging service IF (NUMBER == 0) THEN f523: for NAME ENDIF, f1282: press two now or hold to leave a message. </pre>
a1098	<pre> f1214: You are being prompted to enter the caller PIN given to you by the person you were calling. This must be entered correctly before a reach or page attempt will be made. To leave a voice mail message instead, you may </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	press one.
a1101	IF (NUMBER == 0) THEN f1225: To change reach number information, press 1. ELSE f1224: Call screening is turned on. ENDIF
a1102	f1226: To change reach number, press 1. f1228: To change call screening status, press 3. f1297: To change personal identification numbers, press 4. f1266: To change paging status, press 5. f913: If finished, press pound.
a1103	IF (NUMBER == 0) THEN f1231: Paging is turned off. ELSE f1230: Paging is turned on. ENDIF
a1104	f1303: Your list of caller personal identification numbers contains IF (NUMBER > 0) THEN NUMBER ELSE f585: Zero ENDIF, IF (NUMBER == 1) THEN f84: entry. ELSE f83: entries. ENDIF
a1105	f43: Your call is being answered by AUDIX.
a1106	f1296: Your party was not available.
a1107	f1299: To change call screening status, press 3. f1301: To change your BPCS password, press 5.
a1108	f1246: You are being prompted to turn paging on or off.
a1109	f1263: Please enter more digits, or pound sign.
a1110	f1298: System not administered for reach service.
a1111	f1304: You are not authorized for reach service.
a1112	IF (NUMBER > 0) THEN f1305: PLease enter an outcalling option. To hear a list of options, press 0. ENDIF, IF (NUMBER(2) > 0) THEN f1219: To review or change your reach options, press 7. ENDIF, f105: To restart at the activity menu, press star R.
a1113	f1265: Caller PIN's cannot contain the star or pound characters.
a1114	f1309: For help, press *H again.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a1115	f1313: At the tone, please speak your name.
a1116	f1315: Begin speaking.
a1117	f1316: The calling party hung up. f95: Please disconnect.
a1121	f1404: To administer this greeting, press 1.
a1122	f1408: To administer this greeting, press 2. f105: To restart at the activity menu, press star R.
a1123	IF (NUMBER > 0) THEN f1405: To listen to your secondary greeting, press 0. f1409: To record your secondary greeting, press 1. f1402: To administer your primary greeting, press pound. ELSE f1406: To listen to your primary greeting, press 0. f1407: To record your primary greeting, press 1. f1410: To administer your secondary greeting, press pound. ENDIF, f105: To restart at the activity menu, press star R.
a1124	IF (NUMBER > 0) THEN f1405: To listen to your secondary greeting, press 0. ELSE f1406: To listen to your primary greeting, press 0. ENDIF, f757: To re-record, press 1. IF (NUMBER > 0) THEN f1412: To delete your secondary greeting, and use the system greeting, press star D . f1402: To administer your primary greeting, press pound. ELSE f1411: To delete your primary greeting, and use the system greeting press star D. f1410: To administer your secondary greeting, press pound. ENDIF, f105: To restart at the activity menu, press star R.
a1125	IF (NUMBER > 0) THEN f1414: Your new secondary greeting is now active. ELSE f1413: Your new primary greeting is now active. ENDIF
a1126	f1415: Recording deleted. IF (NUMBER > 0) THEN f1417: Your secondary greeting has not changed.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	ELSE f1416: Your primary greeting has not changed. ENDIF
a1127	f1400: For English press star one.
a1128	f1401: Your primary greeting is in
a1129	f0: <NULL fragment, 0.0 second pause>
a1130	f1403: Your secondary greeting is in
a1131	f0: <NULL fragment, 0.0 second pause>
a1132	f1420: Callers will hear the greeting and receive instructions in the primary language unless they press star-1, in which case they will hear the greeting and receive instructions in the secondary language.
a1133	IF (NUMBER > 0) THEN f1419: You are administering your secondary greeting. ELSE f1418: You are administering your primary greeting. ENDIF
a1134	f1430: The following message was restored.
a1135	f1431: No message to restore.
a1136	f1432: To undelete last deleted message, press star star U.
a1137	f913: If finished, press pound.
a1138	f1433: The return address for this message is not a valid extension.
a1139	f1434: To return to getting messages, press pound. f8: To record a new message, press 4.
a1140	f1434: To return to getting messages, press pound. f291: To transfer to another extension, press star T. f96: For help, press star H.
a1141	f1434: To return to getting messages, press pound. f18: To forward with comment, press 2. f8: To record a new message, press 4.
a1142	f0: <NULL fragment, 0.0 second pause>
a1143	f1436: English
a1144	f1437: <CHIMES - LIKE DOOR BELL> f1438: Call for NAME, f0: <NULL fragment, 0.0 second pause> IF (NUMBER>0) THEN f908: <5.0 second pause> ENDIF
a1145	f1439: <BEEP - LIKE CONF BRIDGE TONE>
a1146	f1440: <BEEP - LIKE RECORD AT TONE TONE>
a1147	f1441: <BEEP BEEP BEEP TONE - FOR OUT OF SPACE TONE>
a1148	f1442: <BEEP - LIKE EOM TONE BUT SOFTER>
a1149	#This announcement is a duplicate of 518 which is used for voice #mail, however this is used for call answer only. #A unique annnc id was intentionally used to allow customers #to not advertise this feature easily.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	f613: To make priority, press 2.
all150	<pre> #This announcement is played when scanning any call answer #message that was left when the calling party is known. # #NUMBER: 0 if message not private, 1 if message is private #NUMBER(2): 0 if message not priority, 1 if message is priority #NUMBER(3): length in seconds of message #NUMBER(4): 0 if message extension unavailable, 1 if available #NUMBER(5): 1 -voice only, 2 fax only, 3 voice and fax #NUMBER(6): number of fax pages #NAME: name of the calling party, if available #TIME: time message was left #DATE: date message was left #BUTTONS: extension of the calling party, if available # VERSION > 2 introduced in INTUITY 3.0 FAX VERSION == 3. IF (VERSION > 2) THEN a1170(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6),NAME,TIME,DATE,BUTTONS) ELSE # VERSION == 2, THIS IS 3.1 DEFINITY AUDIX and 2.0 INTUITY AUDIX IF (NUMBER>0) THEN #Message is private IF (NUMBER(2)>0) THEN #Message is priority f1445: Private, priority call from ELSE #Message is not priority f1446: Private call from ENDIF ELSE #Message is not private IF (NUMBER(2)>0) THEN #Message is priority f1447: Private call from ELSE #Message is not priority f47: Call from ENDIF ENDIF, NAME, f262: received #Time and date message was left TIME, DATE, f905: <.5 second pause> a873(NUMBER(3)), IF (NUMBER(4)>0) THEN #Calling party is known, play extension out also </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f86: extension BUTTONS ENDIF ENDIF </pre>
all151	<pre> #This announcement is played when scanning any call answer #message that was left when the calling party is unknown. # #NUMBER: 0 if message not private, 1 if message is private #NUMBER(2): 0 if message not priority, 1 if message is priority #NUMBER(3): length in seconds of message #NUMBER(4): 0 if message extension unavailable, 1 if available #NUMBER(5): 1 -voice only, 2 -fax only, 3 -voice and fax #NUMBER(6): length of fax pages #TIME: time message was left #DATE: date message was left #BUTTONS: extension of the calling party, if available # VERSION > 2 introduced in INTUITY 3.0 FAX VERSION == 3. IF (VERSION > 2) THEN a1171(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6),TIME,DATE,BUTTONS) ELSE # VERSION == 2, THIS IS 3.1 DEFINITY AUDIX and 2.0 INTUITY AUDIX IF (NUMBER>0) THEN #Message is private IF (NUMBER(2)>0) THEN #Message is priority f1448: Private, priority call received ELSE #Message is not priority f1449: Private call received ENDIF ELSE #Message is not private IF (NUMBER(2)>0) THEN #Message is priority f1450: Priority call received ELSE #Message is not priority f1451: Call received ENDIF ENDIF, #Time and date message was left TIME, DATE, f905: <.5 second pause> a873(NUMBER(3)), </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(4)>0) THEN #Calling party is known, play extension out also f86: extension BUTTONS ENDIF ENDIF </pre>
all152	<pre> f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign. f24: To delete, press star D. </pre>
all153	<pre> #NUMBER: number of days till password expires # assumed greater than 0 IF (NUMBER==1) THEN f1455: Your password will expire within one day. ELSE f1453: Your password will expire in NUMBER, f1454: days. ENDIF </pre>
all154	f1456: Your password has expired.
all155	f1457: Old and new passwords cannot be the same.
all156	<pre> #NUMBER: minimum age before change f1458: Password cannot be changed within NUMBER, IF (NUMBER==1) THEN f1460: day of last change. ELSE f1459: days of last change. ENDIF </pre>
all157	<pre> #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax. #NUMBER(4): 1 - fax enabled, 0 - fax disabled. #This variable was introduced in INTUITY 3.0 fax fax feature. #VERSION > 2 is for INTUITY 3.0 fax feature. #VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature. IF (VERSION > 2) THEN # INTUITY 3.0 - VERSION = 3 </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> a1172(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4)) ELSE # DEFINITY AUDIX 3.1 - VERSION = 2 f1461: You are getting your incoming messages. f1462: To listen to the message, press 0. IF (NUMBER==0) THEN #forwarding not allowed f252: To respond to this message, press 1. ELSE #forwarding allowed f1466: To respond to or forward the message, press one. ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ENDIF </pre>
a1158	<pre> #This announcement is used for the help when manually scanning #message headers. #when the stacked response feature is active. #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 0 if sender doesn't exist, 1 is sender exists #NUMBER(4): 1 is voice only, 2 fax only, 3 voice and fax #NUMBER(5): 0 fax disabled, 1 fax enabled #VERSION > 2 means Intuity MACH3 Fax feautre # f1461: You are getting your incoming messages. IF (VERSION > 2) THEN # Mach 3 IF (NUMBER(4) == 1) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # Voice only f1462: To listen to the message, press 0. ELSE IF (NUMBER(4) == 2) THEN IF (NUMBER(5) == 1) THEN f1073: To print, press star 1. ENDIF ELSE f1462: To listen to the message, press 0. IF(NUMBER(5) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF ENDIF ELSE # Definity 3.0 or 3.1 f1462: To listen to the message, press 0. ENDIF, IF (NUMBER(3)==1) THEN #sender of message exists, may reply f1463: To reply to sender by voice mail, press 1, 7. ENDIF, IF (NUMBER==1) THEN #forwarding allowed f1464: To forward with comment, press 1, 2. ENDIF, f1465: To record a new message, press 1, 4. IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a1159	<pre> #This announcement is used for the help when manually scanning #message headers. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax. #NUMBER(4): 1 - fax enabled, 0 - fax disabled. #This variable was introduced in INTUITY 3.0 fax fax feature. #VERSION > 2 is for INTUITY 3.0 fax feature. #VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature. IF (VERSION > 2) THEN # INTUITY 3.0 - VERSION = 3 a1173(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4)) ELSE # 3.1 DEFINITY AUDIX - VERSION = 2 IF (NUMBER==0) THEN #forwarding not allowed f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one. ELSE #forwarding allowed f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one. ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. ENDIF </pre>
a1160	#This announcement is used for responding to a message.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # #NUMBER: 0 if sender doesn't exist, 1 if sender exists #NUMBER(2): 0 if stacked response off, 1 if stacked response on #NUMBER(3): 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(4): 0 is can't call sender, 1 is can call sender # IF (NUMBER(2)==1) THEN f1434: To return to getting messages, press pound. ENDIF, IF (NUMBER==1) THEN #may reply to sender IF (NUMBER(2)==0) THEN #stacked response off f486: To reply to sender by voice mail, press 1. ELSE #stacked response on f1469: To reply to sender by voice mail, press 7. ENDIF ENDIF, IF (NUMBER(3)==1) THEN f18: To forward with comment, press 2. ENDIF, f8: To record a new message, press 4. IF (NUMBER(4)==1) THEN f163: To call sender, press zero. ENDIF </pre>
all161	<pre> #This announcement is used for help in responding to a message. # #NUMBER: 0 if sender doesn't exist, 1 if sender exists #NUMBER(2): 0 if stacked response off, 1 if stacked response on #NUMBER(3): 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(4): 0 is can't call sender, 1 is can call sender # f323: You are responding to a piece of incoming mail. IF (NUMBER==1) THEN #may reply to sender IF (NUMBER(2)==0) THEN #stacked response off f486: To reply to sender by voice mail, press 1. ELSE #stacked response on f1469: To reply to sender by voice mail, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> press 7. ENDIF ENDIF, IF (NUMBER(3)==1) THEN f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. ENDIF, f8: To record a new message, press 4. IF (NUMBER(4)==1) THEN f163: To call sender, press zero. ENDIF, f1434: To return to getting messages, press pound. </pre>
all162	f1467: The return address for this message is not a mailbox on this system.
all163	f1468: The return address for this message is not a valid extension.
all164	f1470: No voice portion of message to playback.
all165	f618: To remove priority status, press 2.
all166	f646: A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.
all167	<pre> # This announcement was introduced in INTUITY 3.0 FAX. # NUMBER(5) == number of fax messages. IF (NUMBER(3)>0) THEN #password is about to expire a1153(NUMBER(4)) ENDIF, NUMBER + NUMBER(2), f63: new IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, NUMBER, f1010: with priority. IF (NUMBER(5)>0) THEN NUMBER(5), f1011: with fax. ENDIF </pre>
all168	<pre> # This announcement was introduced in INTUITY 3.0 FAX. # NUMBER(3) == number of fax messages. NUMBER + NUMBER(2), f63: new IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, NUMBER, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f1010: with priority. IF (NUMBER(3) > 0) THEN NUMBER(3), f1011: with fax. ENDIF</pre>
all169	<pre># This announcement was introduced in INTUITY 3.0 FAX. # NUMBER(4) == number of fax messages. IF (NUMBER(2)>0) THEN #password is about to expire all153(NUMBER(3)) ENDIF, NUMBER, f63: new f601: Priority IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), f1011: with fax. ENDIF</pre>
all170	<pre>#This announcement is played when scanning any call answer #message that was left when the calling party is known. # # This announcement was introduced in INTUITY 3.0 FAX feature. #NUMBER: 0 if message not private, 1 if message is private #NUMBER(2): 0 if message not priority, 1 if message is priority #NUMBER(3): length in seconds of message #NUMBER(4): 0 if message extension unavailable, 1 if available # NUMBER(5) == 1 voice only, 2- fax only, 3- voice and fax # NUMBER(6) == number of fax pages #NAME: name of the calling party, if available #TIME: time message was left #DATE: date message was left #BUTTONS: extension of the calling party, if available IF (NUMBER>0) THEN #Message is private IF (NUMBER(2)>0) THEN #Message is priority IF (NUMBER(5) == 2) THEN #Message is private, priority fax f993: Private, priority fax call from</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE IF (NUMBER(5)==3) THEN #Message is private, priority voice and fax f994: Private, priority voice and fax call from ELSE #Message is private, priority voice f1445: Private, priority call from ENDIF ENDIF ELSE #Message is not priority IF (NUMBER(5) == 2) THEN #Message is private fax f995: Private fax call from ELSE IF (NUMBER(5) == 3) THEN #Message is private voice and fax f998: Private voice and fax call from ELSE f1446: Private call from ENDIF ENDIF ENDIF ELSE #Message is not private IF (NUMBER(2)>0) THEN #Message is priority IF (NUMBER(5) == 2) THEN #Message is priority fax f1000: Priority fax call from ELSE IF (NUMBER(5) == 3) THEN #Message is priority voice and fax f1003: Priority voice and fax call from ELSE #Message is priority f1447: Private call from ENDIF ENDIF ELSE #Message is not priority IF (NUMBER(5) == 2) THEN #Message is fax f1054: Fax call from </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE IF (NUMBER(5) == 3) THEN #Message is voice and fax f1055: Voice and fax call from ELSE f47: Call from ENDIF ENDIF ENDIF ENDIF, NAME, f262: received #Time and date message was left TIME, DATE, f905: <.5 second pause> #Play out length of message a1010(NUMBER(3),NUMBER(5), NUMBER(6)), IF (NUMBER(4)>0) THEN #Calling party is known, play extension out also f86: extension BUTTONS ENDIF </pre>
all171	<pre> #This announcement is played when scanning any call answer #message that was left when the calling party is unknown. # # This announcement was introduced in INTUITY 3.0 FAX feature. # NUMBER: 0 if message not private, 1 if message is private # NUMBER(2): 0 if message not priority, 1 if message is priority # NUMBER(3): length in seconds of message # NUMBER(4): 0 if message extension unavailable, 1 if available # NUMBER(5) == 1 voice only, 2- fax only, 3- voice and fax # NUMBER(6) == length of fax pages #TIME: time message was left #DATE: date message was left #BUTTONS: extension of the calling party, if available # IF (NUMBER>0) THEN #Message is private IF (NUMBER(2)>0) THEN IF (NUMBER(5) == 2) THEN #Message is private priority fax f1021: Private, priority fax call received ELSE IF (NUMBER(5) == 3) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN #Message is private priority voice and fax f1022: Private, priority voice and fax call received ELSE f1448: Private, priority call received ENDIF ENDIF ELSE #Message is not priority IF (NUMBER(5) == 2) THEN #Private fax f1023: Private fax call received ELSE IF (NUMBER(5) == 3) THEN #Private voice and fax f1024: Private voice and fax call received ELSE #Private voice f1449: Private call received ENDIF ENDIF ENDIF ELSE #Message is not private IF (NUMBER(2)>0) THEN #Message is priority IF (NUMBER(5) == 2) THEN #Priority fax f1025: Priority fax call received ELSE IF (NUMBER(5) == 3) THEN #Priority voice and fax f1026: Priority voice and fax call received ELSE #Priority voice f1450: Priority call received ENDIF ENDIF ELSE #Message is not priority IF (NUMBER(5) == 2) THEN #Fax received f1027: Fax call received ELSE IF (NUMBER(5) == 3) THEN #Voice and Fax received f1030: Voice and fax call received </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE #Voice received f1451: Call received ENDIF ENDIF ENDIF ENDIF, #Time and date message was left TIME, DATE, f905: <.5 second pause> #Play out length of message a1010(NUMBER(3),NUMBER(5), NUMBER(6)), IF (NUMBER(4)>0) THEN #Calling party is known, play extension out also f86: extension BUTTONS ENDIF </pre>
all172	<pre> #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax. #NUMBER(4): 0 fax is disabled, 1 fax is enabled #This variable was introduced in INTUITY 3.0 fax fax feature. #VERSION > 2 is for INTUITY 3.0 fax feature. #VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature. f1461: You are getting your incoming messages. IF (NUMBER(3) == 1) THEN f1462: To listen to the message, press 0. ELSE IF (NUMBER(3) == 2) THEN IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF ENDIF, IF (NUMBER==0) THEN #forwarding not allowed f252: To respond to this message, press 1. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE #forwarding allowed f1466: To respond to or forward the message, press one. ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a1173	<pre> #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax. #NUMBER(4): 0 fax disabled, 1 - fax enabled #This variable was introduced in INTUITY 3.0 fax fax feature. #VERSION > 2 is for INTUITY 3.0 fax feature. #VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature. IF (NUMBER==0) THEN #forwarding not allowed IF (NUMBER(3) == 1) THEN #voice only f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one. ELSE f1036: You are automatically scanning your incoming messages. IF (NUMBER(3) == 2) THEN #FAX only </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF, f1037: To respond to the message, press one. ENDIF ELSE #forwarding allowed IF (NUMBER(3) == 1) THEN #Voice only f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one. ELSE f1036: You are automatically scanning your incoming messages. IF (NUMBER(3) == 2) THEN #FAX only IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ELSE #voice and FAX f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF, f1466: To respond to or forward the message, press one. ENDIF ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a1174	<pre> # New announcement for INTUITY 3.0 - XEROX CAD and ABR Feature and FAX. # This announcement determines what plays out for the help announcements # which call this announcement- a76,a77,a113,a114,a115,a119,a120,a121,a125, # a127,a129,a159. # Which combination plays out depends on how the system is configured and # which features are active at the time. # # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature) # introduced in INTUITY 3.0 # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed. IF (NUMBER == 0) THEN IF (NUMBER(2) == 0) THEN IF (NUMBER(3) == 0) THEN # To administer mailing lists, # personal directory, password, or # account name, press 5. f997: To administer mailing list, personal directory, password, or account name, press 5. ELSE # To administer mailing list, personal directory, # password, # account name, or call answer options, press 5. f1149: To administer mailing list, personal directory, password, account name, or call answer options, press 5. ENDIF ELSE </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(3) ==0) THEN # To administer mailing list, personal directory, # password, account name, or addressing options, # press 5. f1147: To administer mailing list, personal directory, password, account name, or addressing options, press 5. ELSE # To administer mailing list, personal directory, # password, # account name, addressing options, # or call answer options, press 5. f1151: To administer mailing list, personal directory, password, account name, addressing options, or call answer options, press 5. ENDIF ENDIF ELSE IF (NUMBER(2) == 0) THEN IF (NUMBER(3) == 0) THEN # To administer mailing list, personal directory, # password, # fax options, or account name, press 5. f999: To administer mailing list, personal directory, password, fax options, or account name, press 5. ELSE # To administer mailing list, # directory, # password, fax options, account name, or # call answer options, press 5. f1150: To administer mailing list, personal directory, password, fax options, account name, or call answer options, press 5. ENDIF ELSE IF (NUMBER(3) == 0) THEN # To administer mailing list, personal directory, # password, fax options, account name, or # addressing options, press 5. f1148: To administer mailing list, personal directory, password, fax options, account name, or addressing options, press 5. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE # To administer mailing list, personal directory, # password, fax options, account name, addressing # options, or call answer options, press 5. f1146: To administer mailing list, personal directory, password, fax options, account name, addressing options, or call answer options, press 5. ENDIF ENDIF ENDIF </pre>
all175	<pre> # New announcement introduced in INTUITY 3.0. # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(3) is used for Call Answer Disable/Enable (CAD) Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (NUMBER == 0) THEN IF (NUMBER(3) == 1) THEN #CAD enabled f43: Your call is being answered by AUDIX. NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE #CAD disabled. f43: Your call is being answered by AUDIX. NAME, f45: is busy. To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 1) THEN IF (NUMBER(3) == 1) THEN f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f71: To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 2) THEN IF (NUMBER(3) == 1) THEN NAME, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE NAME, f45: is busy. To leave a message, wait for the tone. ENDIF ENDIF, IF(NUMBER(2) == 1 && NUMBER(3) != 1) THEN # FAX enabled. f1141: When finished recording, press pound for more options. ENDIF, f112: Otherwise, for assistance, press zero now. </pre>
a1176	<pre> # New announcement introduced in INTUITY 3.0. # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(3) is used for Call Answer Disable/Enable (CAD) Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (NUMBER == 0) THEN IF (NUMBER(3) == 1) THEN #CAD enabled f43: Your call is being answered by AUDIX. NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE #CAD disabled. f43: Your call is being answered by AUDIX. NAME, f44: is not available. To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 1) THEN IF (NUMBER(3) == 1) THEN f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f71: To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 2) THEN IF (NUMBER(3) == 1) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE NAME, f44: is not available. To leave a message, wait for the tone. ENDIF ENDIF, IF(NUMBER(2) == 1 && NUMBER(3) != 1) THEN # FAX enabled. f1141: When finished recording, press pound for more options. ENDIF, f112: Otherwise, for assistance, press zero now. </pre>
a1177	<pre> # New announcement introduced in INTUITY 3.0. # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(3) is used for Call Answer Disable/Enable (CAD) Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (NUMBER == 0) THEN IF (NUMBER(3) == 1) THEN #CAD enabled f43: Your call is being answered by AUDIX. NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE #CAD disabled. f43: Your call is being answered by AUDIX. NAME, f45: is busy. To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 1) THEN IF (NUMBER(3) == 1) THEN f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f71: To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 2) THEN IF (NUMBER(3) == 1) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE NAME, f45: is busy. To leave a message, wait for the tone. ENDIF ENDIF, IF(NUMBER(2) == 1 && NUMBER(3) != 1) THEN # FAX enabled. f1141: When finished recording, press pound for more options. ENDIF </pre>
all178	<pre> # New announcement introduced in INTUITY 3.0. # VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is used for the # FAX feature. NUMBER(2) == 1 if fax is enabled. # NUMBER(3) is used for Call Answer Disable/Enable (CAD) Xerox Feature # NUMBER(3) == 1 if call answer disabled turned on, 0 if off. IF (NUMBER == 0) THEN IF (NUMBER(3) == 1) THEN #CAD enabled f43: Your call is being answered by AUDIX. NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE #CAD disabled. f43: Your call is being answered by AUDIX. NAME, f44: is not available. To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 1) THEN IF (NUMBER(3) == 1) THEN f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE f71: To leave a message, wait for the tone. ENDIF ENDIF, IF (NUMBER == 2) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(3) == 1) THEN NAME, f1163: is not available. f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect. ELSE NAME, f44: is not available. To leave a message, wait for the tone. ENDIF ENDIF, IF(NUMBER(2) == 1 && NUMBER(3) != 1) THEN # FAX enabled. f1141: When finished recording, press pound for more options. ENDIF </pre>
a1179	f1166: Temporarily cannot access your messages. Processing your request to print all new faxes. Please try again"
a1180	f1168: Fax print all request to NAMEEXT
a1181	<pre> f378: You are checking the status of your outgoing messages. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a1182	<pre> f378: You are checking the status of your outgoing messages. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star D. </pre>
a1183	f59: delivered TIME,DATE
a1184	f1169: Printing has completed. TIME,DATE
a1185	<pre> f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f46: To access your mailbox, press star R. f973: If you are finished, please hang up, or press star, star X. </pre>
a1186	f165: Returned to getting messages.
a1187	f29: Returned to checking status of outgoing messages.
a1188	# New announcement introduced in INTUITY 3.0 Fax feature # Number of pages for fax.

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre># NUMBER(2), 0 fax is disabled, 1 fax is enabled # f1050: Message does not contain voice. f1049: Fax of NUMBER, IF (NUMBER == 1) THEN f1028: page. ELSE f1029: pages. ENDIF</pre>
a1189	#New announcement 1189 for INTUITY MACH 3 DIALSTR
a1190	# annc 1190 Intuity Mach 3 # Pause of .1 second f903: <.1 second pause>
a1191	# annc 1191 Intuity Mach 3 # Pause of .2 second f904: <.2 second pause>
a1192	# annc 1192 Intuity Mach 3 # Pause of .5 second f905: <.5 second pause>
a1193	# annc 1193 Intuity Mach 3 # Pause of 1 second f906: <1.0 second pause>
a1194	# annc 1194 Intuity Mach 3 # Pause of 2 second f907: <2.0 second pause>
a1195	# annc 1195 Intuity Mach 3 # Pause of 5 second f908: <5.0 second pause>
a1900	<pre># announcement for Ford Motor Company # custom development for Tandem Mailboxes # P_TND_CA1 (a1900) # Call Answer name and ext of caller known # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1 = voice, 2 = fax, 3 = both # NUMBER(5) number of fax pages # NAME = primary recipient # NAME(2) = sender # TIME, DATE, BUTTONS (extension of caller) # IF (NUMBER == 0) THEN # not private, not priority a1903(NUMBER(4)) ELSE IF (NUMBER == 1) THEN # private a1904(NUMBER(4)) ELSE</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER == 2) THEN # priority a1905(NUMBER(4)) ELSE # private and priority a1906(NUMBER(4)) ENDIF ENDIF ENDIF, NAME, f1924: ...from... NAME(2), f262: received TIME,DATE, a1010(NUMBER(2),NUMBER(4),NUMBER(5)), IF (NUMBER(3) == 1) THEN f86: extension BUTTONS ENDIF </pre>
a1901	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # P_TND_CA2 (a1901) # Call Answer name and ext of caller NOT known # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = voice, 2 = fax, 3 = both # NUMBER(4) number of fax pages # NAME = primary recipient # TIME, DATE # IF (NUMBER == 0) THEN # not private, not priority a1903(NUMBER(3)) ELSE IF (NUMBER == 1) THEN # private a1904(NUMBER(3)) ELSE IF (NUMBER == 2) THEN # priority a1905(NUMBER(3)) ELSE # private and priority a1906(NUMBER(3)) ENDIF ENDIF ENDIF, NAME, f262: received TIME,DATE, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	a1010(NUMBER(2),NUMBER(3),NUMBER(4))
a1902	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # P_TND_VM (a1902) # Voice Mail Header # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1 = voice, 2 = fax, 3 = both # NUMBER(5) number of fax pages # NAME = primary recipient # NAME(2) = sender # TIME, DATE, BUTTONS (extension of caller) # IF (NUMBER == 0) THEN # not private, not priority a1907(NUMBER(4)) ELSE IF (NUMBER == 1) THEN # private a1908(NUMBER(4)) ELSE IF (NUMBER == 2) THEN # priority a1909(NUMBER(4)) ELSE # private and priority a1910(NUMBER(4)) ENDIF ENDIF ENDIF, NAME, f1924: ...from... NAME(2), f59: delivered TIME,DATE, a1010(NUMBER(2),NUMBER(4),NUMBER(5)), IF (NUMBER(3) == 1) THEN f86: extension BUTTONS ENDIF </pre>
a1903	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1903) called by a1900 and a1901 # message not private or priority # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN # voice f1900: Call to... ELSE IF (NUMBER == 2) THEN # fax f1901: Fax call to... ELSE # voice and fax f1902: Voice and fax call to... ENDIF ENDIF </pre>
a1904	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1904) called by a1900 and a1901 # Private message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1903: Private call to... ELSE IF (NUMBER == 2) THEN # fax f1904: Private fax call to... ELSE # voice and fax f1905: Private voice and fax call to... ENDIF ENDIF </pre>
a1905	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1905) called by a1900 and a1901 # Priority message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1906: Priority call to... ELSE IF (NUMBER == 2) THEN # fax f1907: Priority fax call to... ELSE # voice and fax f1908: Priority voice and fax call to... ENDIF ENDIF </pre>
a1906	<pre> # announcement for Ford Motor Company </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # custom development for Tandem Mailboxes # (a1906) called by a1900 and a1901 # Private/Priority message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1909: Private, priority call to... ELSE IF (NUMBER == 2) THEN # fax f1910: Private, priority fax call to... ELSE # voice and fax f1911: Private, priority voice and fax call to... ENDIF ENDIF ENDIF </pre>
a1907	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1907) called by a1902 # message not private or priority # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1912: Message to... ELSE IF (NUMBER == 2) THEN # fax f1913: Fax message to... ELSE # voice and fax f1914: Voice and fax message to... ENDIF ENDIF ENDIF </pre>
a1908	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1908) called by a1902 # Private message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1915: Private message to... ELSE IF (NUMBER == 2) THEN # fax </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1916: Private fax message to... ELSE # voice and fax f1917: Private voice and fax message to... ENDIF ENDIF </pre>
a1909	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1909) called by a1902 # Priority message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1918: Priority message to... ELSE IF (NUMBER == 2) THEN # fax f1919: Priority fax message to... ELSE # voice and fax f1920: Priority voice and fax message to... ENDIF ENDIF ENDIF </pre>
a1910	<pre> # announcement for Ford Motor Company # custom development for Tandem Mailboxes # (a1910) called by a1902 # Private/Priority message # # NUMBER 1 = voice, 2 = fax, 3 = both # IF (NUMBER == 1) THEN # voice f1921: Private, priority message to... ELSE IF (NUMBER == 2) THEN # fax f1922: Private, priority fax message to... ELSE # voice and fax f1923: Private, priority voice and fax message to... ENDIF ENDIF ENDIF </pre>
a1911	<pre> # Mach 4 announcement for Ford Motor Company # custom development for Tandem Mailboxes # PM4_TND_CA1 (a1911) # Call Answer name and ext of caller known # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1=voice,2=fax,3=text,4=file attachment # NUMBER(5) 1=voice,2=fax,3=text,4=file attachment # NUMBER(6) 1=voice,2=fax,3=text,4=file attachment # NUMBER(7) 1=voice,2=fax,3=text,4=file attachment # NUMBER(8) number of fax pages # NUMBER(9) number of bytes # NAME = primary recipient # NAME(2) = sender # TIME, DATE, BUTTONS (extension of caller) # IF (NUMBER == 1) THEN # private f2021: Private... ELSE IF (NUMBER == 2) THEN # priority f2023: Priority... ELSE IF (NUMBER == 3) THEN # private and priority f2022: Private, priority... ENDIF ENDIF ENDIF, a2101(NUMBER(4),NUMBER(5),NUMBER(6),NUMBER(7)), f1900: Call to... NAME, f1924: ...from... NAME(2), f262: received TIME,DATE, a2102(NUMBER(8),NUMBER(9),NUMBER(2)), IF (NUMBER(3) == 1) THEN f86: extension BUTTONS ENDIF </pre>
a1912	<pre> # Mach 4 announcement for Ford Motor Company # custom development for Tandem Mailboxes # PM4_TND_CA2 (a1912) # Call Answer name and ext of caller NOT known # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1=voice,2=fax,3=text,4=file attachment # NUMBER(4) 1=voice,2=fax,3=text,4=file attachment # NUMBER(5) 1=voice,2=fax,3=text,4=file attachment # NUMBER(6) 1=voice,2=fax,3=text,4=file attachment # NUMBER(7) number of fax pages # NUMBER(8) number of bytes # NAME = primary recipient </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # TIME, DATE # IF (NUMBER == 1) THEN # private f2021: Private... ELSE IF (NUMBER == 2) THEN # priority f2023: Priority... ELSE IF (NUMBER == 3) THEN # private and priority f2022: Private, priority... ENDIF ENDIF ENDIF, a2101(NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6)), f1900: Call to... NAME, f262: received TIME,DATE, a2102(NUMBER(7),NUMBER(8),NUMBER(2)) </pre>
a1913	<pre> # Mach 4 announcement for Ford Motor Company # custom development for Tandem Mailboxes # PM4_TND_VM (a1913) # Voice Mail Header # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1=voice,2=fax,3=text,4=file attachment # NUMBER(5) 1=voice,2=fax,3=text,4=file attachment # NUMBER(6) 1=voice,2=fax,3=text,4=file attachment # NUMBER(7) 1=voice,2=fax,3=text,4=file attachment # NUMBER(8) number of fax pages # NUMBER(9) number of bytes # NAME = primary recipient # NAME(2) = sender # TIME, DATE, BUTTONS (extension of caller) # IF (NUMBER == 1) THEN # private f2021: Private... ELSE IF (NUMBER == 2) THEN # priority f2023: Priority... ELSE IF (NUMBER == 3) THEN # private and priority </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f2022: Private, priority... ENDIF ENDIF ENDIF, a2101(NUMBER(4),NUMBER(5),NUMBER(6),NUMBER(7)), f1912: Message to... NAME, f1924: ...from... NAME(2), f59: delivered TIME,DATE, a2102(NUMBER(8),NUMBER(9),NUMBER(2)), IF (NUMBER(3) == 1) THEN f86: extension BUTTONS ENDIF </pre>
a1914	<pre> # DISCLAIMER announcement added in 4.3 # contains blank fragment that can be # recorded by customer f1925: # this is a blank fragment which can be recorded by # the customer, for use as a disclaimer announcement </pre>
a2000	<pre> # announcement 2000 # new for Mach 4 #f2000, f926: <error sound> f2001: One or more components of this multimedia message could not be delivered. Please contact the sender. </pre>
a2001	<pre> # announcement 2001 # new for Mach 4 f259: scheduled for TIME,DATE, f2002: Message not delivered because it contained 1 or more media types that the recipient's machine is unable to process. </pre>
a2002	<pre> # announcement 2002 # new for Mach 4 f259: scheduled for TIME,DATE, f2003: Message not delivered because it is too long for the recipient's machine. </pre>
a2005	<pre> # announcement 2005 # new for Mach 4 f259: scheduled for TIME,DATE, f2006: Message not delivered because private messages cannot be sent to the recipient's machine. </pre>
a2006	<pre> # announcement 2006 # This is a new for Mach 4 (replaces annc 1169) # NUMBER = total number of messages # NUMBER(2) Yes/No Play password annc # NUMBER(3) number of days till password expires </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(4) = number of fax messages. # NUMBER(5) = number of text messages # NUMBER(6) = number of other media messages NAME, IF (NUMBER(2)>0) THEN #password is about to expire all153(NUMBER(3)) ENDIF, NUMBER, f63: new f601: Priority IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), f1011: with fax. ENDIF, IF (NUMBER(5) > 0) THEN NUMBER(5), f2007: with text. ENDIF, IF (NUMBER(6) > 0) THEN NUMBER(6), f2008: with other media ENDIF </pre>
a2007	<pre> # Announcement 2007 new in MACH4 # NUMBER = number of priority messages # NUMBER(2) = number of non-priority messages # NUMBER(3) = 1/0 play password annc # NUMBER(4) = number days till passwd expires # NUMBER(5) = number of fax messages. # NUMBER(6) = number of text messages # NUMBER(7) = number of binary/other mesages # NAME, IF (NUMBER(3)>0) THEN #password is about to expire all153(NUMBER(4)) ENDIF, NUMBER + NUMBER(2), f63: new IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, NUMBER, f1010: with priority. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER(5)>0) THEN NUMBER(5), f1011: with fax. ENDIF, IF (NUMBER(6) > 0) THEN NUMBER(6), f2007: with text. ENDIF, IF (NUMBER(7) > 0) THEN NUMBER(7), f2008: with other media ENDIF </pre>
a2008	<pre> # announcement 2008 new in MACH4 # replaces a185 # NUMBER = number of messages # NUMBER(2) = 1/0 play passwd annc # NUMBER(3) = days till passwd expires # NUMBER(4) = number of fax messages # NUMBER(5) = number of text messages # NUMBER(6) = nuber of binary/other messages # NAME, IF (NUMBER(2)>0) THEN #password is about to expire a1153(NUMBER(3)) ENDIF, NUMBER, f63: new IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), f1011: with fax. ENDIF, IF (NUMBER(5) > 0) THEN NUMBER(5), f2007: with text. ENDIF, IF (NUMBER(6) > 0) THEN NUMBER(6), f2008: with other media ENDIF </pre>
a2009	<pre> # announcement 2009 new in MACH4 # NUMBER = number of priority messages # NUMBER(2) = number of non-priority messages </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER(3) = number of fax messages # NUMBER(4) = number of text messages # NUMBER(5) = number of binary/other messages # NUMBER + NUMBER(2), f63: new IF (NUMBER + NUMBER(2) == 1) THEN f160: message ELSE f168: messages. ENDIF, NUMBER, f1010: with priority. IF (NUMBER(3) > 0) THEN NUMBER(3), f1011: with fax. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), f2007: with text. ENDIF, IF (NUMBER(5) > 0) THEN NUMBER(5), f2008: with other media ENDIF </pre>
a2010	<pre> # announcement 2010 new in MACH4 # replaces a235 # NUMBER = number of priority messages # NUMBER(2) = number of fax messages # NUMBER(3) = number of text messages # NUMBER(4) = number of binary/other messages # f2: and NUMBER, f63: new f601: Priority IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(2) > 0) THEN NUMBER(2), f1011: with fax. ENDIF, IF (NUMBER(3) > 0) THEN NUMBER(3), f2007: with text. ENDIF, IF (NUMBER(4) > 0) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> NUMBER(4), f2008: with other media ENDIF </pre>
a2011	<pre> # announcement 2011 new in MACH4 # NUMBER = number of priority messages # NUMBER(2) = number of fax messages # NUMBER(3) = number of text messages # NUMBER(4) = number of binary/other messages # f2: and NUMBER, f602: other f63: new IF (NUMBER==1) THEN f160: message ELSE f168: messages. ENDIF, IF (NUMBER(2) > 0) THEN NUMBER(2), f1011: with fax. ENDIF, IF (NUMBER(3) > 0) THEN NUMBER(3), f2007: with text. ENDIF, IF (NUMBER(4) > 0) THEN NUMBER(4), f2008: with other media ENDIF </pre>
a2012	<pre> # announcement 2012 new in MACH4 # deletion tone f2000: <ERROR TONE - Missing Component> </pre>
a2013	<pre> # announcement 2013 new in MACH4 f2009: Incomplete... </pre>
a2014	<pre> # announcement 2014 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> # do pages, bytes, seconds </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	a2102(NUMBER(5),NUMBER(6),NUMBER(7))
a2015	<pre># announcement 2015 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)</pre>
a2016	<pre># announcement 2016 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION</pre>
a2017	<pre># announcement 2017 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2)</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a2018	<pre> # announcement 2018 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... f1117: all local subscribers. IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF ENDIF </pre>
a2019	<pre> # announcement 2019 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... f1117: all local subscribers. IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF ENDIF </pre>
a2020	<pre> # announcement 2020 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... f1117: all local subscribers. IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f602: other ELSE f217: others ENDIF ENDIF </pre>
a2021	<pre> # announcement 2021 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a2022	<pre> # announcement 2022 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a2023	<pre> # announcement 2023 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2024: Private, broadcast... </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))</pre>
a2024	<pre># announcement 2024 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2024: Private, broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)</pre>
a2025	<pre># announcement 2025 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2024: Private, broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION</pre>
a2026	<pre># announcement 2026 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2024: Private, broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2) </pre>
a2027	<pre> # announcement 2027 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)) </pre>
a2028	<pre> # announcement 2028 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2) </pre>
a2029	<pre> # announcement 2029 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
a2030	<pre># announcement 2030 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2)</pre>
a2031	<pre># announcement 2031 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))</pre>
a2032	<pre># announcement 2032 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)</pre>
a2033	<pre># announcement 2033 new in MACH4</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre># MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION</pre>
a2034	<pre># announcement 2034 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2)</pre>
a2035	<pre># announcement 2035 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF</pre>
a2036	<pre># announcement 2036 new in MACH4</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2024: Private, broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... f1117: all local subscribers. IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a2037	<pre> # announcement 2037 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)) </pre>
a2038	<pre> # announcement 2038 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2) </pre>
a2039	<pre> # announcement 2039 new in MACH4 </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION </pre>
a2040	<pre> # announcement 2040 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2) </pre>
a2041	<pre> # announcement 2041 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF </pre>
a2042	<pre> # announcement 2042 new in MACH4 </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre># MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))</pre>
a2043	<pre># announcement 2043 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)</pre>
a2044	<pre># announcement 2044 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION</pre>
a2045	<pre># announcement 2045 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)),</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2)</pre>
a2046	<pre># announcement 2046 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF</pre>
a2047	<pre># announcement 2047 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF</pre>
a2048	<pre># announcement 2048 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of other subscribers #</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2020: ...message to... NAME, IF (NUMBER(5) > 0) THEN f2: and NUMBER(5), IF (NUMBER(5) == 1) THEN f602: other ELSE f217: others ENDIF ENDIF ENDIF </pre>
a2049	<pre> # announcement 2049 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # NUMBER(8) = private/non-private # NUMBER(9) = prioity/non-priority # NUMBER(10) = ext available or not # IF (NUMBER(8) == 1) THEN f2021: Private... ENDIF, IF (NUMBER(9) == 1) THEN f2023: Priority... ENDIF, a2101(NUMBER,NUMBER(2),NUMBER(3)), f2025: ...call from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), IF (NUMBER(10) > 0) THEN f86: extension BUTTONS ENDIF </pre>
a2050	<pre> # announcement 2050 new in MACH4 # Controlling announcement to play length of # message in bytes # IF (NUMBER < 1000) THEN # less than 1K a2051(NUMBER) ELSE IF (NUMBER < 999500) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # less than 1M # allow for rounding a2052(NUMBER) ELSE # 1M or greater a2053(NUMBER) ENDIF ENDIFIF </pre>
a2051	<pre> # announcement 2051 new in MACH4 # announcement for playing length of # message in bytes (less than 1K) # IF (NUMBER == 0) THEN f2010: zero f2011: bytes ELSE IF (NUMBER == 1) THEN f391: one f2012: byte ELSE a820(NUMBER), f2011: bytes ENDIF ENDIFIF </pre>
a2052	<pre> # announcement 2052 new in MACH4 # announcement for playing length of # message in bytes (1K to 1M) # IF (NUMBER < 1025) THEN f391: one f2013: kilobyte ELSE f2053: ...approximately... IF (NUMBER/1000 == 1 && NUMBER%1000 < 500) THEN f391: one f2013: kilobyte ELSE IF ((NUMBER%1000) < 500) THEN a820(NUMBER/1000) ELSE a820((NUMBER/1000) + 1) ENDIF, f2014: kilobytes ENDIF ENDIFIF </pre>
a2053	<pre> # announcement 2053 new in MACH4 # announcement for playing length of # message in bytes (> 1M) # allow for rounding 999500 = 1M </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # NUMBER = number of bytes # IF (NUMBER < 1000000) THEN # rounding for 999500 or greater f2053: ...approximately... f391: one f2015: megabyte ELSE IF (NUMBER == 1000000) THEN f391: one f2015: megabyte ELSE f2053: ...approximately... IF (NUMBER/1000000==1 && NUMBER%1000000 < 500000) THEN f391: one f2015: megabyte ELSE IF ((NUMBER%1000000) < 500000) THEN a820(NUMBER/1000000) ELSE a820((NUMBER/1000000) + 1) ENDIF, f2016: megabytes ENDIF ENDIF ENDIF ENDIF </pre>
a2054	<pre> # announcement 2054 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # NUMBER(8) = private/non-private # NUMBER(9) = prioity/non-priority # NUMBER(10) = ext available of not # IF (NUMBER(8) == 1) THEN f2021: Private... ENDIF, IF (NUMBER(9) == 1) THEN f2023: Priority... ENDIF, a2101(NUMBER,NUMBER(2),NUMBER(3)), f2026: ...call received... TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), IF (NUMBER(10) > 0) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f86: extension BUTTONS ENDIF</pre>
a2055	<pre># announcement 2055 new in MACH4 # NUMBER = number of pages # f2027: Text of... f2053: ...approximately... a820(NUMBER), IF (NUMBER == 1) THEN f1028: page. ELSE f1029: pages. ENDIF</pre>
a2056	<pre># announcement 2056 new in MACH4 # NUMBER = number of bytes # f2028: Binary file of... a2050(NUMBER)</pre>
a2057	<pre># announcement 2057 new in MACH4 # NUMBER: 0 is stacked response off, 1 is stacked response on # NUMBER(2): 0 is forwarding not allowed, 1 is forwarding allowed # NUMBER(3): 0 if sender doesn't exist, 1 if sender exits # NUMBER(4): 1/0 is printable IF (NUMBER==0) THEN #stacked response feature off IF (NUMBER(2)==0) THEN #no forwarding f252: To respond to this message, press 1. ELSE #forwarding f234: To respond or forward, press 1. ENDIF ELSE #stacked response feature on IF (NUMBER(3)==1) THEN #sender of message exists, may reply f1463: To reply to sender by voice mail, press 1, 7. ENDIF, IF (NUMBER(2)==1) THEN #forwarding allowed f1464: To forward with comment, press 1, 2. ENDIF, f1465: To record a new message, press 1, 4. ENDIF, IF (NUMBER(4) == 1) THEN</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # printable f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. </pre>
a2058	<pre> # announcement 2058 new in MACH4 # NUMBER == 1/0 is printable f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key. </pre>
a2059	<pre> # announcement 2059 new in MACH4 # NUMBER = 1/0 contains voice # NUMBER(2) = 1/0 is printable IF (NUMBER == 1) THEN f2054: To re-record, press 1. After recording, press 1 again. ENDIF, IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f1007: To playback, press 2-3. f157: To approve as is, press the pound key. </pre>
a2060	<pre> # announcement 2060 new in MACH4 # NUMBER == 1/0 is printable f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f388: To skip, press the pound key. </pre>
a2061	<pre> # announcement 2061 new in MACH4 # NUMBER == 1/0 is printable f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f24: To delete, press star D. f388: To skip, press the pound key. </pre>
a2062	<pre> # announcement 2062 new in MACH4 # NUMBER = 1/0 contains voice # NUMBER(2) = 1/0 is printable IF (NUMBER == 1) THEN f30: To change, press 1. ENDIF, IF (NUMBER(2) == 1) THEN f1073: To print, press star 1. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>ENDIF, f24: To delete, press star D. f388: To skip, press the pound key.</pre>
a2063	<pre># announcement 2063 new in MACH4 # NUMBER == 1/0 is printable f165: Returned to getting messages. f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D. f388: To skip, press the pound key.</pre>
a2064	<pre># announcement 2064 new in MACH4 # NUMBER == 1/0 is printable f165: Returned to getting messages. f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f255: To delete this message, press star D. f388: To skip, press the pound key.</pre>
a2065	<pre># announcement 2065 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = 1/0 is printable # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f21: To listen, press 0. IF (NUMBER(5) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star D.</pre>
a2066	<pre># announcement 2066 new in MACH4 # NUMBER == 1/0 is printable f252: To respond to this message, press 1. f24: To delete, press star D. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f388: To skip, press the pound key.</pre>
a2067	<pre># announcement 2067 new in MACH4 # f926: <error sound> f1048: Nothing to print.</pre>
a2068	<pre># announcement 2068 new in MACH4 #This announcement is used for the help when manually scanning #message headers.</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1/0 is printable #NUMBER(4): number of components in message # f1461: You are getting your incoming messages. f1462: To listen to the message, press 0. IF (NUMBER(3) == 1) THEN f1073: To print, press star 1. ENDIF, IF (NUMBER==0) THEN #forwarding not allowed f252: To respond to this message, press 1. ELSE #forwarding allowed f1466: To respond to or forward the message, press one. ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(4) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(4) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(4) < 2) THEN f377: To delete message, press star D. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2069	<pre> # announcement 2069 new in MACH4 # replaces a1158 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): stacked response on/off #NUMBER(4): 1/0 is printable #NUMBER(5): number of components in message # f1461: You are getting your incoming messages. f1462: To listen to the message, press 0. IF (NUMBER(4) == 1) THEN #is printable f1073: To print, press star 1. ENDIF, IF (NUMBER(3) == 1) THEN f1463: To reply to sender by voice mail, press 1, 7. ENDIF, IF (NUMBER == 1) THEN #forwarding allowed f1464: To forward with comment, press 1, 2. ENDIF, f1465: To record a new message, press 1, 4. IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(5) == 1) THEN f2035: To advance to the end of the message, press star 6. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE IF (NUMBER(5) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(5) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2070	<pre> # announcement 2070 new in MACH4 # similar to all173 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed #NUMBER(2): 0 is message not scanned, 1 is message scanned #NUMBER(3): 1/0 is printable #NUMBER(4): number of components in this message # IF (NUMBER == 0) THEN f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one. IF (NUMBER(3) == 1) THEN f1073: To print, press star 1. ENDIF ELSE f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one. IF (NUMBER(3) == 1) THEN f1073: To print, press star 1. ENDIF ENDIF, IF (NUMBER(2)==0) THEN #message not scanned f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. ELSE #message scanned </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. ENDIF, f577: To hold the message in its current category, press star star H f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(4) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(4) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(4) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2071	<pre> # announcement 2071 new in MACH4 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message # f378: You are checking the status of your outgoing messages. f1462: To listen to the message, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(2) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(4) > 1) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(4) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2072	<pre> # announcement 2072 new in MACH4 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message # f378: You are checking the status of your outgoing messages. f1462: To listen to the message, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1038: To re-record message before delivery, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(2) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(4) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(4) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2073	<pre> # announcement 2073 new in MACH4 # replaces a929 </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message # f378: You are checking the status of your outgoing messages. f1462: To listen to the message, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1039: To change or send again, press one. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. IF (NUMBER(2) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(2) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(2) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2074	<pre> # announcement 2074 new in MACH4 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message # f378: You are checking the status of your outgoing messages. f1462: To listen to the message, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f1038: To re-record message before delivery, press one. f376: To skip to the next header, press the pound sign. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<p>To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.</p> <p>f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.</p> <pre> IF (NUMBER(2) == 1) THEN f2035: To advance to the end of the message, press star 6. ELSE IF (NUMBER(2) > 1) THEN f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6. ENDIF ENDIF, f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. IF (NUMBER(2) < 2) THEN f377: To delete message, press star D. ELSE f2037: To delete entire message, press star D. ENDIF </pre>
a2075	<pre> # announcement 2075 new in MACH4 # NUMBER: 1 = voice, 2 = fax, 3 = text, 4 = binary/other # f2038: Rewound... IF (NUMBER != 0) THEN f2030: ...voice... (NUMBER-1) ENDIF, f2039: ...component. IF (NUMBER(2) == 1) THEN f2057: At beginning of message. f2040: To listen, press 3. ELSE f2040: To listen, press 3. f2058: To step back to previous component, press star 5. ENDIF </pre>
a2076	<pre> # announcement 2076 new in MACH4 # f2052: At beginning of message. To step back to previous message, press star 2. To listen, press 0. </pre>
a2077	<pre> # announcement 2077 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2078	<pre> # announcement 2078 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a2079	<pre> # announcement 2079 new in MACH4 # replaces all3 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1016: To administer your greeting, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2080	<pre> # announcement 2080 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2081	<pre> # announcement 2081 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2082	<pre> # announcement 2082 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2083	<pre> # announcement 2083 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1013: To administer attendant menu, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	star star X.
a2084	<pre> # announcement 2084 new in MACH4 # replaces a121 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2085	<pre> # announcement 2085 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2086	<pre> # announcement 2086 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2087	<pre> # announcement 2087 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f291: To transfer to another extension, press star T. f117: To reach the covering extension, press star zero. f282: To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X. </pre>
a2088	<pre> # announcement 2088 new in MACH4 # NUMBER = 1 if fax enabled, # NUMBER = 0 if fax is not enabled. f305: You are at the activity menu. IF (NUMBER==0) THEN f990: To record and send voice mail messages, press 1. ELSE f991: To record and send voice mail or fax messages, press 1. ENDIF, f992: To get messages, press 2. f1006: To record or change the greeting heard by callers, press 3. f996: To check your outgoing messages, press 4. f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5. IF(NUMBER == 0) THEN f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logout, press star star R. ELSE f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logout, press Star Star R. ENDIF, f282: To have system wait, press star W. To access the </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.
a2089	<pre> # announcement 2089 new in MACH4 # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature) # introduced in INTUITY 3.0 (MACH3) # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed. # This is the help at subscriber admin w/o "record name" fragment. f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF, f2042: To administer your media preference for sorting incoming messages, press 8. </pre>
a2090	<pre> # announcement 2090 new in MACH4 # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature) # introduced in INTUITY 3.0 (MACH3) # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed. # This is the help at subscriber admin with "record name" fragment. f703: You are at subscriber administration. f700: To administer mailing lists, press 1. To administer personal directory, press 2. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. f702: To record your name, press 5. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF, f2042: To administer your media preference for sorting incoming messages, press 8. </pre>
a2091	<pre> # announcement 2091 new in MACH4 # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature # (ABR) -(XEROX feature) # introduced in INTUITY 3.0 (MACH3) # NUMBER(2) == 0 for addressing options not allowed, 1 # for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) # (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, # 1 for call answer # options allowed. # This is the help at subscriber admin w/0 "record name" # fragment. f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF, f2042: To administer your media preference for sorting incoming messages, press 8. </pre>
a2092	<pre> # announcement 2092 new in MACH4 # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature # (ABR) -(XEROX feature) </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> # introduced in INTUITY 3.0 (MACH3) # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed. # This is the help at subscriber admin with "record name" fragment. f700: To administer mailing lists, press 1. To administer personal directory, press 2. IF (NUMBER == 1) THEN f1052: To specify your fax preferences, press 3. ENDIF, f701: To change your password, press 4. f702: To record your name, press 5. IF (NUMBER(2) == 1) THEN f1144: To specify whether a message can be addressed before it's recorded, press 6. ENDIF, IF (NUMBER(3) == 1) THEN f1145: To administer call answer options, press 7. ENDIF, f2042: To administer your media preference for sorting incoming messages, press 8. </pre>
a2093	<pre> # announcement 2093 f2043: You are administering your preferred media type for sorting incoming messages. Messages with a primary media type matching your preference will be presented before other messages, regardless of the order in which they have been received. f2044: No media preference for sorting incoming messages has been specified. f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4. f2046: To retain your current preference, press the pound key. </pre>
a2094	<pre> # announcement 2094 new in MACH4 f2044: No media preference for sorting incoming messages has been specified. f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4. f2046: To retain your current preference, press the pound key. </pre>
a2095	<pre> # announcement 2095 new in MACH4 f2043: You are administering your preferred media type for sorting incoming messages. Messages with a primary media type matching your preference will be presented before other messages, regardless of the order in which they have been received. </pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre>f2047: Your media preference for sorting incoming messages is... f2030: ...voice... (NUMBER-1), f2048: For no preference, press 0. f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4. f2046: To retain your current preference, press the pound key.</pre>
a2096	<pre># announcement 2096 new in MACH4 f2047: Your media preference for sorting incoming messages is... f2030: ...voice... (NUMBER-1), f2048: For no preference, press 0. f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4. f2046: To retain your current preference, press the pound key.</pre>
a2097	<pre># announcement 2097 new in MACH4 # NUMBER = 0 = none,1 = voice,2 = fax,3 = text,4 = binary/other IF (NUMBER == 0) THEN f2044: No media preference for sorting incoming messages has been specified. ELSE f2030: ...voice... (NUMBER-1), f2049: ...will be your preferred media type. ENDIF</pre>
a2098	<pre># announcement 2098 new in MACH4 f2050: Remote user.</pre>
a2099	<pre># announcement 2099 new in MACH4 f926: <error sound></pre>
a2100	<pre># announcement 2100 new in MACH4 f2051: Your password cannot be, the same as your extension number, consecutive digits, or a single repeated digit. Please enter new password and the pound key.</pre>
a2101	<pre># announcement 2101 new in MACH4 # called by MSG HEADER anncs # to speak type(s) of components # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary IF (NUMBER(3) != 0) THEN # multimedia f2034: ...multi-media... ELSE IF (NUMBER(2) == 0) THEN IF (NUMBER != 0) THEN # only 1 component f2030: ...voice... (NUMBER-1) ENDIF</pre>

US-ENGLISH ANNOUNCEMENTS

DEFINITY® R3.2 / INTUITY™ MACH 4 AUDIX®

Announcement	Fragments
	<pre> ELSE # two components f2030: ...voice... (NUMBER-1), f2018: ...and... f2030: ...voice... (NUMBER(2)-1) ENDIF ENDIF </pre>
a2102	<pre> # announcement 2102 new in MACH4 # called by MSG HEADER annc # to speak pages, bytes, seconds # NUMBER = number of pages # NUMBER = number of bytes # NUMBER = number of seconds # IF (NUMBER > 0) THEN a820(NUMBER), IF (NUMBER == 1) THEN f1028: page. ELSE f1029: pages. ENDIF ENDIF, IF (NUMBER(2) == 0 OR NUMBER(2) > 0) THEN a2050(NUMBER(2)) ENDIF, IF (NUMBER(3) > 0) THEN a873(NUMBER(3)) ENDIF </pre>
a2103	<pre> # NEW ANNOUNCEMENT FOR MACH4 f2004: Message receipt notification: the complete message was delivered to you on an associated system. To play the message header, press 2-3. </pre>
a2104	<pre> # NEW ANNOUNCEMENT FOR MACH4 f2005: Header only message. No part of the original message is missing. To play the message header, press 2-3. </pre>
a2105	<pre> # NEW ANNOUNCEMENT FOR MACH4 f2059: This machine is unable to send mail to... NAME </pre>

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f0 a1090,a1095,a1129,a1131,a1142,a1144

<NULL fragment, 0.0 second pause>

f1 a649

Someone is changing your greeting, please try again later.

f2 a210,a235,a236,a273,a342,a343,a344,a345,a350,a352,
a366,a372,a381,a387,a398,a404,a412,a418,a493,a540,
a541,a542,a543,a544,a545,a546,a553,a554,a673,a675,
a767,a794,a800,a838,a840,a841,a2010,a2011,a2018,
a2019,a2020,a2021,a2022,a2035,a2036,a2041,a2046,
a2047,a2048

and

f3 a608

No new remote subscribers can be addressed.

f4 a874

not private.

f5 a26,a283

To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound.

f6 a98,a100,a509

Enter machine voice ID.

f8 a62,a85,a123,a126,a128,a168,a169,a170,a202,a204,
a205,a693,a759,a760,a761,a768,a1139,a1141,a1160,
a1161

To record a new message, press 4.

f9 a914

star R not available.

f10 a442

That is not a valid machine voice ID.

f11 a98

You are recording machine names.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f12 a310,a973

To re-record, press 1. After recording, press 1 again. To delete, press star D. To playback, press 2-3. To approve as is, press pound.

f13 a49,a68,a101,a267,a310,a332,a581,a589,a879,a881,
a943,a961,a992

To record, press 1. After recording, press 1 again.

f14 a39,a502

To make private, press 1. To make public, press 2.

f15 a455,a456

and is

f16 a238

Enter announcement id

f17 a184,a190

including

f18 a202,a693,a759,a768,a1141,a1160

To forward with comment, press 2.

f19 a695,a698

To review from beginning, press star 1. If finished, press star pound.

f20 a822

Remote extension

f21 a276,a346,a507,a527,a530,a892,a893,a2058,a2060,
a2061,a2063,a2064,a2065

To listen, press 0.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f22 a318,a609,a715,a765

To deliver now, press pound. To schedule delivery time enter hour, minutes, A or P, and pound sign.

f23 a113,a722

To record messages, press 1. To get messages, press 2. To administer your greeting, press 3.

f24 a34,a74,a192,a206,a276,a310,a315,a326,a429,a430,
a501,a507,a508,a525,a527,a892,a893,a907,a1011,
a1012,a1027,a1152,a2057,a2058,a2059,a2061,a2062,
a2063,a2065,a2066

To delete, press star D.

f25 a889

List id not followed by pound.

f26 a757

To record names, press 4. To play names, press 5. To record machine names, press 6. To play machine names, press 7.

f27 a249

To attach original, press Y for yes or N for no.

f29 a255,a1187

Returned to checking status of outgoing messages.

f30 a508,a2062

To change, press 1.

f31 a261

Date not understood.

f32 a262

You must enter your extension to logon.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f34 a538,a540,a548

Electronic Text

f35 a264,a265

Login incorrect.

f36 a50

To record a personal greeting, press 1.

f37 a654,a890

Extension entered not followed by pound

f38 a655,a891

Name entered not followed by pound

f39 a26

**To delete, press star D. To stop playback,
press 3.**

f40 a266

Time not understood.

f41 a62,a85,a123,a170,a1161

**To forward message with comment at beginning,
press 2.**

f42 a284

**The return address for this message is not a
mailbox on this system.**

f43 a282,a288,a289,a290,a291,a292,a293,a1105,a1175,
a1176,a1177,a1178

Your call is being answered by AUDIX.

f44 a289,a292,a1176,a1178

**is not available. To leave a message, wait for
the tone.**

f45 a290,a291,a1175,a1177

is busy. To leave a message, wait for the tone.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f46 a4,a8,a27,a68,a69,a70,a71,a285,a920,a921,a1185

To access your mailbox, press star R.

f47 a286,a287,a658,a659,a1150,a1170

Call from

f48 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159

To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star R.

f49 a603

No operator defined.

f50 a295,a296,a660,a661

Call

f51 a280

Entries deleted, please re-enter delivery time.

f53 a561

Message deleted, no delivery will occur.

f56 a285,a920,a921,a954,a955,a956

Thank you for leaving your message.

f57 a680

accessed

f58 a6,a19,a131,a328,a859,a912

For name addressing, press star A.

f59 a681,a1183,a1902,a1913

delivered

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f60 a308

Changed.

f61 a457,a458

To modify status, press Y for yes or N for no.

f62 a566,a569

Please delete unneeded messages.

f63 a183,a184,a185,a190,a235,a236,a683,a1167,a1168,
a1169,a2006,a2007,a2008,a2009,a2010,a2011

new

f64 a684

old

f65 a451,a452,a469

contains

f66 a535,a626

**If correct, press pound. If not, press star D
and re-enter time.**

f67 a559

To create another list,

f68 a685

undeliverable

f69 a686

undelivered

f70 a687

unopened

f71 a289,a290,a291,a292,a1175,a1176,a1177,a1178

To leave a message, wait for the tone.

f73 a882

You have

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f74 *a181,a187,a225,a281,a379,a380,a381,a382,a383,a384,
a385,a386,a387,a388,a389,a390,a391,a392,a393,a453,
a459,a473,a576,a908*

deleted.

f75 *a179,a913*

To skip, press pound. To delete, press star D.

f77 *a316,a317,a318*

Deleted.

f80 *a14,a15,a16,a17,a18,a61,a68,a69,a70,a71,a102,a103,
a104,a147,a152,a763,a893,a934,a935,a939,a944,a945,
a946,a947,a948,a949,a951,a952,a953,a961*

**To have system wait, press star W. If finished,
please hang up or to disconnect AUDIX, press
star star X.**

f81 *a199,a443,a514*

digits.

f82 *a504*

Please leave a message for

f83 *a320,a451,a1104*

entries.

f84 *a320,a451,a1080,a1104*

entry.

f85 *a332*

Erased.

f86 *a287,a295,a334,a335,a336,a337,a338,a506,a659,a660,
a709,a821,a915,a1150,a1151,a1170,a1171,a1900,a1902,
a1911,a1913,a2049,a2054*

extension

f87 *a812,a834*

This call is experiencing difficulties.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f88 a431

Cannot use the guest password

f89 a348

First message.

f90 a354

Enter fragment id

f91 a528

At end.

f92 a573

Nothing to advance.

f93 a362

You have no personal greeting, system greeting used.

f94 a197,a872

Good-bye.

f95 a191,a253,a258,a279,a336,a504,a565,a615,a766,a834,
a908,a954,a959,a1038,a1117,a1175,a1176,a1177,a1178

Please disconnect.

f96 a496,a694,a763,a968,a1073,a1075,a1076,a1080,a1092,
a1140

For help, press star H.

f97 a815

For help at any time, press star H.

f98 a639,a640,a741

Message not delivered due to transmission problems.

f99 a437,a969,a973

Invalid announcement.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f100 a263,a496,a970,a971

Invalid Entry.

f101 a441

Invalid fragment.

f102 a445

That is not a valid extension.

f104 a447

Message delivered, cannot listen to a delivered message.

f105 a13,a96,a97,a99,a105,a106,a116,a117,a147,a152,a171,
a172,a200,a246,a559,a630,a631,a632,a633,a1008,
a1018,a1020,a1032,a1035,a1112,a1122,a1123,a1124

To restart at the activity menu, press star R.

f108 a34,a49,a992

You are recording a message.

f109 a191,a712,a834,a877

later.

f110 a449,a450,a451,a452,a453,a454,a455,a456,a457,a458,
a459,a460,a462,a463,a465,a466,a467,a468,a469,a470,
a471,a472,a473,a474,a477,a662,a674,a836

list

f111 a29,a31,a63,a64,a478,a511,a559

Please enter list id

f112 a291,a292,a1093,a1175,a1176

Otherwise, for assistance, press zero now.

f113 a484

You already have a list

f114 a484

To replace list, re-enter id and pound sign. To create a new list, enter new list id

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f115 a116,a117,a193,a194,a195,a196,a932,a933

To transfer using names instead, press star A.

f116 a481,a482

List is full.

f117 a4,a9,a15,a68,a69,a70,a71,a79,a80,a108,a114,a116,
a121,a127,a129,a171,a193,a194,a770,a771,a932,a936,
a942,a947,a951,a952,a953,a958,a961,a2080,a2084,
a2086,a2087

To reach the covering extension, press star zero.

f118 a132,a214,a216,a222,a223,a349,a655,a770,a771,a773,
a774

Enter last name

f119 a116,a117,a171,a172,a932,a933,a936,a937

you wish to call

f120 a460,a462,a463,a470,a471,a472

too large to include.

f121 a219,a223

When finished, approve list by pressing pound.

f122 a487

List space nearly full. You may enter

f123 a487

new members.

f124 a463,a472,a476,a480,a483

No more list space.

f125 a511

Must be six or fewer numerals.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f126 a62,a85,a123,a170,a1161

To forward message with comment at end, press
3.

f127 a694

Returned to previous activity.

f128 a446,a769

To request another transfer, press star T.

f129 a446

or leave a message for

f130 a459

because there were no entries.

f131 a220

To send to others not on your list,

f132 a460,a470

You can store your list as is by pressing star
pound or add up to

f133 a480,a481

To continue reviewing, press 3. To delete an
entry, press star D. If finished reviewing,
press star pound.

f134 a462,a471

You can store your list or delete members, but
you cannot add members.

f136 a435

Line busy.

f138 a100

You are listening to machine names.

f139 a460,a470

additional members,

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f140 a322

**Entry already deleted. To delete more entries,
press star 1.**

f141 a479

No more lists.

f142 a348,a450,a454,a607,a680,a681,a682,a683,a684,a685,
a686,a687,a706,a733,a836,a924,a925,a926,a927,a928,
a929,a930,a1157,a1158,a1159,a1172,a1173,a1182,
a2068,a2069,a2070,a2072,a2073

To listen to the header, press 3.

f143 a175,a607,a733,a836,a924,a925,a926,a927,a928,a929,
a930,a1157,a1158,a1159,a1172,a1173,a1182,a2068,
a2069,a2070,a2072,a2073

To step back again, press 2.

f145 a324

List has no entries.

f146 a175,a176

To continue, press pound.

f147 a696,a697,a698

Review completed.

f148 a7,a20,a67,a132,a327,a860

For extension addressing, press star A.

f149 a436

All circuits busy.

f150 a452,a455,a456,a469

members.

f152 a505,a506

Leave Word Calling from

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f153 a510

Maximum length recorded. To re-record, press 2-1. To approve as is, press pound.

f154 a485

Cannot create new list, you have maximum lists allowed. To select lists to be deleted, press 5-1-2 and follow instructions.

f155 a486

Cannot create new list, total number of members in all your lists equals maximum allowed.

f156 a294,a513

Maximum length recorded.

f157 a310,a513,a2059

To approve as is, press the pound key.

f158 a191,a877

Transfer cannot be completed.

f159 a452,a455,a456

member.

f160 a183,a184,a185,a190,a235,a236,a1167,a1168,a1169,
a2006,a2007,a2008,a2009,a2010,a2011

message

f161 a904

midnight.

f163 a85,a168,a169,a170,a759,a760,a761,a768,a1160,a1161

To call sender, press zero.

f164 a680,a681,a682,a683,a684,a685,a686,a687

category.

f165 a527,a530,a1186,a2063,a2064

Returned to getting messages.

f166 a531

At end. To playback, press 2-3.

f167 a34,a533,a560

**To approve, press pound. To record from here,
press 1. To playback, press 2-3.**

f168 a183,a184,a185,a190,a235,a236,a538,a539,a540,a541,
a542,a543,a544,a545,a546,a548,a549,a550,a551,a552,
a553,a554,a555,a627,a1167,a1168,a1169,a2006,a2007,
a2008,a2009,a2010,a2011

messages.

f169 a577

**Admin version not specified, please do so using
administrator's terminal.**

f170 a534,a535

Delivery scheduled

f172 a539,a542,a544,a546,a548,a550,a552,a554,a627

You have new

f173 a199,a317,a431,a443,a444,a514,a586,a612

Please enter new password

f175 a349,a770,a771

**Please note only AUDIX subscribers can be
specified by name.**

f177 a574

Cannot listen to a delivered message.

f178 a575,a576

No addressees identified.

f179 a816

**Warning, if you do not supply an addressee
list, message will be deleted immediately.**

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f180 a562,a581,a611

Nothing to approve.

f182 a585,a586

Nothing to delete.

f184 a589

Nothing to erase.

f185 a229,a467,a468

not found.

f186 a584

**To record messages, press 1. To get messages,
press 2. To check your outgoing messages, press
4.**

f187 a654,a655

and not added to the list.

f188 a592

**Passwords do not match. Please re-enter new
password**

f189 a593

You have no mailbox.

f190 a594

Message delivered, you cannot change it now.

f191 a595

No more messages.

f192 a597

No messages.

f193 a598,a599,a692

No name recorded.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f194 a600

No new messages.

f196 a604

You have no personal greeting.

f197 a178,a226,a348,a454

Cannot step back.

f198 a537

Partial name deleted.

f199 a605,a606,a607

Nothing to rewind.

f200 a609

No time entered, nothing to delete.

f201 a904

noon.

f202 a338,a466,a614,a615,a754

not valid.

f203 a566

No room in your mailbox for a recording.

f207 a571

Message too long to add comment. To record a new message, press star R-1.

f208 a465,a474,a477

is not a public list.

f209 a572

Cannot modify another subscriber's list.

f210 a14,a51

Please enter a new password

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f211 a444

to fifteen digits

f212 a10,a16

**Please enter password again for confirmation.
To delete the password you just entered, press
*D**

f213 a201

Re-enter password

f214 a394,a648

Approved.

f215 a569

No room to retain a copy.

f216 a637,a638,a639,a640,a641,a642,a643,a644

originally

f217 a210,a273,a342,a343,a344,a345,a493,a673,a675,a767,
a838,a840,a841,a2018,a2019,a2020,a2021,a2022,a2035,
a2036,a2041,a2046,a2047,a2048

others

f219 a469,a470,a471,a472,a473,a474,a477

owned by

f220 a56

Enter password

f221 a57

**Enter announcement id and pound sign. Refer to
admin manual for correct id.**

f222 a58

**Enter fragment id and pound sign. Refer to
admin manual for correct id.**

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f223 a53,a59,a60,a87,a613,a627

Please enter extension

f224 a6,a7,a11,a12,a14,a19,a20,a29,a31,a32,a38,a45,a51,
a53,a54,a55,a56,a59,a60,a63,a64,a65,a66,a67,a87,
a98,a100,a116,a117,a132,a171,a172,a193,a194,a195,
a196,a199,a201,a213,a214,a216,a218,a219,a222,a223,
a234,a238,a317,a349,a354,a431,a443,a444,a466,a478,
a484,a497,a498,a509,a511,a514,a521,a559,a586,a592,
a612,a613,a621,a627,a654,a655,a724,a725,a726,a770,
a771,a773,a774,a819,a861,a889,a890,a891,a894,a912,
a932,a933,a936,a937,a940,a941,a1152

and pound sign.

f226 a455,a457,a658,a659,a660,a661,a662,a866

private

f227 a456,a458,a674

public

f228 a688

Record at the tone.

f229 a689

You will have up to

f230 a689

seconds to record.

f232 a611,a691,a692,a883

Recording stopped.

f233 a11,a12

**Previous login incorrect. Please re-enter
extension**

f234 a192,a1012,a2057

To respond or forward, press 1.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f235 a5,a9,a10,a19,a20,a24,a25,a26,a28,a30,a32,a38,a39,
a40,a41,a42,a43,a44,a45,a48,a50,a51,a57,a58,a59,
a61,a62,a63,a64,a65,a66,a67,a78,a79,a80,a83,a85,
a93,a94,a98,a100,a108,a123,a126,a128,a168,a169,
a170,a724,a726

To restart at the activity menu, press star R.
To transfer to another extension, press star T.

f236 a191,a265,a712,a834,a877

Try again

f237 a613

Or press star R.

f238 a200

To review another list,

f239 a282

followed by the pound sign.

f240 a501

To skip, press pound. To listen, press 0.

f241 a463,a472,a482,a483

To review list, press star 1.

f242 a680,a681,a682,a683,a684,a685,a686,a687

Returned to the

f243 a364,a733

Rewound.

f244 a706

Rewound to previous message.

f245 a708,a709

Please return call.

f246 a210

Message addressed to

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f247 a211

To add to list,

f248 a713

scheduled

f249 a713

To change delivery time, press star D; To approve, press pound.

f250 a714

To change delivery time, press star D.

f251 a770,a771,a773,a774

To transfer using extension instead, press star A.

f252 a192,a206,a1012,a1027,a1157,a1172,a2057,a2066,
a2068

To respond to this message, press 1.

f253 a819

Please enter month, day

f254 a93,a94

To play the active version, press 1.

f255 a530,a2064

To delete this message, press star D.

f256 a606,a699

At beginning. To re-record, press 1. To playback, press 2-3.

f257 a727

To use personal greeting, press Y. To use system greeting, press N.

f258 a342,a838

Message to

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f259 a637,a638,a639,a640,a641,a642,a643,a644,a736,a737,
a738,a739,a740,a741,a742,a743,a744,a896,a897,a974,
a2001,a2002,a2005

scheduled for

f261 a637,a638,a639,a640,a641,a642,a643,a644

rescheduled for

f262 a269,a270,a271,a272,a286,a287,a295,a296,a355,a356,
a357,a358,a489,a490,a491,a492,a505,a506,a658,a659,
a660,a661,a663,a664,a665,a666,a668,a669,a670,a671,
a676,a677,a678,a679,a745,a746,a808,a809,a810,a811,
a1150,a1170,a1900,a1901,a1911,a1912,a2014,a2015,
a2016,a2017,a2023,a2024,a2025,a2026,a2027,a2028,
a2029,a2030,a2031,a2032,a2033,a2034,a2037,a2038,
a2039,a2040,a2042,a2043,a2044,a2045,a2049

received

f263 a878,a880

You are recording a subscriber name.

f264 a637,a744

Message not delivered because mailbox was full.

f265 a637,a638

**Message not delivered because their mailboxes
were full.**

f270 a754

subscriber id

f272 a258,a593

Contact administrator for help.

f274 a70,a103,a298,a712,a762,a763,a945,a953

Please make entry soon, or be disconnected.

f275 a766

**Cannot get your messages now, due to multiple
logins to your mailbox.**

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f276 a765

Time requested has passed, please re-schedule delivery.

f277 a147,a152,a826,a934,a935

To exit directory, press pound.

f279 a853,a854

Enter announcement set and pound sign.

f281 a808,a809,a810,a811

Message from

f282 a5,a9,a10,a13,a19,a20,a24,a25,a26,a28,a30,a32,a38,
a39,a40,a41,a42,a43,a44,a45,a48,a50,a51,a57,a58,
a59,a62,a63,a64,a65,a66,a67,a76,a77,a78,a79,a80,
a83,a85,a93,a94,a96,a97,a98,a99,a100,a101,a105,
a106,a108,a113,a114,a115,a116,a117,a119,a120,a121,
a123,a125,a126,a127,a128,a129,a159,a168,a169,a170,
a171,a172,a724,a726,a932,a933,a936,a937,a938,a940,
a941,a942,a943,a960,a2077,a2078,a2079,a2080,a2081,
a2082,a2083,a2084,a2085,a2086,a2087,a2088

To have system wait, press star W. To access the names or numbers directory, press star star N. If finished, please hang up or to disconnect AUDIX, press star star X.

f283 a814

Your mailbox is more than

f284 a814

percent full. Please delete unneeded messages or greetings.

f285 a6,a19,a912

To add a member, enter extension

f286 a7,a20

To add a member, enter last name

f287 a815

Welcome to AUDIX.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f288 a147,a934

You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star A.

f290 a171,a172,a936,a937

If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star A.

f291 a4,a8,a15,a18,a68,a69,a70,a71,a77,a113,a114,a115,
a121,a125,a127,a129,a920,a921,a938,a939,a940,a941,
a942,a947,a949,a951,a952,a953,a955,a956,a957,a958,
a961,a1140,a2078,a2079,a2080,a2081,a2084,a2085,
a2086,a2087

To transfer to another extension, press star T.

f292 a24,a26,a34,a40,a41,a42,a44,a47,a49,a68,a73,a74,
a81,a86,a96,a101,a118,a122,a124,a880,a881,a925,
a926,a927,a928,a929,a930,a943,a961,a992,a1157,
a1158,a1159,a1172,a1173,a1181,a1182,a2068,a2069,
a2070,a2071,a2072,a2073,a2074

Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.

f293 a817

Nothing to playback.

f294 a40,a179

To add entries, press 1.

f295 a468,a477

To re-enter list, press star L.

f297 a55,a66

To specify owner by extension, press star A.

f298 a54,a65

To specify owner by name, press star A.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f299 a26,a50

You are administering your greeting.

f300 a904

A. M.

f301 a904

P. M.

f302 a30

You are recording announcement fragments. Enter fragment id followed by pound sign. Refer to admin manual for correct id.

f303 a32

You are recording names. Enter extension

f304 a68,a101,a880,a881,a943,a961

To playback message, press 2-3. To delete your message, press star D. To approve your message, press pound.

f305 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

You are at the activity menu.

f306 a10,a14,a16,a51

You are changing your password.

f307 a57,a93,a854

You are playing announcements.

f308 a58,a94,a853

You are playing announcement fragments.

f309 a59

You are playing names.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f310 a3

January

f311 NONE

February

f312 NONE

March

f313 NONE

April

f314 NONE

May

f315 NONE

June

f316 NONE

July

f317 NONE

August

f318 NONE

September

f319 NONE

October

f320 NONE

November

f321 NONE

December

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f322 a152,a935

You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star A.

f323 a62,a85,a123,a126,a128,a168,a169,a170,a1161

You are responding to a piece of incoming mail.

f324 a78

You are selecting which greeting will be played to callers. If you want your personal greeting to be played, press Y for yes. If you press N for no, the system greeting will be used.

f325 a137

You are administering your lists. To create a mailing list, press 1. To play a summary of all your lists, press 2. To review a particular list, press 3.

f326 a83

You are doing system administration. To record names, press 4. To play names, press 5. To record a machine name, press 6. To play a machine name, press 7. To record fragments, press 1. To play fragments, press 2. To play announcements, press 3.

f327 a19,a20,a45

You are creating a mailing list.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f328 a6,a7,a19,a20,a912

To delete the previous entry, press star D. To add a mailing list you have already created, or a public list owned by others, press star L. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound.

f329 a45,a67,a861,a1152

You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9.

f330 a12,a87

Or enter just the pound sign if it's your phone.

f331 a790

Personal greeting used.

f332 a380,a381,a382,a383,a384,a385,a386,a387,a388,a389,
a390,a391,a392,a393,a792,a793,a794,a795,a796,a797,
a798,a799,a800,a801,a802,a803,a804,a805,a806

System greeting used.

f333 a44,a913

To add entries to the list or to change status of list, press 1.

f334 a212

When finished addressing, press pound.

f335 a194,a196,a218,a222,a771,a774

When finished, press pound.

f336 a211

To review addressees, press star 1.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f338 a93,a94

To play the admin version, press 2.

f339 a24,a26,a34,a47,a73,a74,a86,a96,a118,a122,a124,
a880,a881,a924,a925,a926,a927,a928,a929,a992,a1157,
a1158,a1159,a1172,a1173,a2068,a2069,a2070,a2071,
a2072,a2073,a2074

**To replay the last few seconds, press 5. To
advance a few seconds, press 6.**

f340 a84

**Enter the hour, one through twelve, then two
digits for the minutes, then A for AM or P for
PM, and the pound sign.**

f341 a33

**Enter the number of the month, one through
twelve, then two digits for the day of the
month, then the pound sign.**

f342 a541,a542,a545,a546,a549,a550,a553,a554

Electronic document communication

f343 a539,a540,a541,a542,a543,a544,a545,a546,a555

Leave word calling

f344 a543,a544,a545,a546,a551,a552,a553,a554

Message Center Service

f345 a184,a185,a190,a236

Voice mail

f346 a879,a881

You are recording a machine name.

f347 a29,a31,a54,a55

You are adding a list.

f348 a63,a64,a65,a66,a67

You are specifying a mailing list to review.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f349 a463,a472,a482,a483,a654,a655

To approve list as is, press pound.

f350 a3

Sunday

f351 NONE

Monday

f352 NONE

Tuesday

f353 NONE

Wednesday

f354 NONE

Thursday

f355 NONE

Friday

f356 NONE

Saturday

f357 a61,a939

You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star D. To change to extension addressing and delete your entry, press star A.

f358 a39

You are identifying a list as private or public.

f359 a43

You are changing the status of your list. To modify status, press Y for yes or N for no.

f360 a41

You are scanning mailing lists. To review list members, press 0. To rewind to previous list, press 2. To continue scanning lists, press 3.

f361 a41

To skip to next list, press pound. To delete list, press star D.

f362 a54,a55,a65,a66

If you own the list, press pound. If someone else owns the list

f363 a29,a31,a63,a64

To approve the list you are creating, press pound.

f364 a54,a65,a497,a890

enter owner's extension

f365 a55,a66

enter owner's name

f366 a29,a63

To specify a different owner by extension, press star D.

f367 a31,a64

To specify a different owner by name, press star D.

f368 a38

You are entering the number for a new list. Please enter a number up to six digits long

f369 a38

To replace an existing list, enter that list's number,

f370 a40,a44

These are entries in your list.

f371 a40,a42,a44

To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3.

f372 a40,a44,a157,a228

To skip to next entry, press pound. To delete current entry, press star D.

f373 a25

You are choosing whether to attach a copy of original message to your reply. To include the original, press Y for yes. To send only your reply, press N for no.

f375 a124,a924,a926

You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1.

f376 a73,a81,a86,a124,a1157,a1158,a1172,a1181,a2068,
a2069,a2071,a2074

To skip to the next header, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.

f377 a73,a86,a118,a122,a124,a924,a925,a926,a927,a928,
a929,a1157,a1158,a1159,a1172,a1173,a1181,a1182,
a2068,a2069,a2070,a2071,a2072,a2073,a2074

To delete message, press star D.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f378 *a73,a81,a86,a928,a929,a930,a1181,a1182,a2071,a2072,
a2073,a2074*

You are checking the status of your outgoing messages.

f379 *a81,a930*

To delete status information, press star D.

f380 *a69,a71,a102,a104,a299,a775,a813,a944,a946,a951,
a952*

Please wait.

f381 *a86,a928*

To listen to the message, press 0. To re-record message before delivery, press 1.

f382 *a33,a84*

You are scheduling your message for delivery.

f383 *a266,a862,a863*

Please enter hour, then two digits for minutes, then A for am or P for pm, and pound sign.

f384 *a90,a92,a161,a261*

Please enter number of month, then two digits for day, and pound sign.

f385 *a75*

To approve delivery time, press pound. To modify delivery time, press star D and listen for further instructions.

f386 *a520*

Cannot change a delivered message.

f387 *a641,a642,a742*

Message not delivered because recipient not found.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f388 a42,a180,a192,a206,a276,a315,a346,a507,a508,a527,
a530,a730,a924,a925,a926,a927,a928,a929,a930,a1011,
a1012,a1027,a1157,a1158,a1159,a1172,a1173,a1182,
a2057,a2058,a2060,a2061,a2062,a2063,a2064,a2066,
a2068,a2069,a2070,a2072,a2073

To skip, press the pound key.

f390 a820,a843,a903

oh

f391 a844,a2051,a2052,a2053

one

f392 a845

two

f393 a846

three

f394 a847

four

f395 a848

five

f396 a849

six

f397 a850

seven

f398 a851

eight

f399 a852

nine

f400 a972

ten

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f401 *NONE*
eleven

f402 *NONE*
twelve

f403 *NONE*
thirteen

f404 *NONE*
fourteen

f405 *NONE*
fifteen

f406 *NONE*
sixteen

f407 *NONE*
seventeen

f408 *NONE*
eighteen

f409 *NONE*
nineteen

f410 *NONE*
twenty

f411 *NONE*
twenty-one

f412 *NONE*
twenty-two

f413 *NONE*
twenty-three

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f414 *NONE*

twenty-four

f415 *NONE*

twenty-five

f416 *NONE*

twenty-six

f417 *NONE*

twenty-seven

f418 *NONE*

twenty-eight

f419 *NONE*

twenty-nine

f420 *NONE*

thirty

f421 *NONE*

thirty-one

f422 *NONE*

thirty-two

f423 *NONE*

thirty-three

f424 *NONE*

thirty-four

f425 *NONE*

thirty-five

f426 *NONE*

thirty-six

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f427 *NONE*

thirty-seven

f428 *NONE*

thirty-eight

f429 *NONE*

thirty-nine

f430 *NONE*

forty

f431 *NONE*

forty-one

f432 *NONE*

forty-two

f433 *NONE*

forty-three

f434 *NONE*

forty-four

f435 *NONE*

forty-five

f436 *NONE*

forty-six

f437 *NONE*

forty-seven

f438 *NONE*

forty-eight

f439 *NONE*

forty-nine

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f440 NONE

fifty

f441 NONE

fifty-one

f442 NONE

fifty-two

f443 NONE

fifty-three

f444 NONE

fifty-four

f445 NONE

fifty-five

f446 NONE

fifty-six

f447 NONE

fifty-seven

f448 NONE

fifty-eight

f449 NONE

fifty-nine

f450 a820

sixty

f451 NONE

seventy

f452 NONE

eighty

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f453 *NONE*
ninety

f454 *a901*
hundred

f455 *a906*
thousand

f456 *a906*
million

f462 *a824*
pound

f463 *a823*
star

f464 *a213,a218,a219,a654*
Enter extensions

f466 *a735*
created

f468 *a488,a749*
To continue playing, press 3.

f470 *a498,a891*
Enter owner's last name

f471 *a497,a498,a890,a891*
If it's your list, press pound.

f472 *a326,a749*
**To approve, press pound. To record from here,
press 1.**

f473 *a532,a682*
filed

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f474 a73,a346,a507,a929

To listen, press 0. To change or send again,
press 1.

f475 a751

To file a copy, press Y for yes or N for no.

f477 a717,a963

Press 1 to select

f478 a718,a964

2 to select

f479 a719,a965

3 to select

f482 a724,a725,a726,a827,a940,a941

Press pound to select

f483 a724,a725,a726,a827,a940,a941

or enter more characters

f484 a45,a67,a521,a861,a1152

Enter more characters followed by the pound
sign; if you just completed entering the last
name, enter the first name.

f485 a455,a456

has

f486 a62,a85,a126,a168,a204,a693,a760,a768,a1160,a1161

To reply to sender by voice mail, press 1.

f487 a33

To delete time, press star D. To default rest
of the delivery time, press pound.

f488 a84

To specify immediate delivery, press pound.
Otherwise

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f492 a448

Owner erased.

f493 a116,a117,a171,a172,a932,a933,a936,a937

You are requesting a transfer.

f498 a466,a889

Please enter a new list id

f499 a750,a990

When finished recording, press # to approve, or 1 to edit your message.

f500 a627

This is AUDIX.

f501 a723

To record messages, press one. To get messages, press two. To administer attendant menu, press 3.

f502 a24,a96,a246

To record attendant menu, press 1. To listen to attendant menu, press 0.

f503 a24,a96

You are administering your attendant menu.

f504 a252

Transferring to an operator,

f505 a248

You have selected an invalid option.

f506 a247

Menu approved and activated.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f507 a282,a297,a298

The person you called is not available. To leave a message, use touch tones to re-enter the number you called.

f508 a253

Attendant Service not available, try again later.

f509 a601

System not administered for outcalling.

f510 a614,a615,a886

Number

f511 a299,a712

If you do not have a touch tone phone,

f512 a772

Your call is being transferred to an operator.

f513 a279

Begin your message by saying the name and telephone number of the person you are calling. Someone will listen to the start of your message, and then forward the complete message to the person you called.

f514 a712,a990

otherwise

f515 a71,a104,a775,a946,a951

To be transferred to an operator,

f516 a69,a102,a944,a952

To leave a message that will be delivered as soon as possible,

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f517 a69,a70,a71,a102,a103,a104,a944,a945,a946,a951,
a952,a953

You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.

f518 a68,a101,a943,a961

You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.

f519 a628

You are not authorized for outcalling.

f520 a629,a630,a631,a632,a633

Your outcalling number,

f521 a618,a619,a630,a631,a632,a633

turned on

f522 a617,a629

turned off to restart at the activity menu, press star R.

f523 a630,a631,a632,a633,a1097

for

f524 a22,a237,a625,a626,a631,a633,a656,a657,a758

to

f525 a624,a630,a632

any time

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f526 a624,a625,a626,a630,a631,a632,a633

subject to administrator restrictions

f527 a28,a97,a108,a307,a629,a630,a631,a632,a633

To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3.

f528 a28,a97,a108,a307,a629,a630,a631,a632,a633

To turn on, press y. To turn off, press n.

f529 a28,a97,a108

You are changing your outcalling options.

f530 a617,a618,a619

Outcalling

f531 a621

Enter outcalling number

f532 a620

To change your outcalling phone number, press 1 and enter the number to be called followed by the pound sign. Anything you enter will be interpreted as a part of the called number. No global commands such as star H will be accepted at this time.

f533 a764

Too many digits.

f534 a623

Your outcalling number is

f535 a80,a106,a616

For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.

f536 a79,a80,a105,a106

You are specifying your outcalling time period.
The time you specify will be restricted by the
times allowed by the system administrator.

f537 a734

Enter the starting hour, minutes, A or P, and
pound sign.

f538 a325

Enter the ending hour, minutes, A or P, and
pound sign.

f539 a758

The system allows outcalls from

f540 a237

and from

f541 a781

Up to

f542 a781

digits may be used.

f543 a53,a627

To avoid further notification of these
messages, press star pound.

f544 a624,a625,a626

Outcalling specified for

f545 a79,a105

To delete own time, press star D.

f546 a825

pause

f548 a582

You have no attendant menu.

f549 a48,a99

You are administering your attendant menu. To create attendant menu, press 1.

f550 a24,a96

To rewind your attendant menu, press two. To delete it, press star D. To stop playback of your attendant menu, press three.

f551 a53,a627

To access your messages,

f552 a334,a335,a336

is not authorized to receive messages.

f553 a335

You may enter another number

f555 a15,a17,a18,a101,a102,a103,a104

To access your mailbox, press star R.

f556 a621,a1015

To exit, press star pound now.

f557 a620

In most cases, entering a star or pound as the first digit will result in the star or pound being outpulsed. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f560 a620

If you are programming a number to call a pager that requires a pound sign termination, press y to hear further help. Otherwise, press n to return to outcalling administration.

f561 a6,a7,a912

You are addressing your message.

f562 a116,a117,a193,a194,a195,a196,a894,a932,a933

Enter the

f563 a116,a117,a193,a194,a195,a196,a932,a933

digit extension

f565 a309

Outcall canceled for new messages currently in mailbox.

f566 a53

You are responding to an outcall notifying you of new messages.

f567 a53

Either logging in or pressing star pound will result in the outcall being canceled for the new messages currently in your mailbox. If additional new messages arrive, another outcall will be scheduled."

f569 a697

To modify, press one. If finished, press star pound.

f570 a512,a883

Recorded name too long

f571 a610

Non-existent subscriber

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f575 a590

Cannot forward a private message

f577 a118,a122,a124,a924,a925,a926,a927,a1157,a1158,
a1159,a1172,a1173,a2068,a2069,a2070

**To hold the message in its current category,
press star star H**

f578 a924,a925,a926,a927,a928,a929,a930,a1157,a1158,
a1159,a1172,a1173,a1182,a2068,a2069,a2070,a2072,
a2073

To skip to the next category, press star pound.

f579 a443,a444

Password must be

f580 a250,a251

Cannot attach a private message

f581 a251

Press N now

f582 a514

AUDIX passwords must now be at least

f584 a643,a644,a743

**Message not delivered because special feature
denied on recipients machine.**

f585 a873,a1009,a1011,a1037,a1104

Zero

f587 a42

You are reviewing a list.

f588 a514

or more digits.

f589 a622

For pagers requiring a pound sign termination, start your number with a double pound sign. This will result in a single pound being outputted at the end of the digit string. Then, a star or pound in the next position will be interpreted as part of the outcalling number.

f590 a622

A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f591 a52

To change your outcalling phone number, press one. To hear further instructions on programming a pager, press y. To return to outcalling administration, press n.

f592 a199

AUDIX passwords must now be

f593 a199,a514

Please choose a new password of

f600 a557

new Broadcast messages.

f601 a183,a184,a190,a235,a875,a1169,a2006,a2010

Priority

f602 a210,a236,a273,a342,a343,a344,a345,a493,a673,a675,
a767,a838,a840,a841,a2011,a2018,a2019,a2020,a2021,
a2022,a2035,a2036,a2041,a2046,a2047,a2048

other

f603 a538,a540,a541,a543,a545,a549,a551,a553,a555

You also have

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f604 a690

As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1, and at the tone, please speak your name. After speaking your name, press 1 again.

f606 a241

To re-record your name, press 1. To approve, press pound.

f607 a650

Name cannot be saved at this time, please continue

f608 a167,a599,a692,a883

At the tone, please speak your name. After speaking your name, press 1.

f609 a583

No room to save Broadcast message so it will be retained in the new message category.

f610 a150

You are recording your name. After you record your name, you can access other AUDIX features. As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1 and at the tone, please speak your first and last name as you would like others to hear it. After speaking your name, press 1 again.

f611 a151

You are recording your name. To record your name, press 1. After recording, press 1 again. To playback name, press 2-3. To approve, press pound.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f612 a149,a519

To make private, press 1.

f613 a518,a1149

To make priority, press 2.

f614 a515

To make broadcast, press 8.

f615 a516

To make a login announcement, press 9.

f617 a705,a919

To remove private status, press 1.

f618 a704,a1165

To remove priority status, press 2.

f619 a700

To remove broadcast status, press 8.

f620 a701

To remove login announcement status, press 9.

f622 a876

not Priority.

f623 a275

Broadcast.

f624 a495

Login announcement.

f625 a208,a831,a833

To activate message waiting notification, press
1.

f626 a143,a146,a731,a732,a831,a832,a833

To specify expiration date, press 2.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f627 a239,a832,a833

To approve broadcast options, press pound.

f628 a146,a311,a832

To deactivate message waiting notification,
press 1.

f629 a716

Please enter month, day, and pound sign.

f630 a303

To change expiration date from

f631 a227,a536

Message waiting notification activated.

f632 a227,a333

Expiration date will be

f633 a517

To make non-interruptible, press 1.

f634 a240,a732

To approve login announcement options, press
pound.

f635 a702

To remove non-interruptible status, press 1.

f636 a564

Login announcement will be non-interruptible.

f637 a438,a439,a440

Invalid date.

f638 a440

is prior to delivery date, please re-schedule.

f639 a260

Message cannot be both broadcast and priority.

f640 a256

Message cannot be both a login announcement and priority.

f641 a257

Message cannot be both a login announcement and private.

f642 a259

Message cannot be both broadcast and a login announcement

f643 a149

You are choosing options for this message. There are no options currently set.

f644 a155

You are choosing options for this message. With the current settings,

f645 a145,a149

Private messages cannot be forwarded by the recipients.

f646 a144,a1166

A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.

f647 a842

the message will be private.

f648 a156

the message will be priority.

f649 a135

the message will be broadcast.

f650 a139

the message will be a login announcement.

f651 a164

the message will be private and priority.

f652 a140

A broadcast message is delivered to every subscriber on this machine. You may also address a broadcast message to subscribers on other machines.

f653 a274

For broadcast options, press star M.

f654 a134

the message will be broadcast and private.

f655 a141

A login announcement will be played each time any subscriber logs onto this machine. You may also address a login message to subscribers on other machines.

f656 a494

For login announcement options, press star M.

f657 a133

You are choosing options for this broadcast message.

f658 a831

Message waiting notification is currently not active.

f659 a130,a146,a831

Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance.

f660 a160,a161

Expiration date specifies the last day this broadcast message will be available to subscribers. The expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date.

f661 a143,a160,a163

To approve these options, press pound.

f662 a146

Message waiting notification is active.

f663 a110

Message waiting notification is not active and this message has an expiration date of.

f664 a112

Message waiting notification is active and this message has an expiration date of.

f665 a138

You are choosing options for this login announcement.

f666 a148

With the current settings, this login announcement will be non-interruptible.

f668 a111

With the current settings, this login announcement will be non-interruptible and the login announcement has an expiration date of.

f669 a109

With the current settings, this login announcement will be interruptible and the login announcement has an expiration date of.

f670 a142,a143

Non-interruptible status forces each subscriber to listen to the entire login announcement every time they log onto this machine.

f671 a143,a163

Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date.

f674 a729,a931

Due to sending restrictions, you cannot send messages to

f678 a439

is past the expiration date, please reschedule.

f679 a182,a293

is not available. Sorry, you cannot leave a message now because this user's mailbox is full.

f680 a177,a288

is busy. Sorry, you cannot leave a message now because this user's mailbox is full.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f681 a647

Sorry, cannot leave a message now because this user's mailbox is full.

f682 a269,a270,a271,a272

Broadcast message from

f683 a268

Broadcaster has deleted this broadcast message.

f684 a355,a356,a357,a358

Private, broadcast message from

f685 a676,a677,a678,a679

Private, priority message from

f686 a663,a664,a665,a666

Private message from

f687 a779

Undeliverable message notification received

f688 a778

An undeliverable message was returned to your outgoing mailbox. To access your outgoing mailbox, press star R 4.

f689 a270,a272,a356,a358,a490,a492,a638,a640,a642,a644,
a664,a666,a669,a671,a677,a679,a737,a746,a809,a811,
a2015,a2017,a2024,a2026,a2028,a2030,a2032,a2034,
a2038,a2040,a2043,a2045

Expiration time is

f690 a668,a669,a670,a671

Priority message from

f691 a489,a490,a491,a492

Login announcement from

f693 a273

Broadcast message to all local subscribers

f694 a675

Private, broadcast message to all local subscribers

f695 a344,a767

Private, priority message to

f696 a343,a840,a841

Private message to

f697 a493

Login announcement to all local subscribers

f698 a345,a673

Priority message to

f699 a739

Message not delivered because another login announcement is active.

f700 a165,a166,a755,a756,a2089,a2090,a2091,a2092

To administer mailing lists, press 1. To administer personal directory, press 2.

f701 a165,a166,a755,a756,a2089,a2090,a2091,a2092

To change your password, press 4.

f702 a166,a756,a2090,a2092

To record your name, press 5.

f703 a165,a166,a2089,a2090

You are at subscriber administration.

f704 a503

To create lists, press 1. To scan lists, press 2. To review and modify lists, press 3.

f705 a320

Directory contains

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f706 a136,a319

To add entries, press 1. To review all entries,
press 2. To review a specific entry, press 3.

f707 a74,a525,a1080,a1084

If finished, press star pound.

f708 a215,a216,a330,a331

If finished adding entries, press pound.

f709 a234

Enter alias for

f710 a331,a860

Enter next name and pound sign.

f711 a224,a225,a226,a228,a229,a917

Alias

f712 a224,a225,a226,a228,a917

defined for

f713 a330

Enter next extension and pound sign.

f714 a587

Directory has no entries.

f715 a360,a361

Cannot add new entries because your directory
is full.

f716 a231,a232

Alias must be ten or fewer numerals.

f717 a233

Alias already defined.

f718 a653

Name entered not followed by pound and not added to the directory.

f719 a652

Extension entered not followed by pound and not added to the directory.

f720 a651

Alias entered not followed by pound and not added to the directory.

f722 a188,a361

was not added to your personal directory.

f723 a136

You are administering your personal directory.

f724 a321

Personal directory review completed.

f725 a131,a132

You are adding entries to your personal directory.

f726 a157

You are reviewing all entries in your personal directory.

f727 a232,a327,a328,a329

Enter alias and pound sign.

f729 a158

You are reviewing a specific entry in your personal directory. To delete the current entry, press star D. To review another entry, enter the alias followed by the pound sign.

f730 a738

Message not delivered because the broadcast mailbox was not defined.

f736 a167

You are recording your name. As you use AUDIX your name will be included in system announcements that you and other people will hear.

f737 a434

Login announcement will be interruptible.

f738 a740

Message not delivered due to sending restrictions.

f739 a342

Message sent to all local subscribers.

f740 a343

Private message sent to all local subscribers.

f741 a344

Private, priority message sent to

f742 a840

Private message sent to

f743 a345

Priority message sent to

f744 a230

For all calls,...

f745 a1,a230,a278,a339,a350,a351,a352,a353,a411,a412,
a413,a414,a415,a416,a417,a418,a419,a420,a421,a422,
a423,a424,a433,a579,a645

active.

f747 a433

For internal calls,...

f748 a339

For external calls,...

f749 a278

For busy calls,...

f750 a579

For no answer calls,...

f751 a645

For out-of-hours calls,...

f752 a425

To listen to a greeting, press 0. To create, change, or delete a greeting, press 1. To scan all your greetings, press 2. To activate a greeting, press 3. To administer call types, press 4. If finished, press pound.

f753 a35,a36,a428

Enter greeting number.

f754 a88,a230,a278,a339,a350,a351,a352,a353,a365,a366,
a367,a368,a369,a370,a371,a372,a373,a374,a375,a376,
a377,a378,a379,a380,a381,a382,a383,a384,a385,a386,
a387,a388,a389,a390,a391,a392,a393,a394,a395,a396,
a397,a398,a399,a400,a401,a402,a403,a404,a405,a406,
a407,a408,a409,a410,a411,a412,a413,a414,a415,a416,
a417,a418,a419,a420,a421,a422,a423,a424,a433,a579,
a645,a830

Greeting

f755 a395

not recorded.

f756 a74,a426,a427,a525

To listen to greeting

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f757 a429,a430,a1124

To re-record, press 1.

f759 a430

To review status, press 2.

f760 a74,a426,a427,a525

press 0.

f762 a303

press 2.

f764 a787,a788,a828

**To use this greeting for all calls, press 0.
For internal calls, press 1. For external calls,
press 2.**

f765 a396

recorded, but not active

f766 a88,a783

To use this greeting for all calls, press 1.

f767 a785,a786,a829

**To use this greeting for all calls, press 0.
For busy calls, press 1. For no answer calls,
press 2.**

f770 a397,a398,a399,a400,a401,a402,a403,a404,a405,a406,
a407,a408,a409,a410

recorded and active

f771 a365,a366,a367,a368,a369,a370,a371,a372,a373,a374,
a375,a376,a377,a378

approved and active

f772 a426

again

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f773 a828,a829

To activate for out-of-hours calls, press 3.

f774 a143,a160,a161,a163,a341,a980

If you have addressed this message and wish to deliver it immediately, press star star pound.

f775 a728

To record messages, press one. To get messages, press two. To administer personal greetings, press 3.

f776 a1,a230,a278,a339,a350,a351,a352,a353,a433,a579,
a645

the system greeting

f777 a522

Cannot listen to system greeting.

f778 a523

Cannot modify system greeting.

f779 a596

No greetings recorded.

f780 a524

Personal greetings review completed.

f781 a74,a525

To skip to the next greeting, press the pound sign.

f782 a789

To activate a greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f783 a784

To activate another greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.

f784 a784,a789

To activate system greeting, enter zero.

f785 a23,a710,a711

Same greeting used for all calls.

f786 a23,a711

To identify calls as internal and external, press 1.

f787 a23,a711

To identify calls as busy and no answer, press 2.

f788 a22,a432,a657

To identify calls as out-of-hours, press 3.

f789 a22,a657

Otherwise, press 4.

f790 a244,a245

Calls identified as internal and external.

f791 a242,a243

Calls identified as busy and no answer.

f792 a242,a244

Calls identified as out-of-hours.

f793 a243,a245

Calls not identified as out-of-hours.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f794 a300

To change identification to busy and no answer,
press 2.

f795 a304

To change to identification internal and
external, press 1.

f796 a703

To remove out-of-hours identification, press 4.

f797 a791

To use same greeting for all calls, press 5.

f798 a22,a656,a657

Prime time is

f800 a161

You are specifying the expiration date.

f801 a314

To respond to this notification, press one. To
delete, press star D. To skip, press pound.

f802 a707

Cannot send a message to the broadcast mailbox.

f805 a352,a353

For internal...

f807 a350,a351

For busy...

f810 a352,a353,a372,a375,a387,a390,a404,a407,a418,a421,
a800,a803

external

f812 a350,a351,a366,a369,a381,a384,a398,a401,a412,a415,
a794,a797

no answer

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f813 a351,a353,a367,a369,a370,a373,a375,a376,a382,a384,
a385,a388,a390,a391,a399,a401,a402,a405,a407,a408,
a413,a415,a416,a419,a421,a422,a795,a797,a798,a801,
a803,a804

and out-of-hours

f814 a350,a351,a352,a353,a366,a367,a368,a369,a370,a371,
a372,a373,a374,a375,a376,a377,a378,a381,a382,a383,
a384,a385,a386,a387,a388,a389,a390,a391,a392,a393,
a398,a399,a400,a401,a402,a403,a404,a405,a406,a407,
a408,a409,a410,a412,a413,a414,a415,a416,a417,a418,
a419,a420,a421,a422,a423,a424,a794,a795,a796,a797,
a798,a799,a800,a801,a802,a803,a804,a805,a806

calls.

f815 a46

You are administering your personal greetings.

f816 a35

You are listening to a personal greeting.

f817 a36

You are recording a personal greeting.

f818 a88,a830

You have just recorded

f819 a74

You are scanning your personal greetings.

f820 a37

You are selecting which greeting to activate.

f821 a21,a22,a23

You are administering call types.

f822 a174

As you use AUDIX your name will be included in system announcements that you and other people will hear. At the tone, please speak your name. After speaking your name, press one.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f823 a1,a365,a380,a397,a411,a793

...for all calls

f825 a372,a373,a374,a375,a387,a388,a389,a390,a404,a405,
a406,a407,a418,a419,a420,a421,a800,a801,a802,a803

...for internal

f826 a370,a371,a385,a386,a402,a403,a416,a417,a798,a799

...for external

f827 a366,a367,a368,a369,a381,a382,a383,a384,a398,a399,
a400,a401,a412,a413,a414,a415,a794,a795,a796,a797

...for busy

f828 a376,a377,a391,a392,a408,a409,a422,a423,a804,a805

...for no answer

f829 a378,a393,a410,a424,a806

...for out-of-hours

f830 a560

You must approve your recording.

f831 a161

To exit the expiration date options, press star pound.

f832 a131,a215,a859

Please enter extension and pound sign.

f833 a131,a132,a327,a328,a895

To delete current entry, press star D.

f835 a618,a630,a631

for all new messages

f836 a619,a632,a633

only for new priority messages

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f837 a634

To turn on Outcalling for all new messages,
press 1. To turn on outcalling only for new
priority messages, press 2.

f838 a153

You are selecting which messages will receive
outcalls.

f839 a74

To rewind to the previous greeting, press 2.

f840 a636

Option

f841 a337,a636

not defined

f842 a565

Announcement not recorded. Try again later.

f843 a254,a837

To scan headers and messages, press 1. To scan
headers only, press 2. To scan messages only,
press 3.

f844 a529

End of message.

f845 a558

Next message.

f846 a837

You are selecting an option for Automatic
Message Scan.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f847 a118,a927,a1159,a1173,a2070

You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press one.

f848 a122,a925,a1159,a1173,a2070

You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press one.

f849 a118,a122,a1159,a1173,a2070

To skip to the next message, press the pound sign. To listen to the header, rewind by pressing two, then play by pressing three. To skip to the next category, press star pound.

f850 a563

Broadcast and Login Message services are not available.

f852 a157

To rewind to the current entry, press two. To rewind to previous entries, press two as many times as necessary.

f853 a962

Messages skipped, retained as new.

f854 a882

seconds to finish recording.

f855 a894,a895

remote AMIS mailbox id

f856 a892,a893

This is a recorded message from

f858 a907

To replay, press 0.

f859 a909

Mailbox id not followed by pound.

f860 a910

Mailbox id not valid.

f861 a886,a915,a931

AMIS

f862 a896

It could not be delivered because the recipient appears to be a wrong number.

f863 a897

It could not be delivered after multiple attempts to deliver the message.

f864 a898

Automated call, please press 1 to disconnect.

f865 a899

Your number was dialed by mistake. We are sorry for this inconvenience. To prevent this from recurring, this call has been reported as a misdialed call.

f866 a911

AMIS casual subscribers cannot be added to your list.

f867 a895

You are entering the

f868 a895,a912

Mailbox id must be less than or equal to 16 digits.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f869 a912

If the extension entered belongs to a casual AMIS subscriber, you will be prompted for a mailbox id.

f900 a855

Standard US English

f901 a856

Announcement set does not exist

f902 a857

Announcement set

f903 a1190

<.1 second pause>

f904 a1191

<.2 second pause>

f905 a269,a270,a271,a272,a355,a356,a357,a358,a489,a490,
a491,a492,a663,a664,a665,a666,a676,a677,a678,a679,
a718,a719,a808,a809,a810,a811,a964,a965,a1010,
a1150,a1151,a1170,a1171,a1192,a2014,a2015,a2016,
a2017,a2023,a2024,a2025,a2026,a2027,a2028,a2029,
a2030,a2031,a2032,a2033,a2034,a2037,a2038,a2039,
a2040,a2042,a2043,a2044,a2045,a2049,a2054

<.5 second pause>

f906 a858,a1193

<1.0 second pause>

f907 a1090,a1194

<2.0 second pause>

f908 a1144,a1195

<5.0 second pause>

f909 a858

Announcement

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f910 a92,a305,a306,a859,a860,a861,a863

You are playing an announcement which need additional input before it can be played.

f911 a301,a305

Enter buttons followed by pound.

f912 a302,a306

Enter number followed by pound.

f913 a35,a36,a88,a131,a132,a136,a319,a327,a328,a329,
a429,a430,a783,a784,a786,a788,a789,a791,a828,a829,
a1074,a1102,a1137

If finished, press pound.

f914 a864

not filed.

f915 a865

No options menu available.

f916 a154

To send message, press pound or enter an option,
to hear a list of options, press zero.

f917 a277

To schedule delivery, press 3.

f918 a667

To re-schedule delivery, press 3.

f919 a672

To file a copy, press 4.

f920 a748

To not file a copy, press 4.

f921 a868

To make private, press 1. To send, press #.

f922 a869

To access the Delivery Options Menu, press #
after recording your message.

f923 a870

Press # to approve your message and access the
Delivery Options Menu

f924 a873,a972

seconds

f925 a873

minutes

f926 a871,a2000,a2067,a2099

<error sound>

f928 a556

New Messages

f929 a635

Old Messages

f930 a207

Accessed Messages

f931 a313

Delivered Messages

f932 a347

Filed Messages

f933 a776

Undeliverable Messages

f934 a777

Undelivered Messages

f935 a780

Unopened Messages

f936 a2

Partial entry deleted.

f937 a872

Sorry you are having difficulty. Please get help and try again later.

f938 a905

first

f939 NONE

second

f940 NONE

third

f941 NONE

fourth

f942 NONE

fifth

f943 NONE

sixth

f944 NONE

seventh

f945 NONE

eighth

f946 NONE

ninth

f947 NONE

tenth

f948 NONE

eleventh

f949 *NONE*

twelfth

f950 *NONE*

thirteenth

f951 *NONE*

fourteenth

f952 *NONE*

fifteenth

f953 *NONE*

sixteenth

f954 *NONE*

seventeenth

f955 *NONE*

eighteenth

f956 *NONE*

nineteenth

f957 *NONE*

twentieth

f958 *NONE*

twenty-first

f959 *NONE*

twenty-second

f960 *NONE*

twenty-third

f961 *NONE*

twenty-fourth

f962 NONE

twenty-fifth

f963 NONE

twenty-sixth

f964 NONE

twenty-seventh

f965 NONE

twenty-eighth

f966 NONE

twenty-ninth

f967 NONE

thirtieth

f968 NONE

thirty-first

f969 a867

You are choosing between announcement sets whose names match your entry. To indicate no announcement sets match, delete entry by pressing star D.

f970 a476

To continue reviewing, press 3. To delete an entry, press star D. If finished reviewing, press pound.

f971 a340,a341,a919,a985

To send, press #.

f972 a921,a956

To reach the covering extension, press zero.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f973 a285,a920,a921,a955,a956,a1073,a1074,a1185

If you are finished, please hang up, or press
star, star X.

f974 a922

Not broadcast.

f975 a923

Not login announcement.

f977 a752

Name not found.

f978 a886

unknown

f979 a878,a880

After recording, press 1 again

f980 a878,a880

To record from here, press 1

f981 a974

Message not delivered because it was longer than
the 8 minute AMIS message limit.

f983 a76,a127

To record and send voice mail messages, press
1. To get messages, press 2. To record or change
the greeting heard by callers, press 3.

f984 a77,a114,a120

To record and send voice mail messages, press 1.
To get messages, press 2. To administer
attendant menu, press 3.

f985 a119,a125,a129

To record and send voice mail messages, press 1.
To get messages, press 2.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f986 a115,a121,a159

To record and send voice mail messages, press 1.
To get messages, press 2. To record or change
the greetings heard by callers, press 3.

f987 a171,a172,a936,a937

Enter last name of the person

f988 a990

To send only a fax, press pound.

f989 NONE

Otherwise, when finished recording, press pound
to approve, or 1 to edit your message.

f990 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

To record and send voice mail messages, press 1.

f991 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

To record and send voice mail or fax messages,
press 1.

f992 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

To get messages, press 2.

f993 a1170

Private, priority fax call from

f994 a1170

Private, priority voice and fax call from

f995 a1170

Private fax call from

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f996 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

To check your outgoing messages, press 4.

f997 a1174

**To administer mailing list, personal directory,
password, or account name, press 5.**

f998 a1170

Private voice and fax call from

f999 a1174

**To administer mailing list, personal directory,
password, fax options, or account name, press 5.**

f1000 a973,a1170

Priority fax call from

f1001 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

**To change outcalling information, press 6. To
scan incoming messages automatically, press 7.
To re-logon, press star star R.**

f1002 a154

To hear a list of options, press 0.

f1003 a1170

Priority voice and fax call from

f1004 a49,a68,a101,a943,a961,a992

**To bypass voice recording and create a fax only
message, press pound.**

f1005 a154

**Load your document into the FAX machine. To
send, press pound or enter an option.**

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1006 a76,a115,a121,a127,a159,a2077,a2081,a2084,a2086,
a2088

**To record or change the greeting heard by
callers, press 3.**

f1007 a310,a812,a2059

To playback, press 2-3.

f1008 a988

To include a fax, press 5.

f1009 a989

To no longer include a fax, press 5.

f1010 a1167,a1168,a2007,a2009

with priority.

f1011 a185,a235,a236,a1167,a1168,a1169,a2006,a2007,a2008,
a2009,a2010,a2011

with fax.

f1012 a907,a991

Press START on your fax machine now.

f1013 a77,a114,a120,a2078,a2080,a2083

To administer attendant menu, press 3.

f1014 a984

Fax will be included.

f1015 a983

Fax will not be included.

f1016 a113,a2079

To administer your greeting, press 3.

f1017 a987

A login announcement must be voice only.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1018 a986

Load your document into the FAX machine, To send, press pound.

f1019 a982,a1028

Cannot replace or modify an existing fax.

f1020 a981

No message to send.

f1021 a1171

Private, priority fax call received

f1022 a1171

Private, priority voice and fax call received

f1023 a1171

Private fax call received

f1024 a1171

Private voice and fax call received

f1025 a1171

Priority fax call received

f1026 a1171

Priority voice and fax call received

f1027 a1171

Fax call received

f1028 a1009,a1011,a1012,a1037,a1188,a2055,a2102

page.

f1029 a1009,a1011,a1012,a1037,a1188,a2055,a2102

pages.

f1030 a1171

Voice and fax call received

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1031 a993,a1031,a1039

A fax must be addressed before it can be created.

f1032 a979

Subscriber cannot receive fax.

f1033 a1003

Cannot print a delivered message.

f1034 a1004

Cannot get your messages now, due to an active print request.

f1035 a1002

Message delivered, cannot print a delivered message.

f1036 a1173

You are automatically scanning your incoming messages.

f1037 a1173

To respond to the message, press one.

f1038 a86,a928,a2072,a2074

To re-record message before delivery, press one.

f1039 a73,a346,a507,a929,a2060,a2061,a2071,a2073

To change or send again, press one.

f1040 a254,a837

To print all new faxes, press 4.

f1041 a1005

There are no new faxes.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1042 a1005

Private fax messages will not be printed, no other faxes to print.

f1043 a1005

Private fax messages will not be printed, print scheduled for all other faxes.

f1044 a892

This is a fax message from

f1045 a892

This is a voice and fax message from

f1046 a907

This is a fax message.

f1047 a907

To print

f1048 a1013,a2067

Nothing to print.

f1049 a1011,a1012,a1037,a1188

Fax of

f1050 a1012,a1188

Message does not contain voice.

f1051 a1014

Voice and fax message.

f1052 a165,a166,a755,a756,a2089,a2090,a2091,a2092

To specify your fax preferences, press 3.

f1053 a1006

Fax not enabled for your mailbox, for help press star H.

f1054 a1170

Fax call from

f1055 a1170

Voice and fax call from

f1056 a1007

System not administered for fax.

f1057 a668,a669,a670,a671

Priority fax message from

f1058 a668,a669,a670,a671

Priority voice and fax message from

f1059 a676,a677,a678,a679

Private, priority fax message from

f1060 a676,a677,a678,a679

Private, priority voice and fax message from

f1061 a1008,a1016

Your default print destination is...

f1062 a355,a356,a357,a358

Private broadcast fax message from

f1063 a355,a356,a357,a358

Private broadcast voice and fax message from

f1065 a269,a270,a271,a272

Broadcast fax message from

f1066 a269,a270,a271,a272

Broadcast voice and fax message from

f1068 a663,a664,a665,a666

Private fax message from

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1069 a663,a664,a665,a666

Private voice and fax message from

f1071 a808,a809,a810,a811

Fax message from

f1072 a808,a809,a810,a811

Voice and fax message from

f1073 a73,a86,a192,a276,a310,a346,a507,a508,a527,a530,
a892,a928,a929,a1011,a1012,a1027,a1158,a1172,a1173,
a2057,a2058,a2059,a2060,a2061,a2062,a2063,a2064,
a2065,a2066,a2068,a2069,a2070,a2071,a2072,a2073,
a2074

To print, press star 1.

f1075 a1008,a1018

**To change the default print destination, press
1.**

f1076 a1008,a1018,a1024

**To have your faxes printed automatically, press
Y for Yes.**

f1077 a1008,a1018,a1024

**To cancel automatic printing of your faxes,
press N for no.**

f1078 a1008,a1018,a1024

To change autodeletion option, press 9.

f1079 a1015

**Enter your default print destination followed by
the pound key.**

f1080 a1017

Invalid destination.

f1081 a1020

After a fax only message is printed automatically, should it also be deleted from your mailbox? Press Y for yes or N for No.

f1082 a1025

To turn on autodeletion, press Y. To turn off, press N.

f1083 a1023

You must enter a default print destination before autoprinting can be used.

f1084 a1024

You are changing your fax print options.

f1085 a1024

To change or add default print destination, press 1.

f1086 a1024

The default print destination is where documents are normally printed.

f1087 a994,a995

To print to destination...

f1088 a994,a995

press pound

f1089 a994

To specify destination, enter digits followed by the pound key.

f1090 a994,a995,a997

To print on the fax machine from which you are calling, press star 6.

f1091 *a995*

You are specifying where your documents will be printed

f1092 *a995,a997,a1008*

A default print destination has not been assigned.

f1093 *a995*

To assign a default print destination press star R, 5-3.

f1094 *a995,a997*

To specify a default destination, enter digits then press the pound key.

f1095 *a995*

This destination will be used for the remainder of this call. When you hang up, your default destination will be restored.

f1096 *a995*

If you choose this option, the document will begin to print. You will not be able to access your mailbox while the document is printing. You will be able to call into your mailbox again after printing is complete.

f1097 *a996,a1005*

Print scheduled.

f1098 *a998*

To approve, press pound.

f1099 *a998*

Or re-enter print destination number and pound sign.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1100 a999
Invalid.

f1101 a999
Re-enter print destination number and pound
sign.

f1102 a1000
Too many print requests, try again later.

f1103 a1001
Fax extension for

f1104 a978
Print request to...

f1105 NONE
To print, press star 1.

f1106 NONE
To send fax, press pound.

f1108 NONE
When autoprinting is turned on, your non-private
faxes are sent automatically to the default fax
print number.

f1109 a344,a767
Private, priority fax message to

f1110 a344,a767
Private, priority voice and fax message to

f1111 a1025
You are in the autodeletion menu.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1114 a1025

If autodeletion is turned on, fax only messages will be deleted after they are automatically printed.

f1115 a345,a673

Priority fax message to

f1116 a345,a673

Priority voice and fax message to

f1117 a273,a342,a343,a675,a2018,a2019,a2020,a2036

all local subscribers.

f1118 a1026

You are specifying the default print destination for fax items.

f1119 a343,a840,a841

Private fax message to

f1120 a343,a840

Private voice and fax message to

f1121 a675

Private broadcast message to

f1122 a675

Private broadcast fax message to

f1123 a675

Private broadcast voice and fax message to

f1124 a1024,a1026

When autoprinting is turned on, all non-private faxes that are received will automatically attempt to print at the default destination.

f1125 a342,a838

Fax message to

f1126 a342,a838

Voice and fax message to

f1127 a273

Broadcast message to

f1128 a273

Broadcast fax message to

f1129 a273

Broadcast voice and fax message to

f1130 a1026

This is also used as the default print destination when scanning fax messages.

f1132 a841

Private voice and fax message to

f1133 a1026

It must be a valid call delivery number.

f1134 a1026

To enter destination, enter digits followed by the pound key.

f1135 a1024

A default print destination must be assigned before autoprinting can be used.

f1136 a1008,a1019,a1021,a1022

Autoprinting is turned on.

f1137 a1008,a1019

Autoprinting is turned off.

f1138 a1008,a1019,a1022

Autodeletion is turned off.

f1139 a1008,a1021

Autodelition is turned on.

f1140 a279,a297

When finished you may attach a fax by pressing pound.

f1141 a1175,a1176,a1177,a1178

When finished recording, press pound for more options.

f1143 a1026

The default print destination should be set to the destination where you normally send your documents for printing.

f1144 a165,a166,a755,a756,a2089,a2090,a2091,a2092

To specify whether a message can be addressed before it's recorded, press 6.

f1145 a165,a166,a755,a756,a2089,a2090,a2091,a2092

To administer call answer options, press 7.

f1146 a1174

To administer mailing list, personal directory, password, fax options, account name, addressing options, or call answer options, press 5.

f1147 a1174

To administer mailing list, personal directory, password, account name, or addressing options, press 5.

f1148 a1174

To administer mailing list, personal directory, password, fax options, account name, or addressing options, press 5.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1149 a1174

To administer mailing list, personal directory,
password, account name, or call answer options,
press 5.

f1150 a1174

To administer mailing list, personal directory,
password, fax options, account name, or call
answer options, press 5.

f1151 a1174

To administer mailing list, personal directory,
password, account name, addressing options, or
call answer options, press 5.

f1152 a1029,a1030,a1032

Address Before Record turned on.

f1153 a1029,a1032

To turn off, press 1.

f1154 a1029,a1030,a1032

Address Before Record turned off.

f1155 a1029,a1032

To turn on, press 1.

f1157 a1032

You are administering Addressing options.

f1158 a1033,a1035

To prevent callers from leaving messages, press
1.

f1159 a1033,a1034,a1035

Call answer messages will not be accepted.

f1160 a1033,a1035

To allow callers to leave messages, press 1.

f1161 a1035

You are administering Call Answer options.

f1162 a279,a504,a1038,a1175,a1176,a1177,a1178,a1185

Sorry, the mailbox you have reached is not accepting messages at this time.

f1163 a504,a1175,a1176,a1177,a1178

is not available.

f1164 a1033,a1034,a1035

Call answer messages will be accepted.

f1165 a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088

To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star R.

f1166 a1179

Temporarily cannot access your messages. Processing your request to print all new faxes. Please try again"

f1167 a1036

Only 25 faxes printed.

f1168 a1180

Fax print all request to

f1169 a1184

Printing has completed.

f1213 a1094

You are being prompted whether you want to paging service of the person you were calling.

f1214 a1098

You are being prompted to enter the caller PIN given to you by the person you were calling. This must be entered correctly before a reach or page attempt will be made. To leave a voice mail message instead, you may press one.

f1215 a1068

To try to reach

f1216 a1068

please press two now, or hold to leave a message.

f1217 a1069

was not available at the number you called. To try to reach

f1218 a1069

at an alternate number, please press two. To leave a voice mail message instead, press one. If you don't press anything, you will also be able to leave a message.

f1219 a1070,a1112

To review or change your reach options, press 7.

f1220 a1074,a1088

When paging is turned on, callers who are unable to contact you at your reach number will have the option to transfer to your paging service.

f1221 a1072,a1074

Your reach number

f1222 a1072,a1074

is turned on

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1223 a1072,a1074
is turned off

f1224 a1074,a1101
Call screening is turned on.

f1225 a1074,a1101
To change reach number information, press 1.

f1226 a1073,a1102
To change reach number, press 1.

f1227 a1073,a1074
To retrieve messages, press 2

f1228 a1073,a1074,a1102
To change call screening status, press 3.

f1229 a1074,a1077
When your reach number is turned on, incoming calls will attempt to be forwarded to it.

f1230 a1074,a1103
Paging is turned on.

f1231 a1074,a1103
Paging is turned off.

f1232 a1074,a1079
When call screening is turned on, callers who are trying to contact you will need to enter a personal identification number, or PIN, that you have given them, before the call will be forwarded to your reach number or allow the caller to page you.

f1233 a1074
To change your reach number, press 1.

f1234 a1075,a1077

To turn your present reach number on, press pound.

f1235 a1075,a1077

To turn your present reach number off, press zero pound.

f1236 a1075,a1077

To enter and turn-on a new reach number, enter that number, followed by the pound sign.

f1237 a1076

is not a valid telephone number or speed dial code.

f1238 a1077

You are updating the status of your reach number.

f1239 a1077

Your present reach number is

f1240 a1077

The number you enter may be a valid telephone number, entered as though you were dialing from your office phone.

f1241 a1077

Or the number you enter may be a single-digit speed-dial code. The only valid speed-dial codes are the digits one through six. For help setting up or changing the speed-dial codes for this account, please contact your system administrator."

f1242 a1077

You do not presently have a reach number.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1243 a1078

To turn call screening on, press pound.

f1244 a1078

To turn call screening off, press zero pound.

f1245 a1079

You are being prompted to turn call screening on or off.

f1246 a1108

You are being prompted to turn paging on or off.

f1247 a1080

in your caller PIN list is

f1248 a1080

To skip to the next PIN, press pound.

f1249 a1080

To delete this PIN, press star D.

f1250 a1080

To add a new PIN, press 1.

f1251 a1081

You are reviewing your list of caller personal identification numbers.

f1252 a1082

You are being prompted to add a caller personal identification number to your list.

f1253 a1081,a1082

When call screening is turned on, callers will need to enter one of these PIN's in order to contact you or have you paged.

f1254 a1082,a1087

Caller PIN's must contain between three and ten digits

f1255 a1082

and cannot contain the star or pound characters.

f1256 a1084

To add a caller PIN to your list, enter the PIN, followed by the pound sign.

f1257 a1083

Your list already contains the maximum number of caller PIN's. You must delete an existing PIN before adding a new one.

f1258 a1085

Caller PIN

f1259 a1085

added to list

f1260 a1086

Duplicate entry.

f1261 a1086

The caller PIN you just entered is already contained in your list.

f1262 a1086

Please enter a different number.

f1263 a1109

Please enter more digits, or pound sign.

f1264 a1087

Caller PIN's cannot contain more than

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1265 a1113

Caller PIN's cannot contain the star or pound characters.

f1266 a1074,a1102

To change paging status, press 5.

f1267 a1090

Incoming external call for

f1268 NONE

Or, press star H for help.

f1269 a1090

To speak with the calling party, please enter your password, followed by the pound sign.

f1270 a1091

This is an automatic system, trying to forward a call to

f1271 a1091

A password must be entered to complete the call.

f1272 a1091

Please enter the password, followed by the pound sign.

f1273 a1089

Please stay on the line.

f1274 a1093

Please enter your PIN now.

f1275 a1096

Please re-enter the PIN or press 1 to leave a message.

f1276 a1071

A reach attempt is about to be made.

f1277 a1071,a1089

This may take up to

f1278 a1067

We were unable to reach the paging service.

f1279 a1071,a1089

Please stay on the line as we try to reach

f1280 a1071

Or, press 1 to leave a message.

f1281 a1097

To transfer to the paging service

f1282 a1097

press two now or hold to leave a message.

f1283 a1090

Incoming call for

f1284 a620,a1077

In all cases, entering a star or pound as the first digit will result in the star or pound being outputted. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f1285 a620

If you are programming a number to call a pager that requires a pound sign in or at the end of the digit string, press y to hear further help. Otherwise, press n to return to outcalling administration.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1286 a622,a1077

Wherever a pound sign is required in the digit string, enter star pound. For pagers requiring a pound sign termination, end your digit string with star pound pound.

f1287 a622,a1077

If a pause is required before a pound sign, enter star star pound.

f1296 a1106

Your party was not available.

f1297 a1102

To change personal identification numbers, press 4.

f1298 a1110

System not administered for reach service.

f1299 a1107

To change call screening status, press 3.

f1300 a1074

To review or change the personal identification numbers used by callers when you have call screening turned on, press 4.

f1301 a1107

To change your BPCS password, press 5.

f1302 a1074

To hear this help message again, press star H.

f1303 a1104

Your list of caller personal identification numbers contains

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1304 a1111

You are not authorized for reach service.

f1305 a1112

Please enter an outcalling option. To hear a list of options, press 0.

f1306 a1071

You will be put on hold while we dial the number where the person you were calling can be reached. If they answer, you will be connected with them.

f1307 a1092

No PINs active.

f1308 a1068

please press two now, followed by your PIN, or hold to leave a message.

f1309 a1114

For help, press *H again.

f1310 NONE

Up to 58 characters may be entered.

f1311 a1077

Up to 29 characters may be entered.

f1312 a1077

To repeat this help, press *H *H.

f1313 a1115

At the tone, please speak your name.

f1314 NONE

Then stay on the line.

f1315 a1116

Begin speaking.

f1316 a1117

The calling party hung up.

f1400 a1127

For English press star one.

f1401 a1128

Your primary greeting is in

f1402 a1123,a1124

**To administer your primary greeting, press
pound.**

f1403 a1130

Your secondary greeting is in

f1404 a1121

To administer this greeting, press 1.

f1405 a1123,a1124

To listen to your secondary greeting, press 0.

f1406 a1123,a1124

To listen to your primary greeting, press 0.

f1407 a1123

To record your primary greeting, press 1.

f1408 a1122

To administer this greeting, press 2.

f1409 a1123

To record your secondary greeting, press 1.

f1410 a1123,a1124

**To administer your secondary greeting, press
pound.**

f1411 a1124

To delete your primary greeting, and use the system greeting press star D.

f1412 a1124

To delete your secondary greeting, and use the system greeting, press star D .

f1413 a1125

Your new primary greeting is now active.

f1414 a1125

Your new secondary greeting is now active.

f1415 a1126

Recording deleted.

f1416 a1126

Your primary greeting has not changed.

f1417 a1126

Your secondary greeting has not changed.

f1418 a1133

You are administering your primary greeting.

f1419 a1133

You are administering your secondary greeting.

f1420 a1132

Callers will hear the greeting and receive instructions in the primary language unless they press star-1, in which case they will hear the greeting and receive instructions in the secondary language.

f1430 a1134

The following message was restored.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1431 a1135

No message to restore.

f1432 a1136

To undelete last deleted message, press star
star U.

f1433 a1138

The return address for this message is not a
valid extension.

f1434 a62,a85,a123,a126,a128,a168,a169,a170,a1139,a1140,
a1141,a1160,a1161

To return to getting messages, press pound.

f1436 a1143

English

f1437 a1144

<CHIMES - LIKE DOOR BELL>

f1438 a1144

Call for

f1439 a1145

<BEEP - LIKE CONF BRIDGE TONE>

f1440 a1146

<BEEP - LIKE RECORD AT TONE TONE>

f1441 a1147

<BEEP BEEP BEEP TONE - FOR OUT OF SPACE TONE>

f1442 a1148

<BEEP - LIKE EOM TONE BUT SOFTER>

f1443 a570

Voice filesystem is out of space.

f1444 a570

Please contact the administrator.

f1445 a1150,a1170

Private, priority call from

f1446 a1150,a1170

Private call from

f1447 a1150,a1170

Private call from

f1448 a1151,a1171

Private, priority call received

f1449 a1151,a1171

Private call received

f1450 a1151,a1171

Priority call received

f1451 a1151,a1171

Call received

f1452 a622

A star entered as part of the digit string will be interpreted as a pause of one and a half seconds.

f1453 a1153

Your password will expire in

f1454 a1153

days.

f1455 a1153

Your password will expire within one day.

f1456 a1154

Your password has expired.

f1457 a1155

Old and new passwords cannot be the same.

f1458 a1156

Password cannot be changed within

f1459 a1156

days of last change.

f1460 a1156

day of last change.

f1461 a1157,a1158,a1172,a2068,a2069

You are getting your incoming messages.

f1462 a73,a86,a928,a929,a1157,a1158,a1172,a1173,a2068,
a2069,a2071,a2072,a2073,a2074

To listen to the message, press 0.

f1463 a192,a1158,a2057,a2069

To reply to sender by voice mail, press 1, 7.

f1464 a192,a1158,a2057,a2069

To forward with comment, press 1, 2.

f1465 a192,a1158,a2057,a2069

To record a new message, press 1, 4.

f1466 a1157,a1172,a1173,a2068

To respond to or forward the message, press one.

f1467 a1162

The return address for this message is not a mailbox on this system.

f1468 a1163

The return address for this message is not a valid extension.

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1469 a1160,a1161

To reply to sender by voice mail, press 7.

f1470 a1164

No voice portion of message to playback.

f1471 a622

Up to 60 characters may be entered.

f1472 a994,a995,a997,a999,a1015,a1026

<.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>

f1900 a1903,a1911,a1912

Call to...

f1901 a1903

Fax call to...

f1902 a1903

Voice and fax call to...

f1903 a1904

Private call to...

f1904 a1904

Private fax call to...

f1905 a1904

Private voice and fax call to...

f1906 a1905

Priority call to...

f1907 a1905

Priority fax call to...

f1908 a1905

Priority voice and fax call to...

f1909 a1906

Private, priority call to...

f1910 a1906

Private, priority fax call to...

f1911 a1906

Private, priority voice and fax call to...

f1912 a1907,a1913

Message to...

f1913 a1907

Fax message to...

f1914 a1907

Voice and fax message to...

f1915 a1908

Private message to...

f1916 a1908

Private fax message to...

f1917 a1908

Private voice and fax message to...

f1918 a1909

Priority message to...

f1919 a1909

Priority fax message to...

f1920 a1909

Priority voice and fax message to...

f1921 a1910

Private, priority message to...

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f1922 a1910

Private, priority fax message to...

f1923 a1910

Private, priority voice and fax message to...

f1924 a1900,a1902,a1911,a1913

...from...

f1925 a1914

this is a blank fragment which can be recorded
by # the customer, for use as a disclaimer
announcement

f1999 NONE

Message does not contain voice.

f2000 a2012

<ERROR TONE - Missing Component>

f2001 a2000

One or more components of this multimedia
message could not be delivered. Please contact
the sender.

f2002 a2001

Message not delivered because it contained 1 or
more media types that the recipient's machine
is unable to process.

f2003 a2002

Message not delivered because it is too long for
the recipient's machine.

f2004 a2103

Message receipt notification: the complete
message was delivered to you on an associated
system. To play the message header, press 2-3.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f2005 a2104

Header only message. No part of the original message is missing. To play the message header, press 2-3.

f2006 a2005

Message not delivered because private messages cannot be sent to the recipient's machine.

f2007 a2006,a2007,a2008,a2009,a2010,a2011

with text.

f2008 a2006,a2007,a2008,a2009,a2010,a2011

with other media

f2009 a2013

Incomplete...

f2010 a2051

zero

f2011 a2051

bytes

f2012 a2051

byte

f2013 a2052

kilobyte

f2014 a2052

kilobytes

f2015 a2053

megabyte

f2016 a2053

megabytes

US-ENGLISH FRAGMENTS
DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f2017 *a2014,a2015,a2016,a2017,a2018*

Broadcast...

f2018 *a2101*

...and...

f2019 *a2014,a2015,a2016,a2017,a2023,a2024,a2025,a2026,
a2027,a2028,a2029,a2030,a2031,a2032,a2033,a2034,
a2037,a2038,a2039,a2040,a2042,a2043,a2044,a2045,
a2065*

...message from...

f2020 *a2018,a2019,a2020,a2021,a2022,a2035,a2036,a2041,
a2046,a2047,a2048*

...message to...

f2021 *a1911,a1912,a1913,a2020,a2027,a2028,a2029,a2030,
a2047,a2048,a2049,a2054*

Private...

f2022 *a1911,a1912,a1913,a2021,a2037,a2038,a2039,a2040,
a2041*

Private, priority...

f2023 *a1911,a1912,a1913,a2022,a2031,a2032,a2033,a2034,
a2035,a2049,a2054*

Priority...

f2024 *a2023,a2024,a2025,a2026,a2036*

Private, broadcast...

f2025 *a2049*

...call from...

f2026 *a2054*

...call received...

f2027 *a2055*

Text of...

f2028 *a2056*

Binary file of...

f2029 *NONE*

This is a...

f2030 *a2075,a2095,a2096,a2097,a2101*

...voice...

f2031 *NONE*

...fax...

f2032 *NONE*

...text...

f2033 *NONE*

...attached file...

f2034 *a2101*

...multi-media...

f2035 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To advance to the end of the message, press star 6.

f2036 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6.

f2037 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To delete entire message, press star D.

f2038 *a2075*

Rewound...

f2039 *a2075*

...component.

f2040 *a2075*

To listen, press 3.

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®

f2041 a2077,a2078,a2079,a2080,a2081,a2082,a2083,a2084,
a2085,a2086,a2087,a2088

To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.

f2042 a2089,a2090,a2091,a2092

To administer your media preference for sorting incoming messages, press 8.

f2043 a2093,a2095

You are administering your preferred media type for sorting incoming messages. Messages with a primary media type matching your preference will be presented before other messages, regardless of the order in which they have been received.

f2044 a2093,a2094,a2097

No media preference for sorting incoming messages has been specified.

f2045 a2093,a2094,a2095,a2096

For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4.

f2046 a2093,a2094,a2095,a2096

To retain your current preference, press the pound key.

f2047 a2095,a2096

Your media preference for sorting incoming messages is...

f2048 a2095,a2096

For no preference, press 0.

f2049 a2097

...will be your preferred media type.

f2050 a2098

Remote user.

f2051 a2100

Your password cannot be, the same as your extension number, consecutive digits, or a single repeated digit. Please enter new password and the pound key.

f2052 a2076

At beginning of message. To step back to previous message, press star 2. To listen, press 0.

f2053 a2052,a2053,a2055

...approximately...

f2054 a2059

To re-record, press 1. After recording, press 1 again.

f2055 NONE

This selection will take effect next time you login. To re-login now, press star star 7.

f2056 NONE

None...

f2057 a2075

At beginning of message.

f2058 a2075

To step back to previous component, press star 5.

f2059 a2105

This machine is unable to send mail to...

US-ENGLISH FRAGMENTS

DEFINITY® R3.2 /INTUITY™ MACH 4 AUDIX®