

"DATASPEED" TAPE-TO-TAPE SYSTEM
TOOLS AND MAINTENANCE SUPPLIES

1. GENERAL

1.01 This section lists the tools and supplies required for the installation and maintenance of DATASPEED apparatus.

2. GENERAL TOOLS

2.01 The tools and supplies listed in the section entitled Teletypewriter Tools and Maintenance Supplies may be required for teletypewriter apparatus, in addition to the special tools listed below.

3. SPECIAL TOOLS

3.01 Special tools and supplies required for the installation and maintenance of DATASPEED apparatus are as follows:

Part No.	Title
TP172060	Contact Spring Bender
TP143089	Armature Clip
TP145867	Grease