

CODE DIGITS 5 & 6 FEATURE		CODE	CODE DIGITS 5 & 6 FEATURE		CODE	CODE DIGIT 7 FEATURE		CODE
POWER AND JACK PANEL FOR ONE OR TWO S9CB	(1)	10	POWER PANEL FOR REMOTE LINE FEED	40	NO CHOICE		0	
BATTERY CHARGER FOR ONE OR TWO S9CB	(2)	20	POWER PANEL (1) FOR ONE S9CB	41				
BATTERY SHELF FOR ONE S9CB	(2)	30	POWER PANEL (1) FOR THREE S9CB	42				
FAN FOR 36A OR M CAB		50						
BATTERY		60						
JACK PANEL FOR ONE TO THREE S9CB WHEN 7A OR 8A POWER PANEL IS USED		70						
ELIMINATION OF POSSIBLE 60HZ POWER LINE INDUCTION NOISE	ADAPTER FOR 1A PWR AND JACK PNL	11						
	1A POWER AND JACK PANEL (3)	12						
PROTECTOR BLOCK ASSEMBLY		13						
>1B POWER AND JACK PANEL (1)		14						
>BATTERY SHELF FOR TWO S9CB		31						
						CODE DIGIT 8		
			REFERENCE	5	6	7	CODE	
			KS-21906	16	10	10	F**	
			KS-22099	15	10	10	E**	
			1A JK P	17	10	10	G**	
			1A PWR & JK	11	10	10	/A%/	
			1A PWR & JK	11	12	10	A**	
			>1B PWR & JK	11	14	10	K%	
			3A BAT CHG	12	10	10	B**	
			6A PWR P	14	10	10	D**	
			7A PWR P	14	11	10	D**	
			8A PWR P	14	12	10	D**	
			128A APP M	13	10	10	C**	
			>145A APP M	13	11	10	C**	
			343A ADPTR	11	11	10	H**	
			ED-7C240-30	11	13	10	J**	

NOTES: (1) SEE S9CP FOR REQUIRED PLUG-IN UNITS (2) ALSO USED WITH SLC-8 231A RPFT (3) FIELD MOD OF 1A PWR & JK PNL SERIES 1 OR 2 OR NEW SERIES 4

DESCRIPTION: SUBSCRIBER LOOP CARRIER-96 - REMOTE TERMINAL APPARATUS