

CODE DIGIT 5 FEATURE	CODE	CODE DIGITS 6 & 7 FEATURE				CODE	CODE DIGITS 6 & 7 FEATURE				CODE
62 TYPE	2	A		210	AO		AE		234	AE	
		B		211	BO		AF		235	AF	
		C		212	CO		AG		236	AG	
		D		213	DO		AH		237	AH	
		E		214	EO		AJ		238	AJ	
		F		215	FO		AK		239	AK	
		G		216	GO		AL		240	AL	
		H		217	HO		AM		241	AM	
		J		218	JO		AN		242	AN	
		K		219	KO	APPARATUS CODE SUFFIX	AP	FREQUENCY (KHZ)	243	AP	
		L		220	LO		AR		244	AR	
		M	FREQUENCY (KHZ)	221	MO		AS		245	AS	
		N		222	NO		AT		246	AT	
		P		223	PO		AU		247	AU	
		R		224	RO		AW		248	AW	
		S		225	SO		AY		249	AY	
		T		226	TO		BA		250	BA	
		U		227	UO		BB		251	BB	
		W		228	WO		BC		252	BC	
		Y		229	YO		BD		253	BD	
		AA		230	AA		BE		254	BE	
		AB		231	AB	CODE DIGIT 8					
		AC		232	AC	REFERENCE	5	6	7	CODE	
		AD		233	AD	62- OSC	2	A TO Y A,B	O A TO Y	A*%	

NOTES: DESCRIPTION: L3 CARRIER - MAINTENANCE OSCILLATOR

CODE DIGIT 5 FEATURE		CODE	CODE DIGITS 6 & 7 FEATURE			CODE	CODE DIGITS 6 & 7 FEATURE				CODE
62 TYPE		2	BF		255	BF					
			BG		256	BG					
			BH		257	BH					
			BJ		258	BJ					
			BK		259	BK					
			BL		260	BL					
			BM		261	BM					
		APPARATUS CODE SUFFIX	BN	FREQUENCY (KHZ)	262	BN					
			BP		263	BP					
			BR		264	BR					
			BS		265	BS					
			BT		266	BT					
			BU		267	BU					
			BW		268	BW					
			BY		269	BY					
							CODE DIGIT 8				
							REFERENCE	5	6	7	CODE
							SEE PAGE 1				
NOTES:			DESCRIPTION: L3 CARRIER - MAINTENANCE OSCILLATOR								