

SWITCHBOARD CABLE & WISE TYPES
AND CODE OF CABLE

1. GENERAL INFORMATION

1.1 The purpose of this UIS is to provide information on the bending radius of the 600B series cables.

2. 600B SERIES CABLES

2.1 The following information is to be added to the bending radius column for the 600B series cable in Table 1 of Section 100.

<u>Cable code</u>	<u>Bending Radius (in.)</u>
606B	5
607B	6
608B	6
609B	7
610B	9
611B	12
612B	11

Bending radius less than those listed should be avoided.

Engineering Planning Manager
(Installation)

NOTICE

Not for use or disclosure outside
Western Electric except under written agreement. Printed in U.S.A.