

A17-49030-00

PROTECTIVE COVER

UPGRADE KIT

Table of Contents

Ordering Information	2
General Description	2
Installation	2
Warranty	4

About this Practice:

This is a new document.

Reissued Practices: Updated and new content can be identified by a banner in the right margin.

Issue date: September 1998

UPDATED

CAUTION

- Install or remove modules from the shelf only when the power is off. If you install a module in the shelf with the power on, the internal circuitry may suffer damage and the product warranty will be void.
- Remove and install circuit boards only in a static-safe environment (use antistatic wrist straps, smocks, footwear, etc.).
- Keep circuit boards in their antistatic bags when they are not in use.
- Do not ship or store circuit boards near strong electrostatic, electromagnetic, magnetic, or radioactive fields.
- For more complete information on electrostatic discharge safety precautions, refer to Bellcore™ Technical Reference # TR-NWT-000870.

ORDERING INFORMATION

NOTE: This section lists the different options available for this product. To order any of the available options, contact Dantel Inside Sales through our toll-free number, **1-800-432-6835**.

OPTION NUMBER	FEATURES
A17-49030-00	Protective Cover Kit

GENERAL DESCRIPTION

Dantel shelves using large wire-wrap fields may now be protected from falling debris and/or physical damage by installing the A17-49030-00 Protective Cover Kit. This kit may be used on any Dantel shelf with 12 or 14 slots and using large (18 by 30) wire-wrap fields.

Applicable shelves may be identified as model numbers:

***13-41075-00**

***13-41075-23**

Applicable wire-wrap fields may be identified on drawings as A80-00081-09, or by counting 18 rows (A-U) by 30 columns on the back panel of the shelf.

NOTE: *Some shelves may have two of the large wire-wrap fields and will therefore require two (2) covers.*

This installation guide describes the process of installing the A17-49030-00 Protective Cover Kit.

INSTALLATION

The steps below will guide you through the process of installing the protective covers.

NOTE: *Under normal circumstances, it should not be necessary to remove power from the shelf to perform this installation.*

1. Remove the four screws as shown in Fig. 1.

WARNING: *Remove only the four screws indicated in Fig. 1. Removing all the screws securing the wire-wrap field may allow the entire panel to shift and short electrical connections on the inside of the panel.*

CONTINUED . . .


INSTALLATION

2. Install the four standoffs (part number 908-00143-01) provided with the kit where you removed the four screws in step 1.
3. Install the protective cover (part number B05-00905-00) using the four screws (part number 901-00406-25) provided with the kit.

NOTE: *Be sure that the lip of the protective cover is at the top of the shelf.*

4. Repeat steps 1 through 3 for all protective covers.
5. This completes the installation process.

FIG. 1 - LARGE WIRE-WRAP FIELD



WARRANTY

LIMITED WARRANTY

The Seller warrants that the standard hardware products sold will be free from defects in material and workmanship and perform to the Seller's applicable published specifications for a period of 18 months for hardware, and 3 months for software, from the date of the original invoice. The liability of the Seller hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned F.O.B. to the Seller's plant, (or, at the Seller's option, refunding the purchase price of such products). In no case are products to be returned without first obtaining permission and a customer return authorization number from the Seller. In no event shall the Seller be liable for any consequential or incidental damages.

Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. The Seller shall make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to custom equipment or products produced to the Buyer's specifications except as specifically stated in writing by the Seller in the contract for such custom equipment.

This warranty is the only warranty made by the Seller with respect to the goods delivered hereunder, and may be modified or amended only by a written instrument signed by a duly authorized officer of the Seller and accepted by the Buyer.

Warranty and remedies on products not manufactured by the Seller are in accordance with warranty of the respective manufacturer. THE SELLER MAKES NO OTHER WARRANTY OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED; AND ALL IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEEDS THE AFORESAID OBLIGATIONS IS HEREBY DISCLAIMED BY THE SELLER.

IN CASE OF DIFFICULTY

If you experience difficulty with this equipment, check the following, as appropriate:

1. **Switch settings**
2. **Signal levels**
3. **Software configuration**
4. **Connections between Dantel's equipment and your equipment.**

If there is still a problem, substitute equipment that is known to be good. For additional assistance, call Dantel's Technical Field Service Department weekdays, 6 A.M. to 5 P.M. pacific time:

1-800-4DANTEL (1-800-432-6835).

If a thorough checkout shows a piece of equipment has malfunctioned, you may return it to the factory. For repairs and emergency replacements, obtain a Return Material Authorization (RMA) number from the Customer Service Representative at **1-800-4DANTEL (1-800-432-6835)**.

To ensure expedient processing of your order, provide a purchase order number and shipping and billing information when requesting an RMA number. Also, when the units are returned to Dantel, include a description of the failure symptoms for each unit returned. Send defective equipment to:

Dantel, Inc. • 2991 North Argyle Avenue • Fresno, California 93727-1388

