



CODED TOOLS  
 NOS. 387A TO 395A

TOOL, 387A




Relay winding connector.  
 For use on 111-type relays.

TOOL, 388A




3/16" and 1/4" Hex. open double-end offset wrench.  
 For general use.

TOOL, 389A




Brush.  
 For use on 197- and 198-type switches.

TOOL, 390A



Hardwood pin.  
 For use in conjunction with portable motor equipment for base metal contact maintenance in cleaning flared portion of 92- and 292-type jack sleeves.

TOOL, 390B



Hardwood pin.  
 For use in conjunction with the portable motor equipment for base metal contact maintenance in cleaning flared portion of 49-type jack sleeves.


SECTION A706.025

TOOL, 391A      Manufacture Discontinued.

→ TOOL, 392A      Manufacture Discontinued.

TOOL, 393A      Manufacture Discontinued.

TOOL, 394A




Contact burnisher.

Replaces the No. 86 tool.

For use on 141- and similar-type jacks.

→ TOOL, 395A



Feeder brush spacer

For use on power driven rotary selectors and 200-, 206-, 209-, and 211-type selectors having six bank feeder brushes excepting those having balanced type brushes. This tool may be modified for use on selectors having two or four bank feeder brushes as covered in Section A508.201 and on A.E.Co. 25-point rotary switches having one, two, or four bank feeder brushes as covered in Section A508.203.