



CODED TOOLS
 NOS. 597A TO 608B

TOOL, 597A




Armature Adjuster
 Replaces the AECO H-14768 tool.
 For use on step-by-step relays.

TOOL, 598A



Test probe
 The No. 419A tool or KS-6278 connecting clip
 or other suitable connecting clip may be
 mounted in the chuck of this tool.
 For use with the 31-type transmission meas-
 uring set.

TOOL, 600A




Short-circuiting tool.
 For use on 19-type resistance in allotter
 circuits.

TOOL, 601A Manufacture Discontinued.

Replaced by the No. 608B tool.

TOOL, 601B



Cut-over tool

For use on U676 and U680 relays in step-by-
 step dial systems.


TOOL, 602A Manufacture Discontinued.

Replaced by the No. 602B tool.

TOOL, 602B Manufacture Discontinued.

Replaced by the No. 602C tool.

TOOL, 602C




Amplifier extractor.

Replaces the No. 602B tool.

For use in extracting J68647A amplifiers
 from mounting plates.

SECTION A706.043

TOOL, 603A



Relay extractor

For use on 275- and 276-type relays.

TOOL, 604A Manufacture Discontinued

Replaced by the No. 604D tool

TOOL, 604B

TOOL, 604C

TOOL, 604D

Tape splicers

The No. 604B tool is used to splice unperforated tape in accounting centers.

The No. 604C tool is used to splice unperforated tape in central offices.


The No. 604D tool is used to splice perforated tape in accounting centers.

For apparatus requirements and adjusting procedures for these tools, refer to Section A438.985 covering this apparatus.

For piece part information for these tools, refer to Section A509.995 covering this apparatus.

For use in AMA system.


TOOL, 605A



Soldering tool

For use in maintaining concentricity between the center contact and the body of a 337-type plug while soldering the plug to the center conductor of a coaxial cable.


TOOL, 606A



Armature tab adjuster

For use on 263- and 264-type relays

TOOL, 607A



Relay winding connector


Replaces the R-2736 relay winding connector.

For use on U-, Y-, UA-, and UB-type relays.

TOOL, 608A Manufacture Discontinued

Replaced by the No. 608B tool.

TOOL, 608B



Cut-over tool

Replaces the No. 608A tool.

For use on EA6, EA12 and EA35 relays.