


CODED TOOLS

NO. 707A TO 718A

TOOL, 707A




Comb Cleaner

This tool, together with the No. 708A, 708B, 709A and 709B tools, replace the KS-13503 Compound Remover.

For use in removing contact protectant compound from 708A and 708B tools.

- TOOL, 708A
- TOOL, 708B



Strip of 9 rubber teeth


Tool	Dimensions			
	A	B	C	D
708A	1-1/8"	1/2"	23/64"	.125"
708B	1-1/2"	1/2"	23/64"	.166"

These tools, together with the No. 707A, 709A and 709B tools, replace the KS-13503 Compound Remover.

Six No. 708A tools, mounted in a No. 709A tool are for use in removing contact protectant compound from panel selector bank terminals. Two No. 708B tools, plus 3 or 4 teeth from a third No. 708B tool, mounted

ed in a No. 709B tool are for use in removing compound from panel line finder bank terminals.

- TOOL, 709A
- TOOL, 709B



Handle (shown with 708-type tools forming comb for removing contact protectant compound.)


Tool	Dimensions	
	A	B
709A	7-19/64"	5-3/4"
709B	4-13/64"	5-3/4"

These tools, together with the No. 707A, 708A and 708B tools, replace the KS-13503 Compound Remover.

The No. 708A and 708B tools must be ordered separately.

The No. 709A tool, fitted with six No. 708A tools is for use in removing contact protectant compound from panel selector bank terminals. The No. 709B tool, fitted with two No. 708B tools plus 3 or 4 teeth from a third No. 708B tool is for use in removing contact protectant compound from line finder bank terminals.

- TOOL, 711A




Adjuster

For use in adjusting the upper armature support lug on all crossbar switches.

SECTION A706.053


TOOL, 712A



Female screwdriver

For use in adjusting the 1548-type inductors of the 486-type networks in ANI identifier frame.


TOOL, 713A



Combination screwdriver and pin wrench

For use as an accessory of the J68412A protection switching test set for adjusting and locking the slugs of the 1509-type inductor.


→ TOOL, 715A



Ratchet handle

This tool forms a part of the No. 1014A tool kit. For use in replacing coils of AF-, AG-, AJ- and AK-type relays, in conjunction with No. 716A and B tools.


→ TOOL, 716A



Ratchet head

This tool forms a part of the No. 1014A tool kit. Used in conjunction with the No. 715A tool when replacing coils of AF-, AG- and AJ-type relays.


→ TOOL, 716B



Ratchet head

This tool forms a part of the No. 1014A tool kit. Used in conjunction with the No. 715A tool when replacing coils of AK-type relays.


→ TOOL, 717A



Coil setter

This tool forms a part of the No. 1014A tool kit. Used in positioning the coil when replacing coils of AF-, AG-, AJ- and AK-type relays.

→ TOOL, 718A

**Wedge**

This tool forms a part of the No. 1014A tool kit. For use in supporting the armature and armature hinge springs, when displacing parts to provide clearance for removal of AF-, AG-, AJ- and AK-type relay coils.