



NONCODED TOOLS
 ADJUSTERS AND APPLICATORS

ADJUSTER, R-1760




For use on 200-, 206-, 209- and 211-type selectors, 25-point rotary switches and 1-type translators.

ADJUSTER, R-2142




For use on sequence switches and 157-type interrupters.

→ADJUSTER, R-2753



For adjusting cover spring on AF-, AG-, AJ- and AK-type relays.

ADJUSTER, R-2830



Similar to the No. 380A tool except that the openings shown at left in the above illustration are wider.


For use on panel multiple brushes in cases where No. 380A tool cannot be used because of brush springs being too wide.

ADJUSTER, R-63773
 Replaced by the No. 379A tool.

ADJUSTER, ARMATURE, AECO H-7056
 Replaced by: Adjuster, Armature, AECO H-13398-1.


ADJUSTER, ARMATURE, AECO H-14768
 Replaced by the No. 597A tool.

ADJUSTER, ARMATURE STOP, AECO H-14769




For use on step-by-step type relays.

ADJUSTER, BANK CONTACT, AECo H-7068-3




For use on plunger-type line and out trunk switches.

ADJUSTER, CAM, AECo H-47202




For use on 197-type switches.

ADJUSTER, DOUBLE DOG, AECo H-7067



For use on 197- and 198-type switches and solenoid-type master switches.

ADJUSTER, FRAME, AECo H-13701.




For use on solenoid-type master switches and plunger-type line and out trunk switches.

ADJUSTER, SEPARATOR, MAGNETIC, D-167912
Replaced by the No. 671A tool.

ADJUSTER, BRUSH, MULTIPLE: D-159890
Replaced by the No. 583A tool.


ADJUSTER, PLUNGER ARM, AECo H-10001-3.



For use on plunger-type line and out trunk switches.

ADJUSTER, SPRING, AECo H-20777
Replaced by the No. 416B tool.



ADJUSTER, SPRING, AECo H-7066



For use on step-by-step type relays and 197- and 198-type switches.

ADJUSTER, SPRING, D-157398
Replaced by the No. 506B tool.

ADJUSTER, SPRING, R-3159
REDUCE TO 3/4"




For use in adjusting normal post springs on 197-type switches.

ADJUSTER, SPRING, R-55760
Replaced by the No. 380A tool.


ADJUSTER, SPRING, R-69710
Replaced by the No. 371 tool.

ADJUSTER, SPRING, FINGER, TRIP, D-159676



Six needles are furnished with each tool.
For use on panel elevator apparatus.

ADJUSTER, VERTICAL ARMATURE, AECO H-13398-1.



Replaces the AECO H-7056 Armature Adjuster.
For use on 197- and 198-type switches.

APPLICATOR, TRUARC, WALDES KOHINOOR INC.
(In ordering, specify the number of applicator required to accommodate the ring series, size and thickness.)



No. of
Applicator

Ring Series,
Size and Thickness

E-9	5133-9-.015
E-12	5133-12-.015
E-15	5133-15-.025
E-18	5133-18-.025
E-25	5133-25-.025

For use in No. 2 and 2AA Telephone Answering Sets.