

NONCODED TOOLS

TAPS AND MISCELLANEOUS TOOLS

TAP, 2-56, COMMERCIAL

For use on 101-type relays.


TAP, 8-32, COMMERCIAL

For use in repairing vertical drive shafts.

TOOL, BLOCKING, SPRING, D-170030


Replaced by the No. 672A tool.

TOOL, BLOCKING, KS-16369



For blocking 221-, 222-, 223-, 224-, 247- and 248-type relays operated for a long period.

TOOL, BLOCKING, ITE-4069



For blocking 245-, 254-, 263-, and 264-type relays.

TOOL, BREAKOFF, TANG, HELI-COIL CORP. NO. 1196-5

This tool consists of a steel rod for breaking off the insert tangs and a holder in which the rod slides.


The use of this tool is covered in Section A509.986.

For use in breaking off the 1191-5CN insert tangs after insertion.

TOOL, BUSYING, BANK, AECo H-23366


Replaced by the Nos. 370A and 370B tools.

TOOL, CARD HANDLING, KS-14545



For use in bulk handling of No. 200 blanks and coded cards when servicing 1-type translators.

TOOL, CARD INSERTING, KS-14553




For use in inserting single coded cards in 1-type translators.

TOOL, CLEANING, BANK, AECo H-16590, DETAIL 1

Replaced by the No. 402E tool.

TOOL, CORD REPAIR, KS-2348




Replaces the No. 109 tool.

For use on keys, for placing shell and binding screws on 109-, 110-, 309- and 310-type plugs, and for repairing tinsel switchboard cords.

SECTION A707.160

TOOL, CRIMPING, HAND, KS-15710
(In ordering, specify list number of tool desired)




Long handle crimping tool

No.	Dim. Across Flats	Die Code	For Outer Sleeve No.
KS-15710,L2 (WT234)	.292 ± .003	T	KS-15712,L4
KS-15710,L3 (WT236)	.316 ± .003	V	KS-15712,L5, L7,L10
	.316 ± .003	V	KS-15712,L5, L7,L10
	.386 ± .003	X	KS-15712,L6, L8,L11

The use of this tool is covered in Section A504.402.


For use with KS-15712 shield connectors when terminating the shields of wire or cable.

TOOL, DEBURRING, KS-16088



For use in deburring coded cards for 1-type translators and for use with No. 81A test set in gauging the height of burrs on cards.


TOOL, DIALING, KS-8400



Replaces the No. 282 tool.

For use in rotating dials.


TOOL, EXTRACTING, HELI-COIL CORP.
(In ordering, specify number of tool desired.)



Tool No.	Will extract "Inserts"
1227-06	1185-2CN
1227-6	1191-3CN
"	1191-4CN
"	1191-5CN

For initial use in KS-13835 Readers.

TOOL, INSERTING, HELI-COIL CORP.
(In ordering, specify number of tool desired.)




Tool No.	"Inserts" used with tool
528-2N	1185-2CN
535-3N	1191-3CN
535-4N	1191-4CN
535-5N	1191-5CN

Heli-coil inserts, used with this tool, must be ordered separately.


For initial use in KS-13835 Readers.

TOOL, MORRILL AND MORRILL NO. 218




For use in extracting 310- and 311-type vacuum tubes.

TOOL PRESSURE, D-156695




For use in cleaning plunger-type line switch springs.

TOOL, REPAIR, VALVE



For pressure testing purposes.
(Spec. AT-7471X)

TOOL, RETAINING DISC, TP99896




For use on 1A and 1B regenerator units.

TOOL, SETTING, GEAR CASE, R-1026



For use on friction roll drives.


TOOL, TEST, D-96346



Resistance 43.2 and 132.6 ohms.


For use in testing the "B" relay of secondary line switches associated with allotter equipment.

TOOL, TESTING, TAPE, D-151155



For use on tape announcing machines.

TOOL, THREADING, TAPE, D-151159



For use on tape announcing machines.