

## BACKBOARDS IDENTIFICATION

### 1.00 INTRODUCTION


1.01 This section covers the identification of the most commonly used backboards and gives a brief description of their uses.

1.02 Methods for mounting backboards are in the section entitled Backboards, Installation.


1.03 This section is reissued to:

- Add new color line, gray (-49).
- Delete backboards that are "Manufacture Discontinued".


1.04 Due to extensive changes, marginal arrows have been omitted.




◀ **81** — Wood, black. Used for mounting five 58-, 98-, or 106-type station protectors.




**79** — Wood, black. Used for mounting ▲ one 58-, 98-, or 106-type station protector or two 111A station protectors.



◀ **144D** — Wood, black. Used for mounting all coded multislot coin collectors and a subscriber set. Holes for mounting coin collector fitted with Dot Tee nuts using P-210235 screws (1/4-20 by 1-inch FH steel machine screws). Screws not furnished with backboard. Replaces 144C backboard.





◀ **139A-3** — Metal, black. For mounting all coded multislot coin collectors on horizontal surfaces. Screws provided for mounting coin collector.



◀ **147A** — Wood, gray. For mounting J86205H rectifier and 634- and 653-type subscriber sets.



**154A** — Wood, gray. For mounting 584-, 684-, 685-, 686-, and 687-type subscriber sets on a wall or over an outlet.






◀ **155A** — Metal, black. Used for mounting 534- and 634-type subscriber sets on a wooden baseboard. Screws provided for mounting subscriber set.

**156A** — Metal, black. For ▶ mounting 584- and 684-type subscriber sets on a wooden baseboard. Screws provided for mounting subscriber set.





◀ **163A** — Phenol fiber, gray. For mounting 14A- or 20A-type indicator. Screws provided for mounting backboard to wall and indicator to backboard.


**164A** — Wood, black. Used ▶ for mounting C- or G-type hand telephone set mountings (hangup handset); 7-type buzzers and bells; No. 1, 2, 3, or 4 directory hangers. Replaces No. 157A.



**165A** — Wood, gray. For mounting KS-5250, J86205A and B rectifiers, and 50-type recorder connector.




◀ **166A** — Metal, galvanized. Used for mounting 320-type telephone set. Bolts provided for mounting telephone set.




◀ **167A Type\*** — Metal. For mounting coin collectors in 5-, 6-, 7-, 10-, or 11-type booths. Screws provided for mounting coin collector.


\* Black -3  
Beige -32




▶ **167B-3** — Metal, black. For mounting coin collector in 9-type booths. Screws provided for mounting coin collector.



▲ **168D** — For mounting one 42A or one 44A connecting block.




▲ **168E** — For mounting two or three 44A connecting blocks.




▲ **168F** — For mounting four 44A connecting blocks.

168-, E-, and F-type backboards are plastic and are available in the following colors:

- Gray -49
- Ivory -50





◀ **169A** — Metal, steel gray. Used for mounting 592-type subscriber set where protection from weather and mechanical injury is desired. Metal box with hinged cover. Screws provided for mounting subscriber set.



◀ 171A — Wood, gray. Used for mounting 531-, or 592-type subscriber set.



▶ 172C Type\* — Plastic. Used for mounting 354-, 356-, 357-, 554-, 556-, or 558-type wall telephone sets. No. 8-32 by 3/8-inch machine screws provided for mounting telephone set.

- |            |                 |
|------------|-----------------|
| * Black -3 | White -58       |
| Ivory -50  | Rose pink -59   |
| Green -51  | Light beige -60 |
| Red -53    | Light gray -61  |
| Yellow -56 |                 |




◀ 173A — Wood, gray. For mounting two No. 15A apparatus mountings. Machine screws furnished for mounting apparatus mountings.

**173B Backboard.** Designed to mount one 31A apparatus mounting. Gray finish. (Two of the 173-type backboards mounted side by side will fit under the 117A cover.)



**174A** — Aluminum alloy, black. For mounting all coded multislot coin collectors. Additional security of mounting is obtainable by the use of four security studs, P-10E070. (Order separately.) These studs may be used only with coin collectors having aluminum backplates.




**176A** — Wood backboard, gray. For mounting small miscellaneous apparatus such as jacks, buzzers, indicators, and keys.



SECTION C43.233.1

KS-5796 Type — Wood.

Lists 1 and 7, Lists 2 and 8, Lists 3 and 9.\*



▲  
List 1 — For mounting one  
105A apparatus  
box. Replaces 160A.

List 7 — For mounting one  
105B apparatus  
box.

▲  
List 2 — For mounting two 105A  
apparatus boxes. Re-  
places 161A.

List 8 — For mounting two 105B  
apparatus boxes.

\* Black -L1, 2, 3  
Gray -L7, 8, 9

List 3 — For mounting three ▲  
105A apparatus boxes. Replaces 162A.

List 9 — For mounting three 105B apparatus boxes.