

COIN COLLECTOR EXTENSIONS

1. GENERAL

- 1.01 This section covers the provision of extension stations at coin collectors. Extensions may be provided only at semi-public coin collectors.
- 1.02 Effective at once, the use of the 150GZ coin collector is discontinued and an extension station may be connected to the tip and ring of the line at the most convenient point.
- 1.03 Anti-sidetone equipment must be used at both the coin collector and the extension station. At existing sidetone coin collectors, it will be necessary to substitute anti-sidetone collectors when connecting an extension station.

2. NEW INSTALLATIONS

- 2.01 When a Service Order calls for the connection of a new coin collector with an extension station, an anti-sidetone coin collector, a manual instrument for the extension and anti-sidetone subsets shall be ordered by the apparatus clerk.
- 2.02 The apparatus clerk, when ordering the collector, shall be guided by the following table:

Non-Hand Set  
Coin Collectors

155G or 166G equipped with a GSE-69186 Card Holder on a "Do Not Substitute" basis

Hand Set  
Coin Collectors

174G or 176G equipped with a GSE-69186 Card Holder on a "Do Not Substitute" basis

or

191G, minus the 50C Card Holder, equipped with a GSE-69186 Card Holder on a "Do Not Substitute" basis

3. EXTENSIONS TO BE CONNECTED TO EXISTING COIN COLLECTORS

3.01 On all Service Orders which require the connection of an extension to an existing coin collector, a survey shall be made to determine whether the coin collector is the proper type, and the apparatus clerk notified of the type involved.

3.02 If the existing coin collector is a 50G, 150G, 161G, 55G or 74G type it shall be disconnected and one of the anti-sidetone types, converted for 10¢ operation, substituted.