


ORDER TURRET No. 1 CONNECTIONS


1. GENERAL

1.01 This section covers the manual and dial connections for Order Turret No. 1 and the desk stands which are used with this turret.

1.02 When adding the 3A or 4A varistor to an existing turret, remove existing wires between T and LT terminals of the induction coil and telephone set terminals GN and Y. Run a pair of wires from terminals T and LT of induction coil to the varistor and run another pair of wires from the varistor to telephone set terminals GN and Y.



**Fig. 1—50E Desk Stand
 (Dial only)**



**Fig. 2—40AL Desk Stand or
 Equipment (Manual only)**




Fig. 3—Order Turret No. 1 Manual and Dial