

## SUCTION GAS INDICATOR

### NOTES CONCERNING THIS ADDENDUM

This addendum supplements Section G82.650.1 with information on the interval at which the aspirator bulb should be tested and modifies the time element in regard to this test. Also included are additional instructions on field repairs of the Suction Gas Indicator.

The cross-reference "See Addendum" should be written in at 3.09 and 3.13 which are supplemented and at 3.09(2) which is modified.

### 3. MAINTENANCE

3.09 Aspirator Bulb: The bulb should be tested each time the indicator is used to determine if the check valves are operating.

(2) The bulb should inflate very slowly (not less than 15 to 18 seconds).

3.13 Parts for Field Replacement: Repairs in the field should be limited to those provided for in the box of spare parts furnished with the indicator. (See the drawing in Paragraph 2.01.) Other repairs should be taken care of as outlined in Paragraph 3.15.