

**BELL SYSTEM PRACTICES**  
**Outside Plant Construction**  
**and Maintenance**

**SECTION G85.071.1**  
**Issue 1, September, 1958**  
**AT&TCo Standard**


## **387B PLUG**

### **1. GENERAL**

1.01 This section describes the 387B Plug and covers the method of using it to facilitate connecting a telephone set to cable pairs terminated on 444-type jacks.

### **2. DESCRIPTION**

2.01 The 387B Plug is illustrated in the following sketch. Each plug is equipped with two lugs to which the test clips at the end of the leads of a telephone set may be firmly attached.



### **3. USE**

3.01 Connect the 387B Plug to a 444-type jack, as shown below. The test clips of the leads on the telephone set should be attached to the lugs, as illustrated.

