

SOLDERING EQUIPMENT AND WAX POTS

2. ELECTRIC SOLDERING COPPERS

- 2.02 Electric soldering coppers shall be disconnected when not in use.
- 2.03 Frayed cords or cords having broken insulation shall be repaired or replaced at once.
- 2.04 An electric soldering copper may break down internally in such a way that the metal parts of the tool become crossed with the heating circuit. This condition is indicated by arcing when the metal of the tool comes in contact with circuits or grounded frames. In such cases, the tool shall be taken out of service at once.
- 2.05 All cords for electric soldering coppers shall be equipped with

two-part extension plugs in good order. It is intended that these plugs shall automatically break the circuit if the cord is subjected to any sudden or excessive strain.

3. OPEN FLAME TORCHES

- 3.05 The restrictions on the use of such torches apply to everyone including telephone cable splicers and installers and to contractors employed on plumbing, heating, electrical wiring, or any other work.

4. HEATING IMPREGNATING COMPOUND
AND SOLDER

- 4.03 Note that the restrictions apply to everyone, including cable splicers, installers and outside contractors.