

TABLE OF CONTENTS

DIV. I - GENERAL

Sec. 1 Table of Contents.

DIV. II - "A" OPERATORS (AND SUPERVISORS)

- Sec. 1 Answering Calls.
Sec. 2 Obtaining and Acknowledging Orders.
~~Appendix "A" Calls for Time of Day~~
~~Sec. 3 Local Multiple Connections.~~
~~Sec. 4 Direct Call Circuit Trunk Connections.~~
~~Sec. 5 Direct Straightforward Trunk Connections.~~
~~*Sec. 6 Tandem Straightforward Trunk Connections.~~
~~Sec. 7 Ringdown Trunk and Built-up Connections.~~
~~Sec. 8 Key Indicator Trunk Connections.~~
~~Sec. 9 Dial Trunk Connections.~~
~~Sec. 10 Toll Line Connections.~~
Sec. 11 Supervising on Signal and Disconnecting.
Sec. 12 Completing Delayed Calls.
Sec. 13 A-B Toll Calls.
~~Sec. 14 Long Distance Calls.~~
Sec. 15 Requests for Rates and Charges.
~~Sec. 16 Information Calls.~~
~~Sec. 17 Calls for Official Lines.~~
Sec. 18 Emergency Calls,
Sec. 19 Telegram Calls,
Sec. 20 Message Rate Calls-Registered,
Sec. 21 Message Rate Calls-Ticketed.
Sec. 22 Postpayment Coinbox Calls.
Sec. 23 Prepayment Coinbox Calls,
Sec. 24 Calls for Rural Lines.
Sec. 25 Service Criticisms.
~~Sec. 26 Miscellaneous Orders and Requests.~~
~~1. Calling party requests the time of day.~~
~~2. Request for information regarding the location of fires, the results of sporting events, arrival and departure of trains, etc.~~
~~3. Request to be furnished a directory.~~
~~4. Calling party makes a request to have his telephone taken out, moved or changed.~~
~~5. Calling party asks the number or the class of service of the line on which he is talking.~~
~~6. Inquiry made as to your identity.~~
~~7. Calling party asks to have his bell rung.~~
~~8. Calling party states or indicates that his bell has been rung.~~
~~9. Called party requests the number or the name of the calling party.~~
~~10. Call from a party line on which service from one or more stations is denied for non-payment.~~

TABLE OF CONTENTS - Cont'd

- ~~V1. Call from an individual line on which service is denied for non-payment.~~
- ~~V2. Miscellaneous requests from subscribers.~~
- Sec.27 General Practices.
 - 1. Testing a line or trunk.
 - 2. Passing an order over a call circuit or trunk.
 - 3. Acknowledging repetition of orders by other operators.
 - 4. Acknowledging reports from other operators or from supervisors.
 - 5. Procedure after giving a report to the calling party.
 - 6. Excusing a call to the called party.
 - ~~V. Obtaining the calling party's number or station designation.~~
 - 8. Obtaining or checking the called number.
 - 9. Making a memorandum of the called number.
 - 10. Reaching the calling station.
 - 11. Split cord operation.
 - 12. Starting conversation.
 - 13. Use of prescribed and alternate phrases.
 - 14. Supervisors' calls.
- Sec.28 Equipment Trouble.
- Sec.29 Sample Tickets.
- ~~Sec.30 Patrol Transfer Method.~~

DIV. III - "B" OPERATORS (AND SUPERVISORS)

- *Sec. 1-A Automatic Listening Straightforward Positions.
- *Sec. 1-B Key Listening Straightforward Positions-Call Indicator Temporarily Straightforward.
- *Sec. 1-C Key Listening Straightforward Positions-Manual Ringing Trunks Converted from Call Circuit to Straightforward. (Except No. 9 Boards)
- *Sec. 1-D Key Listening Straightforward Positions-New Manual Ringing Trunks. (Except No. 9 Boards)
- *Sec. 1-E Key Listening Straightforward Positions-No. 9 Boards with Manual Ringing Trunks Converted from Call Circuit to Straightforward.
- ~~Sec. 1-F Key Listening Straightforward Positions No. 9 Boards with New Manual Ringing Trunks.~~
- *Sec. 1-G Jack Listening Straightforward Positions-Machine Ringing Trunks. (Except No. 9 Boards)
- *Sec. 1-H Jack Listening Straightforward Positions-Manual Ringing Trunks Converted from Call Circuit to Straightforward.
- *Sec. 1-I Jack Listening Straightforward Positions-New Manual Ringing Trunks.
- ~~Sec. 1-J Call Circuit Positions.~~
- Sec. 2 Establishing Connection.
- Sec. 3 Equipment Trouble.
- Sec. 4 Plugging up Lines on Plugging-up Cords, Extension Voltmeter Cords, Extension Test Cords and Transfer Test Cords.

GENERAL

TABLE OF CONTENTS - Cont'd

~~DIV. IV - "B" CALL INDICATOR OPERATORS (AND SUPERVISORS)~~

- ~~Sec. 1-A Panel Key Display Positions.~~
- ~~Sec. 1-B Step-by-Step Key Display Positions.~~

*DIV. V - TANDEM COMPLETING OPERATORS (AND SUPERVISORS) AT "A" BOARDS

- Sec. 1 Incoming Trunks for Use with "A" Cord Circuits.

~~DIV. VI - TOLL SWITCHING OPERATORS (AND SUPERVISORS)~~

- ~~Sec. 1 Straightforward Positions.~~
- ~~Sec. 2 Call Circuit Positions.~~

*DIV. VII - TANDEM OPERATORS (AND SUPERVISORS)

- Sec. 1-A Automatic Listening Positions.
- Sec. 1-B Key Listening Positions-Call Indicator Temporarily Straightforward.
- Sec. 2 Establishing Connection.
- Sec. 3 Equipment Trouble.

*DIV. VIII - TANDEM CALL INDICATOR OPERATORS (AND SUPERVISORS)

- Sec. 1 Panel Key Display Positions.

*DIV. IX - TRIBUTARY TANDEM OPERATORS (AND SUPERVISORS)

- Sec. 1 Tributary Tandem Positions.

DIV. X - RINGDOWN OPERATORS (AND SUPERVISORS)

- Sec. 1 Answering Calls and Obtaining and Acknowledging Orders.
- Sec. 2 Establishing Connection.
- Sec. 3 Supervising on Signal and Disconnecting.
- Sec. 4 Long Distance Calls.

~~DIV. XI - INTERCEPTING OPERATORS (AND SUPERVISORS)~~

- ~~Sec. 1 Intercepted Calls - Method A (Where calls are not completed through the intercepting position but a report is given to the "A" or "B" operator by looping back, the "A" operator's front supervisory signal remains lighted when the intercepting operator answers.)~~
- ~~Sec. 2 Intercepted Calls - Method B (Where calls are not completed through the intercepting positions and no report is given to the "A" operator, the "A" operator's front supervisory signal remains lighted when the intercepting operator answers.)~~

GENERAL

TABLE OF CONTENTS - Cont'd

- ~~Sec. 3 Intercepted Calls - Method C (Where calls are not completed through the intercepting position but a report is given to the "A" operator either by flashing back or by looping back, the "A" operator's front supervisory signal goes out when the Intercepting operator answers.)~~
- ~~Sec. 4 Intercepted Calls - Method D (Where calls are completed through the intercepting position or a report is given to the "A" operator either by flashing back or by looping back, the "A" operator's front supervisory signal goes out when the Intercepting operator answers.)~~
- ~~*Sec. 5 Intercepted Calls - Method E (Where calls are completed through the intercepting positions or a report is given to the "A" or "B" operator by looping back. The "A" operator's front supervisory signal remains lighted when the intercepting operator answers and on a call completed through her position, goes out when the called station answers.)~~

DIV. XII - TROUBLE OPERATORS (AND SUPERVISORS)

- Sec. 1 Permanent Signals.
Sec. 2 Calls for Lines Out of Order.
Sec. 3 Verifying Busy and Don't Answer Reports.
Sec. 4 Plugging Up Open Lines and Ringdown Trunks.
Sec. 5 Handling Transfer Test Cords.
Sec. 6 *Miscellaneous Conditions*

DIV. XIII - RURAL OPERATORS (AND SUPERVISORS)

- Sec. 1 Rural Line Calls

FEDERAL TAX REFERENCES

- ~~Div. II, Sec. 15, paragraphs 4 and 5 ("A" operators)
Div. II, Sec. 19, paragraph 6 ("A" operators)
Div. II, Sec. 22, paragraphs 5 and 8 ("A" operators) paragraphs 10, 16 and 17 ("A" supervisors)
Div. II, Sec. 23, paragraph 6A ("A" operators) paragraphs 13, 24 and 25 ("A" supervisors)
Div. II, Sec. 27, paragraphs 15, 16 and 17 ("A" operators)
Div. II, Sec. 31, paragraph 5 ("A" operators)~~

~~*These sections are not usable in this exchange and, therefore, are not filed in this binder.~~