

| | | | |
|-------|---------|---------|---|
| ISSUE | 1 | 2 | 3 |
| DATE | 6-25-51 | 10-7-53 | |

MISC. CKT. EMERGENCY TRANSLATOR CONNECTOR

EMERGENCY CARD TRANSLATOR

TOS

MISC. CKT. TROUBLE RECORDER

REPLACING FOREIGN AREA TRANSLATOR

SEQUENCE CHART

REPLACING HOME TRANSLATOR



EA

EB


HE

PLUGS IN FBO & FBE JACKS

PLUG IN DB JACK



DECODER



FBO-, FBE- (MTR)

TOS (DFT)

TOS (FAT)

TOS (DFT)

SEE NOTE 2

PLUG IN FE JACK

PLUG IN HE JACK

EMO, EME

HE (D)

PLUGS REMOVED FROM FBO & FBE JACKS

HE (ET)

FBO-, FBE- (MTR)

PLUG REMOVED FROM DB JACK

P (ET)

TOS (DFT)


C (ET)

P (ET)


XCO-2 (ET)

XCO-2 (ET)


HOME CARD TRANSLATOR




DECODER FOREIGN AREA CARD TRANSLATOR



FOREIGN AREA CARD TRANSLATOR




TRANSLATOR CONNECTOR



SN MG

MGI

MAJOR ALARM



NOTES:

| OS OPTION | FEATURE OR OPTION | SD OPTION | SD |
|-----------|------------------------|------------------|----------|
| A | NON-PAIRED TRANSLATORS | FIG. 33 | 68392-01 |
| B | PAIRED TRANSLATORS | FIG. 33, FIG. 66 | 68392-01 |
| C | FOR DECODERS 0-9 | FIG. 4 | 68341-01 |
| D | FOR DECODERS 10-17 | FIG. 5 | 68341-01 |

2. THE CARDS ARE REMOVED FROM BOX (DFT OR FAT) AND PLACED IN EMERGENCY BOX.

- DECODER CONNECTOR CKT. SD-68339-01, 155.6
- CARD TRANSLATOR CKT. SD-68342-01, 155.7
- DECODER CKT. SD-68340-01, 155.8
- MISC. CKT. EMER. TRNSL. CONN. SD-68429-01, 155.3
- MISC. CKT. TRNSL. CONN. SD-68418-01, 155.3
- MISC. CKT. TROUBLE RECORDER SD-68392-01, 155.5
- *TRANSLATOR CONNECTOR CKT. SD-68341-01, 155.6

**TRANSLATOR CONNECTOR
MAKE BUSY ARRANGEMENTS
FOR TRANSLATORS
AND
SUBSTITUTION OF EMERGENCY
TRANSLATOR**