






CARD TRANSLATOR

TRANSLATOR CONNECTOR

DECODER



TO LEAD A TABLE A
TO LEAD A TABLE B
TO LEAD A TABLE D

DECODER INPUT INFORMATION TO CARD TRANSLATOR

OS 162-1

3 SHEETS, SHEET 1

NO. 4A OR 4M TOLL

BELL TELEPHONE LABORATORIES, INC.

ISSUE	1	2	3	4	5
DATE	9-17-51	9-30-53			

3 SHEETS, SHEET 1

MP-11682

PRINTED IN U. S. A.

ISSUE	DATE
1	9-17-51
2	9-30-51

TABLE A

OPERATION OF AO-D7 CODE BAR MAGNETS																								
INCOMING SENDER		DECODER CONNECTOR		DECODER								TRANSLATOR CONNECTOR		CARD TRANSLATOR										
REGISTER RELAY CONTACTS	CONNECTOR RELAY CONTACTS	TROUBLE RECORDER CUT-IN RELAY CONTACTS	PUNCH	CODE CUT-IN RELAY CONTACTS	LEAD TO SHEET 1	HOME TRANSLATOR CONN. RELAY CONTACTS	DECODER FOREIGN-AREA TRANSLATOR CONN. RELAY CONTACTS	CONNECTOR RELAY CONTACTS	CODE BAR RELAYS	RES.	JACK SPRING	CODE BAR MAGNETS	JACK SPRING	CODE BAR SLAVE RELAY CONTACTS										
AO	20	20	RT1	0	AO	1T	CC1	2T	AO	4T	HC11	3T	4T	FC11	3T	20	AO	AO	18	AO	9	5T	SA0	6T
A1	21	21	RT1	1	A1	3T	CC1	4T	A1	6T	HC11	5T	6T	FC11	5T	21	A1	A1	19	A1	27	9T	SA1	10T
A2	22	22	RT1	2	A2	5T	CC1	6T	A2	8T	HC11	7T	8T	FC11	7T	22	A2	A2	20	A2	45	9T	SA2	10T
A4	23	23	RT1	3	A4	7T	CC1	8T	A4	10B	HC11	9B	10B	FC11	9B	23	A4	A4	21	A4	63	9T	SA4	10T
A7	24	24	RT1	4	A7	9T	CC1	10T	A7	12B	HC11	11B	12B	FC11	11B	24	A7	A7	22	A7	81	9T	SA7	10T
BO	30	30	RT	54	BO	1B	CC1	2B	BO	2B	HC11	1B	2B	FC11	1B	30	BO	BO	36	BO	10	5T	SB0	6T
B1	31	31	RT	55	B1	3B	CC1	4B	B1	4B	HC11	3B	4B	FC11	3B	31	B1	B1	37	B1	28	9T	SB1	10T
B2	32	32	RT	56	B2	5B	CC1	6B	B2	6B	HC11	5B	6B	FC11	5B	32	B2	B2	38	B2	46	9T	SB2	10T
B4	33	33	RT	57	B4	7B	CC1	8B	B4	8B	HC11	7B	8B	FC11	7B	33	B4	B4	39	B4	64	9T	SB4	10T
B7	34	34	RT	58	B7	9B	CC1	10B	B7	12T	HC12	11T	12T	FC12	11T	34	B7	B7	40	B7	82	9T	SB7	10T
CC	40	40	RT	49	CC	1T	CC2	2T	CO	2T	HC12	1T	2T	FC12	1T	40	CO	CO	54	CO	10	5T	SC0	6T
C1	41	41	RT	50	C1	3T	CC2	4T	C1	4T	HC12	3T	4T	FC12	3T	41	C1	C1	55	C1	28	9T	SC1	10T
C2	42	42	RT	51	C2	5T	CC2	6T	C2	6T	HC12	5T	6T	FC12	5T	42	C2	C2	56	C2	46	9T	SC2	10T
C4	43	43	RT	52	C4	7T	CC2	8T	C4	8T	HC12	7T	8T	FC12	7T	43	C4	C4	57	C4	64	9T	SC4	10T
C7	44	44	RT	53	C7	9T	CC2	10T	C7	10T	HC12	9T	10T	FC12	9T	44	C7	C7	78	C7	82	9T	SC7	10T
DO	25	25	RT	44	DO	1T	CC3	2T	NONE	2B	HC12	1B	2B	FC12	1B	25	DO	DO	72	DO	11	5T	SD0	6T
D1	26	26	RT	45	D1	3T	CC3	4T	NONE	4B	HC12	3B	4B	FC12	3B	26	D1	D1	73	D1	29	9T	SD1	10T
D2	27	27	RT	46	D2	5T	CC3	6T	NONE	6B	HC12	5B	6B	FC12	5B	27	D2	D2	74	D2	47	9T	SD2	10T
D4	28	28	RT	47	D4	7T	CC3	8T	NONE	8B	HC12	7B	8B	FC12	7B	28	D4	D4	75	D4	65	9T	SD4	10T
D7	29	29	RT	48	D7	9T	CC3	10T	NONE	10B	HC12	9B	10B	FC12	9B	29	D7	D7	76	D7	83	9T	SD7	10T




TABLE B

OPERATION OF E0-F7 CODE BAR MAGNETS																						
INCOMING SENDER		DECODER CONNECTOR		DECODER								TRANSLATOR CONNECTOR		CARD TRANSLATOR								
REGISTER RELAY CONTACTS	DESIGNATION OF LEAD TO SHEET 1	CONNECTOR RELAY CONTACTS	TBL. RCDR. CUT-IN RELAY CONTACTS	PUNCH	CODE CUT-IN RELAY CONTACTS	HOME TRANSLATOR CONN. RELAY CONTACTS	DECODER FOREIGN-AREA TRANSLATOR CONN. RELAY CONTACTS	CONNECTOR RELAY CONTACTS	CODE BAR RELAYS	RES.	JACK SPRING	CODE BAR MAGNETS	JACK SPRING	CODE BAR SLAVE RELAY CONTACTS								
E0	E0-A	E0-B	35	35	39	E0	1B	CC3	2E	4T	3T	4T	3T	35	E0	E0	90	E0	11	5T	SE0	6T
E1	E1-A	E1-B	36	36	40	E1	3B	CC3	4B	6T	5T	6T	5T	36	E1	E1	91	E1	29	9T	SE1	10T
E2	E2-A	E2-B	37	37	41	E2	5B	CC3	6B	8T	7T	8T	7T	37	E2	E2	92	E2	47	9T	SE2	10T
E4	E4-A	E4-B	38	38	42	E4	7B	CC3	8B	10T	9T	10T	9T	38	E4	E4	93	E4	65	9T	SE4	10T
E7	E7-A	E7-B	39	39	43	E7	9B	CC3	10B	12T	11T	12T	11T	39	E7	E7	94	E7	83	9T	SE7	10T
FO	FO-A	FO-B	45	45	34	FO	1T	CC4	2T	2T	1T	2T	1T	45	FO	FO	108	FO	12	5T	SFO	6T
F1	F1-A	F1-B	46	46	35	F1	3T	CC4	4T	4B	3B	4B	3B	46	F1	F1	109	F1	30	9T	SF1	10T
F2	F2-A	F2-B	47	47	36	F2	5T	CC4	6T	6B	5B	6B	5B	47	F2	F2	110	F2	48	9T	SF2	10T
F4	F4-A	F4-B	48	48	37	F4	7T	CC4	8T	8B	7B	8B	7B	48	F4	F4	111	F4	66	9T	SF4	10T
F7	F7-A	F7-B	49	49	38	F7	9T	CC4	10T	10B	9B	10B	9B	49	F7	F7	112	F7	84	9T	SF7	10T




TABLE C

OPERATION OF CODE BAR SLAVE RELAYS													
CARD TRANSLATOR													
JACK SPRINGS	CODE BAR MAGNET CONTACTS	JACK SPRINGS	CODE BAR SLAVE RELAYS & CONTACTS	RES.	TROUBLE RECORDER CUT-IN RELAY CONTACTS	PUNCH							
5 & 23	CS1	13	4B SCS1	3B SCS1	8B RT	7B CS1							
5 & 23	VO	14	7T SVO	8T SVO	6B RT	5B VO							
5 & 23	NVO	15	7T SNVO	8T SNVO	4B RT	3B NVO							
5 & 23	AO	31	4B SA0	3B SA0	4T RT3	3T AO							
5 & 23	A1	32	6B SA1	5B SA1	6T RT3	5T A1							
5 & 23	A2	33	6B SA2	5B SA2	8T RT3	7T A2							
5 & 23	A4	34	6B SA4	5B SA4	10T RT3	9T A4							
5 & 23	A7	35	6B SA7	5B SA7	12T RT3	11T A7							
5 & 23	BO	49	4B SB0	3B SB0	4B RT3	3B BO							
5 & 23	B1	50	6B SB1	5B SB1	6B RT3	5B B1							
5 & 23	B2	51	6B SB2	5B SB2	8B RT3	7B B2							
5 & 23	B4	52	6B SB4	5B SB4	10B RT3	9B B4							
5 & 23	B7	53	6B SB7	5B SB7	12B RT3	11B B7							
5 & 23	CO	67	4B SCO	3B SCO	4T RT2	3T CO							
5 & 23	C1	68	6B SC1	5B SC1	6T RT2	5T C1							
5 & 23	C2	69	6B SC2	5B SC2	8T RT2	7T C2							
5 & 23	C4	70	6B SC4	5B SC4	10T RT2	9T C4							
5 & 23	C7	71	6B SC7	5B SC7	12T RT2	11T C7							
41 & 59	DO	85	4B SDO	3B SDO	4B RT2	3B DO							
41 & 59	D1	86	6B SD1	5B SD1	6B RT2	5B D1							
41 & 59	D2	87	6B SD2	5B SD2	8B RT2	7B D2							
41 & 59	D4	88	6B SD4	5B SD4	10B RT2	9B D4							
41 & 59	D7	89	6B SD7	5B SD7	12B RT2	11B D7							
41 & 59	EO	103	4B SEO	3B SEO	4T RT1	3T EO							
41 & 59	E1	104	6B SE1	5B SE1	6T RT1	5T E1							
41 & 59	E2	105	6B SE2	5B SE2	8T RT1	7T E2							
41 & 59	E4	106	6B SE4	5B SE4	10T RT1	9T E4							
41 & 59	E7	107	6B SE7	5B SE7	12T RT1	11T E7							
41 & 59	FO	121	4B SFO	3B SFO	4B RT1	3B FO							
41 & 59	F1	122	6B SF1	5B SF1	6B RT1	5B F1							
41 & 59	F2	123	6B SF2	5B SF2	8B RT1	7B F2							
41 & 59	F4	124	6B SF4	5B SF4	10B RT1	9B F4							
41 & 59	F7	125	6B SF7	5B SF7	12B RT1	11B F7							
41 & 59	CG0	139	8B SCG0	7B SCG0	2B RT1	1B CG0							
41 & 59	CG1	140	7B SCG1	6B SCG1	4T RT1	3T CG1							
41 & 59	CG2	141	10B SCG2	9B SCG2	12T RT1	11T CG2							
41 & 59	CG4	142	8B SCG4	7B SCG4	2B RT1	1B CG4							
41 & 59	CS2	143	4B SCS2	3B SCS2	10B RT1	9B CS2							





TABLE D

OPERATION OF CARD GROUPING CODE BAR MAGNETS													
DECODER		TRANSLATOR CONNECTOR		CARD TRANSLATOR									
DESIGNATION OF LEAD TO SHEET 1	HOME TRANSLATOR CONN. RELAY CONTACTS	DECODER FOREIGN-AREA RELAY CONTACTS	CONNECTOR RELAY CONTACTS	CODE BAR RELAYS	RES.	JACK SPRING	CODE BAR MAGNETS	JACK SPRING	CODE BAR SLAVE RELAY CONTACTS				
CG0	3T	4T	3T	4T	50	CG0	CG0	126	CG0	12	9T	SCG0	10T
CG1	5T	6T	5T	6T	51	CG1	CG1	127	CG1	30	9T	SCG1	10T
CG2	7T	8T	7T	8T	52	CG2	CG2	128	CG2	48	9T	SCG2	10T
CG4	9T	10T	9T	10T	53	CG4	CG4	129	CG4	66	9T	SCG4	10T




NOTES:

OS OPTION	FEATURE OR OPTION	SD OPTION	SD
A	FOR HOME TRANSLATOR.	FIG. 14	68340-01
		Y	68342-01
B	FOR DECODER FOREIGN TRANSLATOR	FIG. 15	68340-01
		W	68342-01
C	FOR FOREIGN TRANSLATOR.	Z	68341-01
		X	68342-01
D	FOR EMERGENCY TRANSLATOR	FIG. 3 & V	68341-01
		Z	68342-01
E	1 DIGIT TX CALLS	LOOPED WIRING	68221-01
			68423-01
			68424-01
F	2,3,OR 2 & 3 DIGIT TX CALLS	XWB	68221-01
		XWK	68423-01
			68424-01






- CS1 & 2 MAGNETS ARE ENERGIZED BY CS1 & 2 RELAYS OPERATED, BUT DO NOT OPERATE UNTIL CARD SUPPORT LIFT MAGNETS ARE DE-ENERGIZED.
- LEADS 1 & 2 CONNECT TO AO-A7 AS REQUIRED TO AGREE WITH 1ST DIGIT OF ROUTE RELAY NUMBER.
- LEADS 3 & 4 CONNECT TO BO-B7 AS REQUIRED TO AGREE WITH 2ND DIGIT OF ROUTE RELAY NUMBER.

SEQUENCE CHART



ISSUE	1	APR 51	2	MAY 51
DATE	9-17-51		9-30-51	

CARD TRANSLATOR



DECODER INPUT INFORMATION TO CARD TRANSLATOR