


INCOMING SENDER

TOLL SWITCHING TRUNK

SENDER LINK AND CONNECTOR

OUTGOING SENDER



- INCOMING LINK & CONNECTOR CKT. SD-68393 - 01, ISS. 7
- INCOMING SENDER CKT.-MF SD-68222 - 01, ISS. 16
- INCOMING TRUNK CKT. SD-68237 - 01, ISS. 7
- INT. FRAME CKT. SD-68058 - 01, ISS. 15
- MARKER CKT. SD-68388 - 01, ISS. 5
- OUTGOING LINK & CONNECTOR CKT. SD-68394 - 01, ISS. 5
- OUTGOING SENDER CKT. SD-68018 - 01, ISS. 25
- SENDER LINK & CONNECTOR CKT. SD-68334 - 01, ISS. 13
- TOLL SWITCHING TRK. CKT.-REV. OR PCL. SD-68326 - 01, ISS. 10
- TRUNK BLOCK CONNECTOR CKT. SD-68027 - 01, ISS. 13

MF INCOMING SENDER
 SL CHECK & SYNCHRONIZATION
 WITH OUTGOING SENDER

OS 141-1 2 SHEETS, SHEET 1 NO. 4A TOLL

ISSUE	1	2	3
DATE	11-26-51	7-27-53	

2 SHEETS, SHEET 1

MP-11736

REVISED	1	11/22/52	2	11/22/52
DATE	11-22-52	7-27-53		

