



Carrier VoIP

# Call Agent Performance Management

Document status: Standard  
Document version: 07.02  
Document date: 20 October 2006

Copyright © 2006, Nortel Networks  
All Rights Reserved.

The information in this document is sourced in Canada, the United States of America, and the United Kingdom.

This is the Way, This is Nortel, Nortel, the Nortel logo, the globemark design, and the NORTEL NETWORKS corporate logo, are trademarks of Nortel Networks. All other trademarks are the property of their respective owners. All rights reserved.

---

# Call Agent Performance Management

---

The Call Agent Manager provides performance statistics such as memory and processor usage for the Call Agent hardware and software platform. Call processing application statistics such as call attempts per hour are available from the MAP.

## New in this release

### Feature changes

See the following section for information about feature changes.

#### **Gigabit Ethernet interface for sparing for Compact Call Agent cards**

This feature is applicable only to the CS2100 for the enterprise market.

In this release, feature A00012478 introduces the Gigabit Ethernet interface for sparing for MCPN905-based Compact Call Agent (CCA) cards. (MCPN765-based CCA cards continue to use fiber channel sparing.) The introduction of Gigabit Ethernet sparing causes the following changes in the MAP interface:

- "Sparing link" or "SL" appears where "fiber channel" or "FC" formerly appeared.
- Under Compact Call Agent Maintenance (CCAMTC) in the MAP interface, there is a new command to query the sparing link. The command is "16 QuerySL". You can use the command to find out whether the fiber channel interface or the Gigabit Ethernet interface is selected for sparing.

These changes appear in the screen illustrations in this document.

### Other changes

There are no other changes.

### Performance strategy overview

Check the performance of the call processing application at the MAP. If performance is degraded, follow the MAP procedures and also investigate the performance of the platform from the Call Agent Manager.

In addition to the "CAPACITY" (page 6) performance management information in this section, refer to *Communication Server 2000 Performance Management*, NN10149-711, for information about using the call processing application operational measurements. For information about the available operational measurement groups, see *DMS-100 Operational Measurements Reference Manual*, 297-8001-814 (NA) or 297-9051-814 (EMEA).

---

## MAP performance procedures

---

The MAP is the call processing application interface.

Begin monitoring performance of the call processing application before monitoring the platform performance.

## CAPACITY

The CAPACITY level provides call processing statistics. Levels PARMS and SCHEDMAP are available from the CAPACITY level. These levels provide office parameter information and scheduler information.

### CAPACITY level

Access the CAPACITY level from the CI level:

CI:>

>MAPCI;MTC;CAPACITY

```

          IOD          CCS      Lns      Trks          APPL
          .            .        .        .            .
CAPACITY
0 Quit      CATMP/HR UTIL ENGCATMP ENGLEVE SYNC CCOVRLD IDLE SUTL
2 Parms    103320  --      --      BELOW YES  OFF  YES
3 SchedMap
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
  USERNAME
Time 10:29 >

```

**Note:** Fields UTIL and ENGCATMP do not display a value if CPU UTIL is below 15% or if field SYNC is "NO."

The following performance statistics are available.

Measurement	Unit	Description
CATMP/HR	Number	Call attempts per hour.

Measurement	Unit	Description
UTIL	Number	<p>If the call processing application is synchronized, then this field represents:</p> $UTIL = \frac{(callp\ occ + IO\ occ + SYS\ occ)}{(eng\_cp\_time + eng\_io\_time + eng\_sys)}$ <p><b>Note 1:</b> Processor occupancy is abbreviated to "occ" in the above calculations. Variables eng_cp_time, eng_io_time, and eng_sys are equal to the expected CPU occupancy of each class at capacity. For example, eng_sys is the amount of CPU time the SYS class is expected to require at capacity. The Call processing (callp) class processes calls, the IO class sends and receives messages, and the SYS class is used mostly to maintain synchronization of the call processing application between the two Call Agents.</p> <p><b>Note 2:</b> The sum of eng_cp_time, eng_io_time, and eng_sys is equal to the engineering point, 70%.</p>
ENGCATMP	Number	This field is equal to CATMP/HR divided by UTIL.
ENGLLEVEL	String	This field indicates if the current CATMP/HR are BELOW or ABOVE the calculated value for ENGCATMP.
CCOVRD	ON/OFF	Status of Central Control Overload controls in the last minute.

The call attempts data is obtained from registers in the OFZ operational measurement (OM) group. The following table provides additional information on the specific registers used from OFZ.

#### OM registers in OM group OFZ used to determine Call Rate

OM Field	Description
NIN	Number of incoming calls
NIN2	Extension register for NIN
NORIG	Number of originating calls
NORIG2	Extension register for NORIG

## PARMS level

Access the PARMS level from the CAPACITY level.

>PARMS

```

          IOD          CCS      Lns      Trks          APPL
          .            .        .        .            .
CAPACITY
0 Quit      CATMP/HR UTIL ENGCATMP ENGLEVELE SYNC CCOVRLD IDLE SUTL
2 Parms    103320  --      --      BELOW YES      OFF YES
3 SchedMap
4          Parms
5          Guaranteed Terminal_CPU_Share = 0%
6          AUXCP_CPU_Share = 1%
7          CC_Englevel_Warning_Threshold = 77%
8          NETM share setting = 0%
9          DNC share setting = 3%
10         SNIP share setting = 1%
11         1% CPU allocation = -- CATMP/HR
12
13
14
15
16
17
18
  USERNAME
Time 10:42 >

```

- **GUARANTEED\_TERMINAL\_CPU\_SHARE**

Displays the current setting for this office parameter in table OFCENG (Office Engineering). This value determines the expected occupancy for GTERM at capacity and determines the ratio shown in the GTERM field on the SCHEDMAP level.

- **AUXCP\_CPU\_SHARE**

Displays the current setting for this office parameter in table OFCENG. This value determines the expected occupancy for AUXCP at capacity and determines the ratio shown in the AUXCP field on the SCHEDMAP level.

- **CC\_ENGLEVELE\_WARNING\_THRESHOLD**

Displays the current setting for this office parameter in table OFCENG (default value of 100). This value triggers the display for the ENGLEVELE field at the Capacity MAP level and uses the value ABOVE or BELOW.

- **NETM Share setting**

Time allocated to NETMTC class. This value determines the expected occupancy for NETM at capacity and determines the ratio shown in the NETM field on the SCHEDMAP level.

- **DNC Share setting**

Time allocated to NOSFT class. This value determines the expected occupancy for NOSFT at capacity and determines the ratio shown in the DNC field on the SCHEDMAP level.

- **SNIP Share setting**

Time allocated to SNIP class. This value determines the expected occupancy for SNIP at capacity and determines the ratio shown in the SNIP field on the SCHEDMAP level.

- **1% CPU Allocation**

The 1% CPU Allocation measurement is no longer supported.

## SCHEDMAP level

This level provides information about the scheduler system.

Office parameters AUXCP and GTERM settings can be changed in table OFCENG. Changing these parameters alters the amount of time that is available for call processing and changes the reported call capacity utilization.

```

      IOD          CCS      Lns      Trks          APPL
SchedMap          .
0 Quit           CATMP/HR  UTIL ENGCATMP  ENGLEVE  SYNC  CCOVRLD  IDLE
2 Parms         103800    --      --      BELOW  YES   OFF   YES
3
4              SCHED  FORE MAINT  DNC  AUXCP  OM  GTERM  BKG NETM SNIP
5              367   3163   11    0    5    58    0  169  0  32
6
7
8              SCHEDMAP:
9
10
11
12
13
14
15
16
17
18
  USERNAME
Time 11:02 >

```

The following table describes the fields for the SCHEDMAP level.

Measurement	Unit	Description
SCHED	Percent	Observed scheduler overhead utilization relative to the expected overhead occupancy at capacity (Expected occupancy or OCCexp = 8%).
FORE	Percent	Observed operating system utilization relative to the expected occupancy at capacity. Foreground includes SYSTEMCLASS, SYSTOOLCLASS, INITCLASS (OCCexp = 1%).
MAINT	Percent	Observed MAINTCLASS utilization relative to the expected occupancy at capacity (OCCalloc = 8%).

Measurement	Unit	Description
DNC	Percent	Observed NOSFTCLASS utilization relative to the expected occupancy allocated at capacity. DNC includes NOSFT class (OCCalloc = 3%).
AUXCP	Percent	Observed AUXCPCLASS utilization relative to the expected occupancy at capacity. This value can be altered via the office parm AUXCP_CPU_SHARE (OCCalloc = 1% to 25%).
OM	Percent	Observed OM utilization relative to the expected occupancy at capacity. OM includes GOMCLASS and NGOMCLASS (OCCalloc = 3%).
GTERM	Percent	Observed GTERMCLASS utilization relative to the expected occupancy at capacity. This value can be altered via the office parm GUARANTEED_TERMINAL_CPU_SHARE (OCCalloc = 2% to 16%).
BKG	Percent	Observed background classes utilization relative to the expected occupancy at capacity. Background includes BKGCLASS and AUDITCLASS (OCCalloc = 3%).
NETM	Percent	Observed NETMTCCCLASS utilization relative to the expected occupancy allocated at capacity (OCCalloc = 0%).
SNIP	Percent	Observed SNIPCLASS utilization relative to the expected occupancy at capacity (OCCalloc = 1%).

---

## Call Agent Mgr performance procedures

---

The Call Agent Manager provides performance statistics for the Call Agent hardware and software platform. This information includes statistics like memory and processor usage. Call processing statistics are not reported to the Call Agent Manager. Call processing statistics are available at the MAP.

## Retrieving the processor load

The Call Agent uses the number of processes in a runnable state to indicate the processor load.

### Retrieving the processor load

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
`CoreMtc`
- 2 Enter the Sys level.  
`Sys`
- 3 Enter the QryCPU command.  
`QryCPU`

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit         Unit0 Inact no      . Inact . Act .      . insync .
2 QryCPU       Unit1 Act  no      . Inact . Act .      . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS
7 QryLd        CPU report retrieved on Tue Jul  2 11:54:23 2003:
8 QryNTP
9 QryCpUtl     1 min Load Avg: 0.25
10             5 min Load Avg: 0.17
11             15 min Load Avg: 0.08
12
13 LogQuery    Number of Processes: 50
14 Alarm
15 QueryIP     Alarm Description: 1 minute load average
16 QuerySL     Minor threshold: 10.00
17 Help        Major threshold: 20.00
18 Refresh     Critical threshold: 40.00
mtc
Time 11:54 >

```

- 4 This procedure is complete.

—End—

## Retrieving disk usage

The Call Agent implements a filesystem in RAM (RAMDISK) for platform applications. Use this procedure to determine statistics for this RAMDISK.

### Retrieving disk usage

---

#### Step Action

---

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
`CoreMtc`
- 2 Enter the Sys level.  
`Sys`
- 3 Enter the QryDsk command.  
`QryDsk`

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit        Unit0 Inact no      . Inact . Act  .      . insync .
2 QryCPU      Unit1 Act  no      . Inact . Act  .      . insync .
3 QryDsk
4 QryMem      Disk report retrieved on Tue Jul  2 11:57:02 2005:
5 QryZmb
6 QryNFS      Total Disk Size:   30.40 MB
7 QryLd       Free Root Disk:   12.34 MB (41%)
8 QryNTP      Free User Disk:   10.77 MB (35%)
9 QryCpUtl
10            Total File Nodes:   8064 blocks
11            Free File Nodes:   6320 blocks (78%)
12            Block Size:       1 KB
13 LogQuery   Max Filename Length: 255
14 Alarm
15 QueryIP    Alarm Description: Percentage root free disk space
16 QuerySL    Minor threshold: 15
17 Help       Major threshold: 10
18 Refresh    Critical threshold: 5
   mtc
Time 12:02 >

```

- 4 This procedure is complete.

---

—End—

---

## Retrieving memory usage

Use this command to determine the amount of platform RAM available and the amount used.

### Retrieving memory usage

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
`CoreMtc`
- 2 Enter the Sys level.  
`Sys`
- 3 Enter the QryMem command.  
`QryMem`

```

CallAgent      SYS      CON      APPL      Unit: 0
.
.
.
Sys
0 Quit         Unit0 Inact no . Inact . Act . . insync .
2 QryCPU       Unit1 Act  no . Inact . Act . . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS       Memory report retrieved on Tue Jul  2 08:33:34 2005:
7 QryLd
8 QryNTP       Total Memory:      961 MB
9 QryCpUtl     Free Memory:       92 MB (10%)
10             Cached Memory:    240 MB (25%)
11             Shared Memory:  87 MB ( 9%)
12             Buffer Memory:   31 MB ( 3%)
13 LogQuery    Reserved Memory: 3 0.21 MB
14 Alarm       Available Memory: 223.37 MB (free+cached+buffer-reserved)
15 QueryIP     Alarm Description: Based on the amount of avail memory remaining
16 QuerySL     Minor threshold: 20
17 Help        Major threshold: 15
18 Refresh     Critical threshold: 10
mtc
Time 08:33 >

```

- 4 This procedure is complete

—End—

## Retrieving zombie process statistics

Use this command to query information about the number of zombie processes running on the Call Agent card.

### Retrieving zombie process statistics

Step	Action
------	--------

*At the Call Agent Manager*

- |   |  |
|---|--|
| 1 | Enter the CoreMtc level.<br><b>CoreMtc</b> |
| 2 | Enter the Sys level.<br><b>Sys</b>         |
| 3 | Enter the QryZmb command.<br><b>QryZmb</b> |

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit         Unit0 Inact no      . Inact . Act .      . insync .
2 QryCPU       Unit1 Act  no      . Inact . Act .      . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS
7 QryLd
8 QryNTP
9 QryCpUtl
10
11             Zombie process report retrieved on Fri Nov  2 12:23:46 2005:
12
13 LogQuery    Number of Zombie Processes: 0
14 Alarm
15 QueryIP     Alarm Description: Number of zombie processes
16 QuerySL     Minor threshold: 5
17 Help        Major threshold: 10
18 Refresh     Critical threshold: 15
   mtc
Time 12:24 >

```

- |   |                             |
|---|-----------------------------|
| 4 | This procedure is complete. |
|---|-----------------------------|

—End—

## Retrieving NFS mount points

Nonvolatile storage for the Call Agent is provided by the STORage Management (STORM) unit. The Call Agent accesses this storage through the STORM unit. Each STORM controls and accesses mount points.

Use this procedure to determine the number of mount points and the number of accessible mount points.

### Retrieving NFS mount points

Step	Action
<i>At the Call Agent Manager</i>	
1	Enter the CoreMtc level. <b>CoreMtc</b>
2	Enter the Sys level. <b>Sys</b>
3	Enter the QryNFS command. <b>QryNFS</b>
4	This procedure is complete.

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit        Unit0 Act    no      . Act    . Inact  .      . insync .
2 QryCPU      Unit1 Inact  no      . Act    . Inact  .      . insync .
3 QryDsk
4 QryMem      NFS mount report retrieved on Tue Jul  2 12:23:08 2005:
5 QryZmb
6 QryNFS      Number of accessible mounts: 6 / 6
7 QryLd
8 QryNTP      Local Name                      Accessible %Used
9 QryCpUtl    /TAPE                            Y           51
10            /3PC/sd00                        Y           15
11            /var/log                          Y           51
12            /TAPE1                            Y           14
13 LogQuery   /PC/sd01                         Y           13
14 Alarm      /var/log_mate                    Y           14
15 QueryIP
16 QuerySL    Alarm Description: Number of accessible mounts with free space
17 Help      Minor threshold: 5
18 Refresh    Major threshold: 3
   mtc      Critical threshold: 2
Time 12:37 >

```

---

—End—

---

### **Additional information**

The Minor threshold is always one less than the number of mount points.

## Retrieving software versions

Use this command to determine the platform operating system and platform application versions.

### Retrieving software versions

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
`CoreMtc`
- 2 Enter the Sys level.  
`Sys`
- 3 Enter the QryLd command.  
`QryLd`

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit        Unit0 Inact no      . Inact . Act .      . insync .
2 QryCPU      Unit1 Act  no      . Inact . Act .      . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS
7 QryLd
8 QryNTP
9 QryCpUtl
10
11
12
13 LogQuery   System load report retrieved on Fri Mar 17 16:26:52 2006:
14 Alarm
15 QueryIP    Ramdisk: ncgl_cca_905_image_9.11.1.0
16 QuerySL    Linux: 2.4.22-ncgl-9.11.1.0 #1 Wed Mar 17 04:48:59 EST 2006
17 Help       Peel: 9.25.0
18 Refresh    Maintenance: 5.0.15
   mtc
Time 16:27 >

```

- 4 This procedure is complete.

—End—

## Retrieving Network Time Protocol information

Use this command to query the number of Network Time Protocol (NTP) servers accessible by the Call Agent and any time offset from the time servers. NTP servers are provisioned at the CS 2000 SAM21 Manager client.

### Retrieving Network Time Protocol information

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
**CoreMtc**
- 2 Enter the Sys level.  
**Sys**
- 3 Enter the QryNTP command.  
**QryNTP**

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .              .

Sys
0 Quit         Unit0 Inact no      . Inact . Act  .      . insync .
2 QryCPU      Unit1 Act  no      . Inact . Act  .      . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS
7 QryLd
8 QryNTP
9 QryCpUtl
10
11
12
13 LogQuery   NTP report retrieved on Tue Jul  2 13:01:21 2003:
14 Alarm
15 QueryIP    Total number of time servers: 2
16 QuerySL    Number of accessible servers: 2
17 Help       Number of synchronized servers: 2
18 Refresh    Time Offset from server 10.40.24.251: 0(ms)
mtc
Time 13:02 >

```

- 4 This procedure is complete.

---

—End—

---

## Retrieving CPU utilization

Use this procedure to measure CPU utilization. This metric is a more accurate measure of system load than `QryCPU`.

### Retrieving CPU utilization

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the CoreMtc level.  
`CoreMtc`
- 2 Enter the Sys level.  
`Sys`
- 3 Enter the QryCpUtl command.  
`QryCpUtl`

```

CallAgent      SYS      CON      APPL      Unit: 0
.              .              .              .

Sys
0 Quit         Unit0 Inact no      . Inact . Act .      . insync .
2 QryCPU       Unit1 Act  no      . Inact . Act .      . insync .
3 QryDsk
4 QryMem
5 QryZmb
6 QryNFS
7 QryLd
8 QryNTP
9 QryCpUtl
10             CPU Utilization report retrieved on Mon Mar  3  8:54:52 2003:
11
12             5 min Util Avg: 53.08
13 LogQuery    20 min Util Avg: 52.83
14 Alarm       30 min Util Avg: 52.78
15 QueryIP     Alarm Description: cpu utilization average
16 QuerySL     Minor threshold: over 95.00% for 5 minutes
17 Help        Major threshold: over 99.00% for 20 minutes
18 Refresh     Critical threshold: over 99.00% for 30 minutes
   mtc
Time  8:55  >

```

- 4 This procedure is complete.

—End—



## Message controller

When the CS 2000 - Compact is deployed in a Time Division Multiplex (TDM) network, a pair of Message Controller cards are installed in the SAM21 shelf. These cards work between the Call Agent cards and the Message Switch (MS).

Performance management for the Message Controller cards is completed through the Call Agent Manager.

### MCMtc level of the Call Agent Manager

```

CallAgent      SYS      CON      APPL      MC      Unit: 0
.              .        .        .        .        .

MCMtc
0 Quit         MC0      .        . Act     . Inact   open      open
2              MC1      .        . Act     . Inact   open      open
3
4
5 QryLd
6 QryHits
7 ClrHits
8 Trnsl
9
10
11
12
13 LogQuery
14 Alarm
15             QryHits:  Display link hit rate on an MC blade.
16             Parns:  [MCBladeNum] [MCLinkNum]
17 Help                MCBladeNum  -  0 or 1
18 Refresh             MCLinkNum   -  0 or 1
   mtc
Time 13:42 >

```

## Retrieving ATM link performance

Use this procedure to query the performance statistics for an ATM link between the Message Controller card and the Message Switch (MS). The statistics are generated and recorded by the ATM PMC interface and made available to the operating system. The `QryHits` command initiates the operating system to refresh the data.

### Retrieving ATM link performance

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the MCMtc level.  
`MCMtc`
- 2 Use the QryHits command to view the statistics.  
`QryHits <mc_no> <lnk_no>`

#### Example

```
QryHits 0 0
```

*Statistics for the link are displayed to the screen.*

```

CallAgent      SYS      CON      APPL      MC      Unit: 0
.              .              .              .              .
MCMtc          Blade:  Eth0:    Eth1:    Atm0:    Atm1:
0 Quit         MC0      .        . Act    . Inact  open    open
2              MC1      .        . Act    . Inact  open    open
3
4
5 QryLd
6 QryHits
7 ClrHits
8 Trnsl        Hit Count report retrieved on Mon Mar 24 14:05:06 2003:
9
10             SBIP      = 430
11             LBIP      = 940
12             PBIP      = 372
13 LogQuery    LPEBE    = 2920
14 Alarm       PFEBE    = 1464
15             CORR HCS   = 7
16             UNCORR HCS = 52
17 Help        TX CELLS = 2147403647
18 Refresh     RX CELLS = 87199426
mtc
Time 14:05 >

```

- 3 Repeat the query for the other three ATM links and use the information in "[Additional information](#)" (page 25) to assess the status of the links.
- 4 This procedure is complete.

---

—End—

---

## Additional information

Review the abbreviations.

### **SBIP, LBIP, PBIP**

These values indicate the section, line, and path bit interleave parity (BIP) errors for the link.

### **LFEBE, PFEBE**

These values indicate the line and path far end bit errors for the link.

### **CORR HCS, UNCORR HCS**

These values indicate the number of cells with correctable and uncorrectable higher order connection supervision for the link.

### **RX CELLS, TX CELLS**

These values indicate the number cells received and sent over the link.

If the error values appear, check recent log reports to determine if a Message Controller card was removed from service, CCA340 and SM21500, or if the Message Switch entered a trouble condition, MS log reports. Use the `clear hits` command to zero the counters and monitor the link performance.

The TX CELLS value increases at the constant ATM cell rate of 365 566 cells per second. This value does not indicate the number of cells that carried data only, it is the total number of cells transmitted. At this cell rate, the TX CELLS counter reaches its maximum limit of 2 147 483 647 in 96 minutes.

The RX CELLS value reaches its maximum limit of 2 147 483 647 in approximately 42 hours.

## Clearing ATM performance counters

Use this procedure to zero the ATM link performance counters.

### Clearing ATM performance counters

Step	Action
------	--------

*At the Call Agent Manager*

- 1 Enter the MCMtc level.

```
MCMtc
```

- 2 Use the ClrHits command to zero the statistics.

```
ClrHits <mc_no> <lnk_no>
```

**Example**

```
ClrHits 0 0
```

*Statistics for the link are displayed to the screen.*

```

CallAgent      SYS      CON      APPL      MC      Unit: 0
.              .              .              .              .
.              .              .              .              .
MCMtc          Blade:   Eth0:     Eth1:     Atm0:    Atm1:
0 Quit        MC0      .        . Act    . Inact   open     open
2             MC1      .        . Act    . Inact   open     open
3
4
5 QryLd
6 QryHits
7 ClrHits
8 Trnsl
9
10
11
12
13 LogQuery
14 Alarm
15
16
17 Help
18 Refresh    Request passed.
   mtc
Time 14:05 > 7 0 0

```

- 3 If preferred, clear the hits for the other link on the Message Controller.

**Example**

```
> 7 0 1
```

- 4 This procedure is complete.

—End—



Carrier VoIP

## Call Agent Performance Management

Copyright © 2006, Nortel Networks  
All Rights Reserved.

Publication: NN10153-711  
Document status: Standard  
Document version: 07.02  
Document date: 20 October 2006

To provide feedback or report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

The information in this document is sourced in Canada, the United States of America, and the United Kingdom.

The information contained herein is the property of Nortel Networks and is strictly confidential. Except as expressly authorized in writing by Nortel Networks, the holder shall keep all information contained herein confidential, shall disclose it only to its employees with a need to know, and shall protect it, in whole or in part, from disclosure and dissemination to third parties with the same degree of care it uses to protect its own confidential information, but with no less than reasonable care. Except as expressly authorized in writing by Nortel Networks, the holder is granted no rights to use the information contained herein.

This is the Way, This is Nortel, Nortel, the Nortel logo, the globemark design, and the NORTEL NETWORKS corporate logo, are trademarks of Nortel Networks. All other trademarks are the property of their respective owners. All rights reserved.

