

Feature Operation

Auto Dial			
store	AutoDI		^AutoDI
use		AutoDI	
display	Display	AutoDI	
Hold			
place a call on hold			
return to a held call			
Transfer			
	Trans		^Trans
Handsfree (if configured)			
activate			
switch to handset			
handset to handsfree			
Mute (On/Off)			
Conference			
	Conf		^Conf
Last Number Redial			
Ring Again			
activate	RingAgn		
when notified		^RingAg	
cancel	^RingAg		
Call Forward			
activate	Forward		^Forwar
cancel	^Forwar		
reinstate	Forward	^Forwar	
view number	Display	^Forwar	
Call Pickup			
		Pickup	
Call Waiting			
answer		^CWait	
return to first call			
Message			

Explanations

Legend

	Lift the handset, or press the DN key, or press the Hands-free key.
	Replace handset, or press to end the call.
	Dial a number.
	Press the line (DN) key.
^AutoDI	The ^ flashes when a feature is being programmed. The ^ lights steadily when a feature is active.

Programming your Meridian/Succession CSE 1000 i2004 Internet Telephone

Telephony Options List

Access the Telephony Options List

/ Select

Volume adjustment

Ringer	Select	/	Select	Cancel	Cancel
Handset Listen	Select	/	Select	Cancel	Cancel
Handsfree Listen	Select	/	Select	Cancel	Cancel
Headset Listen	Select	/	Select	Cancel	Cancel
Buzzer	Select	/	Select	Cancel	Cancel

Contrast adjustment

/ Select Cancel

Language

/ Select Select Cancel

Date/time format

/ Select Cancel

Display diagnostics

/ Cancel

Key click enable

/ Select Cancel

Ring type

/ Play Select Cancel

Call timer

/ Select Cancel


OnHook Default Path

/ Select Cancel

For additional information on the operation of your telephone, please consult the *Meridian/Succession CSE 1000 i2004 Internet Telephone User Guide*.

Introducing your Meridian/Succession CSE 1000 i2004 Internet Telephone

NORTEL
NETWORKS



Meridian/Succession CSE 1000 Internet Telephone

i2004
Quick Reference Card

