



1992-1995 Honda Civic Oil and Oil Filter Replacement

A video tutorial on how to change the oil and oil filter on a 1992-1995 Honda Civic.

Written By: eCuration



INTRODUCTION

A video guide on how to change the oil and oil filter on a 1992-2000 Honda Civic.

TOOLS:

- Hydraulic Floor Jack (1)
- Jack Stand (1)
- Oil Drain Pan (1)
- Oil Filter Wrench (1)
- Long Neck Funnel (1)
- 3/8" Drive Ratchet (1)
- 17 mm Box End Wrench (1)
- Paper Towels (1)
- Torque Wrench (1)
- Socket 17mm (1)

PARTS:

- 5W-30 Motor Oil (4)
- Oil Filter Honda Civic 1992-2000 (1)

To reassemble your device, follow these instructions in reverse order.