



1993-1997 Toyota Corolla Coolant Replacement

A video tutorial that will show you how to change the old coolant in your 1993-1997 Toyota Corolla.

Written By: eCuration



INTRODUCTION

You should change the engine coolant once every 2 years.

Follow this video tutorial by YouTuber [NutzAboutbolts](#) to complete this job yourself.

TOOLS:

- Oil Drain Pan (1)
- Long Neck Funnel (1)

PARTS:

- Engine Coolant (1)

To reassemble your device, follow these instructions in reverse order.