



1994-1997 Honda Accord Coolant Replacement

A video tutorial on how to change the coolant by draining and refilling on your 1994-1997 Honda Accord.

Written By: eCuration



INTRODUCTION

You should change the coolant in your Honda Accord once every two years.

Follow this video guide by YouTuber [NutzAboutBolts](#) to do the job yourself.

TOOLS:

- Oil Drain Pan (1)
- Long Neck Funnel (1)

PARTS:

- Engine Coolant (1)

To reassemble your device, follow these instructions in reverse order.