




1998-2002 Honda Accord Drive Belt Replacement

A video tutorial on how to change an old worn out drive serpentine belt on a 1998-2002 Honda Accord.

Written By: eCuration



This document was generated on 2019-09-21 01:56:06 PM (MST).

INTRODUCTION

A noisy belt and or belt wear is an indication that a belt should be replaced. Belts are usually replaced at 105k miles or 7 year intervals.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the job yourself.

TOOLS:

- 3/8" Drive Ratchet (1)
- 14mm Deep Socket (1)
- 12mm Deep Socket (1)
- 10mm Socket (1)
- Pry Bar (1)

PARTS:

- Power Steering Belt (1)
- Alternator Belt (1)

To reassemble your device, follow these instructions in reverse order.