



2000 Gmc Sierra Light Replacement

A simple and effective guide on replacing the headlights, taillights, and overhead light.

Written By: keith beaudoin



INTRODUCTION

A simple and effective guide on replacing the headlights, taillights, and overhead light.

TOOLS:

- Phillips #2 Screwdriver (1)

Step 1 — Headlights, Taillights, and an overhead light



- Open your tailgate fully, exposing both sides where the tailgate sits.

Step 2



- Unscrew the two phillips head screws located above and below the tailgate support.

Step 3



- Once the screws have been removed, simply pull off the taillight. The red plug is the taillight. Twist it a quarter turn counter clockwise, and pop it out.

Step 4



- Remove the old bulb and replace it with your new one.
- Side note: Make sure replacement bulb is save voltage/amperage rating.

Step 5



- Open the hood and take a look above your headlights.

Step 6



- Two metal pins holding each of the headlights in place will need to be removed (no tool necessary).
- Turn the plastic headlight mount counter clockwise by one quarter of a turn.
- Then lift the pins up to fully remove them.

Step 7



- Once the pins have been removed, GENTLY pull your headlight upwards, towards you. The bulbs should now be exposed. The bulb on the top is your headlight.

Step 8



- As you did with the taillight bulb, turn the piece that is holding the bulb in place a quarter turn counter clockwise, and the bulb will pop out. Now your new bulb will take it's place.

To reassemble your device, follow these instructions in reverse order.