



# 2002-2006 Toyota Camry Engine Air Filter Replacement

A video tutorial on how to change the engine air filter on a 2002-2006 Toyota Camry.

Written By: eCuration



## INTRODUCTION

If you are experiencing reduced fuel economy or horsepower, misfiring engine, and or unusual sounds then it may be time to replace the engine air filter. Regardless of issues, the engine air filter should be replaced every two years.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.

### TOOLS:

- [3/8" Drive Ratchet](#) (1)
- [10mm Deep Socket](#) (1)
- [3/8-Inch Drive Extension Bar](#) (1)
- [Torque Wrench](#) (1)

### PARTS:

- [Engine Air Filter](#) (1)

To reassemble your device, follow these instructions in reverse order.