



# 2002-2006 Toyota Camry Oil And Oil Filter Replacement

A video tutorial on how to replace and change out the oil and oil filter on a 2002-2006 Toyota Camry.

Written By: eCuration



This document was generated on 2019-09-26 04:05:33 AM (MST).

## INTRODUCTION

This short video guide will show you how to replace the oil and oil filter on your 2002-2006 Toyota Camry.

Do this maintenance every 5k miles.

[video: <https://www.youtube.com/watch?v=Zj3tlcGqjU8>]

### TOOLS:

- Hydraulic Floor Jack (1)
- Jack Stand (1)
- 3/8" Drive Ratchet (1)
- 10" Ratchet Extension (1)
- 14 mm socket (1)
- Oil Drain Pan (1)
- Oil Filter Wrench (1)
- Long Neck Funnel (1)

### PARTS:

- 5W-30 Motor Oil (5)
- Oil Filter Engine Toyota Camry 2002-2006 (1)

To reassemble your device, follow these instructions in reverse order.