



2004-2008 Audi A4 (B7) Ignition Coil Replacement

A video tutorial on how to repair, install, fix, change or replace a bad or broken ignition coil or coil pack on a 2005-2008 Audi A4.

Written By: eCuration



This document was generated on 2019-11-05 06:09:20 PM (MST).

INTRODUCTION

One of the most common symptoms associated with a faulty ignition coil is engine performance issues.

If you are experiencing misfires, a rough idle, loss of power, and or a reduction in gas mileage then follow this video guide to replace the ignition coils yourself.

TOOLS:

- [T20 Torx Screwdriver](#) (1)
- [Flathead Screwdriver](#) (1)

PARTS:

- [Ignition Coil](#) (1)

To reassemble your device, follow these instructions in reverse order.