



2005 Honda Pilot Rear Strut Replacement

This guide will show how to change the rear struts of a 2005 Honda Pilot.

Written By: Kayla Peterson



INTRODUCTION

Having your vehicle struts crack, break, or simply stop working is a very common problem with cars today. Without working struts on the trunk of your car, it is difficult to open and close your trunk.

TOOLS:

- Small Flathead Screw Driver (1)

PARTS:

- Lift Support Struts (1)

Step 1 — Rear Struts



- Begin by placing a support beneath the trunk that takes all the weight of the trunk.

Step 2



- Insert the flat head screwdriver under the clip, at the top of the strut, and lift the clip until it pops off completely.

Step 3



- Now, insert the flat head screwdriver under the clip, at the bottom of the strut, and lift the clip until it pops off completely.

Step 4



- Line up the ball and the socket pieces of your new strut.

Step 5



- Use force to push the strut and connect the ball and socket joint.

To reassemble your device, follow these instructions in reverse order.