



2005-2015 Nissan Xterra Oil and Oil Filter Replacement

A video tutorial on how to change the oil and oil filter on a 2005-2015 Nissan Xterra.

Written By: eCuration



INTRODUCTION

An oil change should be performed every 5,000 miles.

Follow this video tutorial by YouTuber [Ry The Car Guy](#) to complete the replacement yourself.

Safety

If this is your first time working on a vehicle read our [safety tips](#) before proceeding.

TOOLS:

- Hydraulic Floor Jack (1)
- Jack Stands (1)
- Wheel Chocks (1)
- Oil Drain Pan (1)
- Oil Filter Wrench (1)
- 3/8" Drive Ratchet (1)
- 14mm socket (1)
- Shop Towels or Rags (1)
- Latex or nitrile gloves (1)

PARTS:

- 5W-30 Motor Oil (5.4)
- Oil Filter (1)
- Oil Drain Plug and Gasket (1)

To reassemble your device, follow these instructions in reverse order.