



2006-2008 Toyota RAV4 Cabin Air Filter Replacement

Are you noticing a strange smell on the inside of your RAV4? The cabin air filter likely needs to be replaced. This free video guide will show you how!

Written By: eCuration



INTRODUCTION

The inside cabin air filter is essential as it filters the outside air of pollutants before it enters the vehicle and should be replaced once every year.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.



TOOLS:

- [Pair of Hands](#) (1)



PARTS:

- [Cabin Air Filter](#) (1)

To reassemble your device, follow these instructions in reverse order.